



NTC-500 Series User Guide

NTC-501
NTC-502

Part Number PMD-00315
Revision A June 2025

Trademark Notice

This product may reference NetComm. On December 26, 2024, Lantronix, Inc. acquired the Industrial Internet of Things (IIoT) product portfolio from NetComm Wireless Pty Ltd and is authorized to use the NetComm trademark in association with this product.

Intellectual Property

© 2025 Lantronix, Inc. All rights reserved. No part of the contents of this publication may be transmitted or reproduced in any form or by any means without the written permission of Lantronix.

Lantronix is a registered trademark of Lantronix, Inc. in the United States and other countries.

Patented: <https://www.lantronix.com/legal/patents/>. Additional patents pending.

Warranty

For details on the Lantronix warranty policy, please go to our web site at <https://www.lantronix.com/support/warranty/>.

Contacts

Lantronix, Inc.
48 Discovery, Suite 250
Irvine, CA 92618, USA
Toll Free: 800-526-8766
Phone: 949-453-3990
Fax: 949-453-3995

Technical Support

Online: www.lantronix.com/technical-support/

Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix website at <https://www.lantronix.com/about-us/contact/>.

Disclaimer

All information contained herein is provided “AS IS.” Lantronix undertakes no obligation to update the information in this publication. Lantronix does not make, and specifically disclaims, all warranties of any kind (express, implied or otherwise) regarding title, non-infringement, fitness, quality, accuracy, completeness, usefulness, suitability or performance of the information provided herein. Lantronix shall have no liability whatsoever to any user for any damages, losses and causes of action (whether in contract or in tort or otherwise) in connection with the user’s access or usage of any of the information or content contained herein. The information and specifications contained in this document are subject to change without notice.

Important Notice

This device, like any wireless device, operates using radio signals which cannot guarantee the transmission and reception of data in all conditions. While the delay or loss of signal is rare, you should not rely solely on any wireless device for emergency communications or otherwise use the device in situations where the interruption of data connectivity could lead to death, personal injury, property damage, data loss, or other loss. Lantronix accepts no responsibility for any loss or damage resulting from errors or delays in transmission or reception, or the failure of the Lantronix NTC-500 Series router to transmit or receive such data.

Safety and Hazards



Warning: Do not connect or disconnect cables or devices to or from the USB port, SIM card tray, Ethernet port or the terminals of the power connector in hazardous locations such as those in which flammable gases or vapours may be present, but normally are confined within closed systems; are prevented from accumulating by adequate ventilation; or the location is adjacent to a location from which ignitable concentrations might occasionally be communicated.

Revision History

Date	Rev.	Comments
June 2025	A	Reformatted to Lantronix For prior document history, see <i>Appendix B. NetComm Document History</i> .

For the latest revision of this product document, please check our online documentation at <https://www.lantronix.com/support/documentation/>.

Contents

1. Overview	9
Introduction.....	9
Target audience.....	9
Prerequisites.....	9
Notation.....	9
2. Product introduction	10
Product overview	10
Product features.....	10
Package contents.....	10
3. Physical dimensions and indicators.....	11
Physical dimensions.....	11
Interfaces.....	12
LED indicators.....	13
Signal strength LEDs	14
LED update interval	14
Ethernet port LED indicators	14
4. Placement of the router	15
Antenna installation	15
Mounting options	16
DIN rail mounting bracket	16
DIN rail installation	17
Wall mounted via DIN bracket	17
Ceiling mounted via DIN bracket.....	18
Pole mounted via DIN bracket	18
Rail mounting adapter.....	19
5. Installation and configuration of the NTC-500 Series router.....	20
Powering the router	20
DC power via 2-way connector	20
DC power via field terminated power source	20
Installing the router.....	20
6. Advanced configuration.....	21
Initialization	21
Configure as a new device (create new passwords)	22

Logging In.....	23
7. Status	24
8. Networking	29
Cellular settings	29
Wireless WAN profiles.....	29
Band selection	33
SIM management	33
Operator setting	34
Cell lock.....	36
SIM security	37
5G Network slicing.....	38
Service assurance	41
LAN	42
LAN	42
DHCP	43
VLAN	45
Routing settings.....	48
Static routes	48
Firewall	50
DMZ	51
Port forwarding	52
Filtering.....	53
Redundancy (VRRP).....	56
RIP	60
VPN	61
IPSec	61
OpenVPN	65
GRE Tunnelling	72
Server Certificate.....	74
9. Services	77
Network time (NTP).....	77
SNMP	79
Configuring SNMP	79
Configuring SNMP traps	80
TR-069.....	81

DNS server	82
SMS messaging	83
Setup.....	83
Diagnostics	85
Inbox.....	98
New message.....	98
Outbox.....	99
MQTT	99
Configuring MQTT	101
OMA-LWM2M	104
Supported LWM2M objects	105
Event Configuration.....	107
Event Notification Configuration.....	108
Destination configuration.....	109
Event notification log	111
Email Settings	112
Dynamic DNS	114
10. System	115
Log	115
System log	115
System log settings.....	115
Diagnostic log	118
IPSec log.....	120
Watchdog	121
Periodic ping.....	121
Periodic reboot.....	123
System configuration.....	123
Restore factory defaults	123
Web server setting	124
Administration settings	125
Settings backup/restore	127
Site and location settings	128
Runtime configuration	129
SSH key management.....	129
LED operation mode.....	132

A/B system configuration	133
Firmware upgrade	134
Updating the router firmware	134
Access control.....	134
Reboot	136
Field test	137
Encrypted debuginfo	138
Appendix A. Configuring Radio Access Technologies	139
Appendix B. NetComm Document History	140
Appendix C. Compliance Information	141

1. Overview

Introduction

This document provides you all the information you need to set up, configure and use the Lantronix NTC-500 Series router.

Target audience

This document is intended for system integrators or experienced hardware installers who understand telecommunications terminology and concepts.

Prerequisites

Before continuing with the installation of your NTC-500 Series router, please confirm that you have the following:

An electronic computing device with a working Ethernet network adapter and a web browser such as Mozilla Firefox® or Google Chrome™.

Notation

The following symbols may be used in this document:



Note: *This note contains useful information.*



Important: *This is important information that may require your attention.*



Warning: *This is a warning that may require immediate action in order to avoid damage or injury.*

2. Product introduction

Product overview

The NTC-500 Series router is a high-end high-speed industrial-grade 5G router. Designed with critical and complex applications in mind, it provides ultra-reliable, high bandwidth throughput even in extremely harsh environments.

The NTC-500 Series router supports the latest 3GPP Release 16 5G features including 5G Non-standalone (NSA), 5G Standalone (SA) and 5G Slicing which enables complex end-to-end, on-demand quality of service solutions in partnership with leading carrier networks.

Perfect for connected smart building systems, vending and ticketing machines, digital signs, surveillance systems, traffic light control and remote vehicle automation.

Product features

- 5G Standalone (SA)
- 5G Non-Standalone (NSA) with failover to 4G
- 2.5GbE Ethernet Port
- Robust ruggedized industrial-grade metal housing with multiple mounting options
- Wide operating temperature range
- Designed, assembled and tested for unmanned locations in extreme environments
- Easy and clear LED status display for connection status and network type as well as two user-customizable LEDs.
- Remote device configuration, management, and firmware upgrade.

Package contents

The Lantronix NTC-500 Series package contains:

- 1 x NTC-500 Series router
- 1 x Two-way Molex connector
- 1 x 1.5m Ethernet cable
- 1 x DIN rail mounting bracket
- 1 x Welcome Card

If any of these items are missing or damaged, please contact your sales representative or the support team.

3. Physical dimensions and indicators

Physical dimensions

Figure 3-1 NTC-500 Series router top and side views




Table 3-1 Router Dimensions

NTC-500 SERIES ROUTER DIMENSIONS	
Length	143.5 mm
Depth	110.5 mm
Height	30.0 mm
Weight	410 grams

Interfaces

The following interfaces are available on the NTC-500 Series router:

Table 3-2 Interfaces

ITEM	DESCRIPTION
Antenna sockets	SMA female connector for cellular antennas.
SIM card tray	Insert SIM card here.
SIM Eject button	Press with a SIM removal tool to eject the SIM card tray.
Two-way terminal block connector	Connect power source wires here. Power wires may be terminated on optional terminal block and connected to DC input jack. Refer to the diagram and table under the Installation section for correct wiring of the terminal block. Operates in the 8-40V DC range.
Factory reset button	Press and hold for less than 5 seconds to reboot to normal mode. The LEDs are green and extinguish in sequence to indicate that the router will reboot normally if the button is released during this period. Press and hold for 5 to 15 seconds to reboot to recovery mode. The LEDs are amber and extinguish in sequence to indicate that the router will load the recovery image. Press and hold for 15 to 25 seconds to reset the router to factory default settings. The LEDs are red and extinguish in sequence to indicate that the router will reset to factory default settings if the button is released during this period
2.5GbE RJ45 Ethernet port	Connect one or several devices via a network switch here.
USB-C port	Provides USB connectivity for debugging.

LED indicators

The NTC-500 Series router uses nine LEDs to display the current system and connection status.

Figure 3-2 LED indicators




Table 3-3 LED indicators

LED	NAME	COLOUR	STATE	DESCRIPTION
	Power		Off	Power off
			Blinking	Router starting up
			On	Power on
	SIM		Off	No SIM detected
			Blinking	SIM error
			On	SIM installed and working
	4G Network		Off	No 4G connection
			Blinking	Connecting to 4G network
			On	4G connected
	5G Network		Off	No 5G connection
			Blinking	Connecting to 5G network
			On	5G connected
	Signal Strength		Off	No signal
			One Lit	Poor signal
			Two Lit	Fair signal
			Three Lit	Good signal
	Custom 1	Customizable		Programmable LED for custom use
	Custom 2	Customizable		Programmable LED for custom use

Signal strength LEDs

The following table lists the signal strength range corresponding with the number of lit signal strength LEDs.

Table 3-4 Signal strength of LED indicators

NUMBER OF LIT LEDs	SIGNAL STRENGTH
All LEDs unlit	No signal
1	> -90 dBm
2	-70 dBm to -90 dBm
3	< -70dBm


LED update interval

The signal strength LEDs update within a few seconds with a rolling average signal strength reading. When selecting a location for the router or connected or positioning an external antenna, please allow up to 20 seconds for the signal strength LEDs to update before repositioning.

Ethernet port LED indicators

The Ethernet port of the NTC-500 Series router has two LED indicators.

Figure 3-3 NTC-500 Series Ethernet port LED indicators



The table below describes the status of each light and their meanings.

Table 3-5 Ethernet port LED indicators

LED	STATUS	DESCRIPTION
Green	On	Valid network link.
	Blinking	Activity on the network link.
	Off	No valid network detected.
Amber	On	Ethernet port is operating at a speed of 100Mbps or 1000Mbps or 2500Mbps.
	Off	Ethernet port is operating at a speed of 10Mbps or no Ethernet cable is connected

4. Placement of the router

Antenna installation

The router is fitted with four SMA female antenna connectors. Attach antennas fitted with a SMA male connector by turning them in a clockwise direction.

Figure 4-1 NTC-500 Series router antenna installation



Connecting antennas to the device should provide optimum cellular and Wi-Fi signal strength in a wide range of environments. If you find the signal strength is weak, try adjusting the orientation of the antennas. If you are unable to get an acceptable signal, try moving the router to a different place or mounting it differently.



Note: When selecting a location for the router, allow at least 20 seconds for the signal strength LEDs to update before trying a different location.

For best performance, position the antennas as shown in the following diagram.

Figure 4-2 NTC-500 Series router optimal antenna positioning




Mounting options

The NTC-500 Series router can be quickly and easily mounted in a variety of locations.

DIN rail mounting bracket

The DIN rail mounting bracket provides multiple ways to mount the router. Clip the router into the bracket as shown below.


Figure 4-3 NTC-500 Series router DIN mounting bracket



DIN rail installation


The V Bend allows you to snap the DIN bracket onto the middle of a DIN rail rather than sliding it onto the end.

Figure 4-4 NTC-500 Series router DIN mounting bracket




Wall mounted via DIN bracket

Figure 4-5 NTC-500 Series router wall mounted using DIN bracket




Ceiling mounted via DIN bracket

Figure 4-6 NTC-500 Series router ceiling mounted using DIN bracket



Pole mounted via DIN bracket

Figure 4-7 NTC-500 Series router pole mounted using DIN bracket



Rail mounting adapter

The NTC-500 Series router can also be mounted by using an optional rail mount adapter.

Figure 4-8 NTC-500 Series router rail mount adapter



5. Installation and configuration of the NTC-500 Series router

Powering the router

The NTC-500 Series router can be powered in one of two ways:

- DC power input via 2-pin connector (8-40V DC)
- DC power input via field terminated power source (8-40V DC)

The green power LED on the router lights up when a power source is connected. Nominal power input is (12V DC/1.5A).

DC power via 2-way connector

The positive and ground terminals on the 6-pin connector can accept power from a separately sold DC power supply. Both a standard temperature range DC power supply and an extended temperature range DC power supply are available to purchase as accessories.

If you have purchased an optional DC power supply, first remove the terminal block from the connector. The terminal block connector uses rising cage clamps to secure the wires and ships with the cages lowered and ready for wire insertion. Inspect the cage clamps and use a flathead screwdriver to lower the cage clamps if they have become raised. Insert the wires into the terminal block as shown below, noting the polarity of the wires, then use a flathead screwdriver to raise the cage clamp to secure the wires in the terminal block. Insert the wired terminal block into the terminal block connector of the router and then connect the adapter to a wall socket.

DC power via field terminated power source

If an existing 8-40V DC power supply is available, you can insert the wires into the supplied terminal block to power your router. Use a flathead screwdriver to tighten the terminal block screws and secure the power wires, making sure the polarity of the wires is correctly matched, as illustrated below. You should avoid using DC cables greater than 2 metres in length.

Installing the router

After you have mounted the router and connected a power source, follow these steps to complete the installation process.

1. Connect equipment that requires network access to the Ethernet port of your router. This may be your computer for advanced configuration purposes, or your end equipment which requires data access via the NTC-500 Series router. You can connect one device directly, or several devices using a network switch.
2. If you are attaching antennas, first remove the antenna socket caps from the Main and Auxiliary antenna sockets by turning them in an anti-clockwise direction, then screw the antennas onto the sockets by turning them in a clockwise direction.
3. If your router does not come with a SIM pre-installed, insert a SIM card into the SIM card slot by pressing the SIM Eject button to eject the SIM card tray. Place the SIM card in the tray and then insert the loaded tray into the SIM slot with the gold side facing up.
4. Ensure the external power source is switched on and wait 2 minutes for your NTC-500 Series router to start up and connect to the mobile network. Your router arrives with preconfigured settings that should suit most customers. Your router is now connected. To check the status of your router, compare the LED indicators on the device with those listed in the LED indicators table.

6. Advanced configuration

To access the web-based user interface, open a web browser (e.g. Mozilla Firefox or Google Chrome), type **https://192.168.1.1** into the address bar and press **Enter**.

The router's web user interface is displayed.



Important: The HTTP protocol is disabled by default, secure HTTP (HTTPS) is the default protocol. HTTP access is available but must be manually enabled.

Initialization

The first time the device is booted (or booted after it is factory reset), the device enters "Configuration mode". In Configuration mode, the router runs a setup wizard which must be completed before it will boot into "Live mode". This is a security feature which enables you to set strong passwords for web root, web user, and Telnet/SSH access or restore a previous configuration from a file.

To complete the setup:

1. Select the Next button on the first dialogue box.

Welcome to your new router. The router is now in configuration mode and must be either configured with secure passwords or restored to a previous configuration before it is operational.

Next

2. Enter the factory default password which is printed on the device label then select the Next button.

To begin using your device, please enter the factory default password. The factory default password is printed on the device label.

Next

3. Select whether to configure the router as a new device or to restore a previous configuration backup.

Configure as a new device (create new passwords)

Select **I want to configure this as a new device** then select the **OK** button.

In the New Passwords section, enter a strong password in each field. You may configure the same password for all three accounts, but it must meet the security criteria set out below:

The password must be a minimum of eight characters and no more than 128 characters in length.

The password must contain at least one upper case, one lower case character and one number.

The password must contain at least one special character, such as: ` ~ ! @ # \$ % ^ & * () - _ = + [{] } \ | ; : ' " , < > / ?

Additionally, the password must satisfy an algorithm which analyses the characters as you type them, searching for commonly used patterns, passwords, names and surnames according to US census data, popular English words from Wikipedia and US television and movies and other common patterns such as dates, repeated characters (aaa), sequences (abcd), keyboard patterns (qwertyuiop) and substitution of numbers for letters.


Figure 6-1 New device configuration dialog page

When you have completed all password fields, press the **Save** button. If the passwords meet the security criteria, they are saved and the router reboots to Live mode automatically. See below for further instructions on logging in.

Logging In

To log in to the router, enter the login username (root or user) and the password that you configured during the initialisation process.

Figure 6-2 Log in prompt for web-based user interface

The image shows a web browser window displaying the NetComm login interface. At the top, there is a navigation bar with the NetComm logo on the left and several menu items: Status, Networking, Services, System, and Help. A user icon is located on the far right of the navigation bar. Below the navigation bar, the main content area has a light gray background. In the center, the word "Login" is displayed in blue. Below "Login", there are two input fields: "Username" and "Password". The "Password" field has a small eye icon to its right, indicating a toggle for password visibility. Below the input fields, there is a blue button labeled "Log in".


Note: If logging in with the account user, the account allows you to manage all settings of the router except functions such as firmware upgrade, device configuration backup and restore and reset to factory default settings, which are privileged only to the root manager account.



7. Status

The status page of the web interface provides system related information and is displayed when you log in to the NTC-500 Series router management console. The status page shows System information, LAN details, Cellular connection status, WWAN connection status, Wireless LAN status and Neighbouring cell information. You can toggle the sections from view by selecting the  or  buttons to show or hide them. Extra status boxes will appear as additional software features are enabled (e.g. VPN connectivity).

Figure 7-1 NTC-500 Series router status page



NetComm | **Status** | Networking | Services | System | Help | admin

SYSTEM INFORMATION

Device information

Device name
5G Industrial IoT Router

Model
[Redacted]

Uptime
00:06:17

Site name
Not configured

Location
Not configured

Serial number
[Redacted]

Hardware version
[Redacted]

Device firmware
[Redacted]

Cellular module

Model
[Redacted]

Module firmware
[Redacted]

IMEI
[Redacted]

LAN

IP
[Redacted]

MAC address
[Redacted]

Ethernet port status
Up / 1000 Mbps / FDX

IP passthrough host MAC
[Redacted]

CELLULAR CONNECTION STATUS

WWAN CONNECTION STATUS

ADVANCED STATUS

The following information is included on the Status page:

Table 7-1 Status page item details

Item	Definition
System information	
System up time	The current up time (the time since the router was last turned on) of the router.
Site name	The configured site name.
Location	The configured location.
Device name	The device name of the NTC-500 Series router.
Model	The commercial product name which helps to identify the available features of the router.
Hardware version	The hardware version of the router.
Serial number	The serial number of the router.
Firmware version	The firmware version of the router
Cellular Model	The type of phone module and the firmware version of the module.
Module firmware	The firmware revision of the phone module.
IMEI	The International Mobile Station Equipment Identity number used to uniquely identify a mobile device.
LAN	
IP	The IP address and subnet mask of the router.
MAC address	The MAC address of the router.
LAN Port Status	Displays the current status of the LAN port and its operating speed.
IP passthrough host MAC	The MAC address associated with the passthrough host when IP passthrough is enabled.
Cellular Connection Status	
SIM status	Displays the activation status of the NTC-500 Series router on the carrier network. This includes information about whether there is a SIM inserted or if the SIM card has an error.
Signal strength (dBm)	The current signal strength measured in dBm.
Network registration status	The status of the NTC-500 Series router registration for the current network.
Operator selection	The mode used to select an operator network.

Item	Definition
Provider	The current operator network in use.
Roaming status	The roaming status of the NTC-500 Series router.
Allowed bands	The bands to which the NTC-500 Series router may connect.
Current band	The current band being used by the NTC-500 Series router.
Connection (RAT)	The radio access technology in use.
Coverage	The type of mobile coverage being received by the NTC-500 Series router.
WWAN	
Profile name	The name of the active profile.
Status	The IPv4 connection status of the active profile.
IPv6 status	The IPv6 connection status of the active profile.
MTU	The current IPv4 Maximum Transmission Unit (MTU) of the WWAN connection.
IPv6 MTU	The current IPv6 Maximum Transmission Unit of the WWAN connection.
WWAN IP	The IPv4 address assigned by the mobile broadband carrier network.
DNS server	The primary and secondary IPv4 DNS servers for the WWAN connection.
WWAN IPv6	The IPv6 address assigned by the mobile broadband carrier network.
IPv6 DNS server	The primary and secondary IPv6 DNS servers for the WWAN connection.
APN	The Access Point Name currently in use.
Connection uptime	The length of time of the current mobile connection session.
Max DL	The maximum download speed that is possible.
Max UL	The maximum upload speed that is possible.
Current DL	The current download speed.
Current UL	The current upload speed.
Advanced Status	
Mobile country code	The Mobile Country Code (MCC) of the NTC-500 Series router.
Mobile network code	The Mobile Network Code (MNC) of the NTC-500 Series router.
SIM ICCID	The Integrated Circuit Card Identifier of the SIM card used with the NTC-500 Series router, a unique number up to 19 digits in length.

Item	Definition
IMSI	The International Mobile Subscriber Identity is a unique identifier of the user of a cellular network.
Packet service status	Displays whether the packet service is attached or detached. When APN or username/password is changed, the device detaches and reattaches to the network.
ECGI	E-UTRAN Cell Global Identifier. The globally unique identity of a cell in E-UTRA. The ECGI concatenates the PLMN-Id and the ECI (E-UTRAN Cell Identifier). The ECI concatenates the eNodeB ID and the Cell ID
eNodeB	Also known as the Evolved Node B, this is the hardware element in the LTE network that communicates directly with mobile devices.
Cell ID	A unique code that identifies the base station from within the location area of the current mobile LTE network signal.
PCI	Physical Cell ID of the LTE Cell.
Channel number (EARFCN)	The channel number of the current cellular connection.
Reference Signal Received Power (RSRP)	A cell-specific reference signal used to determine RSRP.
Reference Signal Received Quality (RSRQ)	RSRQ calculates signal quality taking into consideration the RSSI. It is calculated by $N \times \text{RSRP} / \text{RSSI}$ where N is the number of Physical Resources Blocks (PRBs) over which the RSSI is measured.
Signal to interference plus noise ratio (SINR)	The power of a certain signal of interest divided by the sum of the interference power (from all the other interfering signals) and the power of some background noise.
CQI	Channel Quality Indicator. This is a value between 1 and 15 with 15 being the highest rating.
NCGI	NR Cell Global Identifier. This concatenates the PLMN-Id (PLMN Identifier) and the 36bit NCI (NR Cell Identity). This information is not available when the device is operating in LTE or 5G Non-Standalone mode.
gNodeB	The gNodeB (gNB) is the term given to network equipment that transmits and receives wireless communications between UE and a mobile network
gNB Cell ID	A unique code that identifies the base station from within the location area of the current mobile 5G network signal. This is not available when the device is operating in LTE or 5G Non-Standalone mode.
gNB PCI	Physical Cell ID of the 5G NR Cell.

Item	Definition
Channel number (NR ARFCN)	The channel number of the current 5G cellular connection.
SSB Channel Number (SSB ARFCN)	The Synchronization Signal Block (SSB) channel number of the current 5G cellular connection.
Subcarrier spacing (SCS)	The size of the current Subcarrier Spacing (SCS) expressed in KHz.
Reference Signal Received Power (SS-RSRP)	Synchronisation Signal Reference Signal Received Power (SS-RSRP). The linear average over the power contributions (in Watts) of the resource elements that carry Secondary Synchronisation Signal (SSS).
Reference Signal Received Quality (SS-RSRQ)	Secondary Synchronisation Signal Reference Signal Received Quality. SS-RSRQ calculates signal quality taking into consideration the RSSI. It is calculated by $N \times SS-RSRP / NR \text{ carrier RSSI}$ where N is the number of Physical Resource Blocks (PRBs) over which the NR RSSI is measured.
Signal to interference plus noise ratio (SS-SINR)	Synchronisation Signal – Signal to interference plus noise ratio. The power of a certain signal of interest divided by the sum of the interference power (from all the other interfering signals) and the power of some background noise.
NR CQI	The 5G NR Channel Quality Indicator (CQI).
Synchronization Signal Block (SSB) Index	This is a key part of beam management. It is a value comprised of Primary Synchronization Signal (PSS), Secondary Synchronization Signal (SSS) and the Physical Broadcast Channel (PBCH).
Neighbouring cell information	
PCI	The Physical Cell ID.
EARFCN	E-UTRA Absolute Radio Frequency Channel Number. Uniquely identifies the LTE Band and carrier frequency.
RSRP	Reference Signal Received Power (RSRP).
RSRQ	Reference Signal Received Quality (RSRQ).
Serving	The radio signal being served e.g., 5G NR, LTE.

8. Networking

The Networking section provides configuration options for Wireless WAN, LAN, Firewall, Routing and Service Assurance.

Cellular settings

Wireless WAN profiles

The wireless WAN profiles page allows you to configure and enable/disable connection profiles. To access this page, select on the Networking menu, and under the Wireless WAN menu, select the Wireless WAN profiles connection item.

Each profile refers to a set of configuration items which are used by the router to activate a Packet Data Protocol (PDP) context. Under normal scenarios, you may have a single profile enabled. Multiple profiles can be used for simple fast-switching of PDP settings such as APN, or for advanced networking configuration where multiple simultaneous PDP contexts may be required.

Figure 8-1 Wireless WAN profiles

WIRELESS WAN PROFILES						
Profile no.	Profile name	Status	APN	IP passthrough	Map to LAN/VLAN	Default route
1		☐ On ☒ Off	blank	☐ On ☒ Off	bridge0 v	☒ edit
2		☐ On ☒ Off	blank	☐ On ☒ Off	None v	☐ edit
3		☐ On ☒ Off	blank	☐ On ☒ Off	None v	☐ edit
4		☐ On ☒ Off	blank	☐ On ☒ Off	None v	☐ edit
5		☐ On ☒ Off	blank	☐ On ☒ Off	None v	☐ edit
6		☐ On ☒ Off	blank	☐ On ☒ Off	None v	☐ edit
Save						

Table 8-1 WWAN profile item details

ITEM	DEFINITION
Profile no.	Number of the profile.
Profile name	Name of the profile.
Status	Toggles the corresponding profile on and off. Only one profile may be turned on at any time.
APN	The APN configured for the corresponding profile.
IP passthrough	Allows a downstream device, such as a router, to manage the connection. The downstream device connects to the Internet and receives a WAN IP address so that all Internet traffic is passed to the downstream device. Internet traffic is still terminated at the gateway (NTC-500 Series router) and passed through to a downstream device, so the carrier is still able to connect to the gateway.
Map to LAN/VLAN	The LAN or VLAN that the profile is assigned to.
Default Route	Sets the profile as the default route for traffic.

Connecting to the mobile broadband network

The NTC-500 Series router supports the configuration of up to six APN profiles; these profiles allow you to configure the settings that the router will use to connect to the 5G/4G network and switch easily between different connection settings.

For advanced networking purposes, you may activate a maximum of two profiles simultaneously (dependent on network support). When activating two connection profiles, you should avoid selecting two profiles with the same APN as this can cause only one profile to connect. Similarly, activating two profiles which are both configured to automatically determine an APN can cause a conflict and result in neither profile establishing a connection. It is recommended that the two active connection profiles have differing, manually configured APNs to avoid connection issues and ensure smooth operation.

Manually configuring a connection profile

To manually configure a connection profile:

1. Select the edit  button corresponding the **Profile** that you wish to modify.
2. The **Wireless WAN profile settings** page is displayed.

Figure 8-2 WWAN profiles – WWAN profile settings

WIRELESS WAN PROFILE SETTINGS

PROFILE SETTINGS

Enable

Name

APN

Username

Password 👁

Authentication type ▾

PDP type ▾

MTU size 576-1500

Metric number 0-65535

IP passthrough

Allow admin access

Modem profile ▾ modem profile changes require a reboot to take effect

PROFILE ROUTING

You may route only particular traffic via this connection profile by specifying the network address and mask below of the destination network. Blank values will route all traffic via this profile. Please leave these settings blank if you are unsure.

Network address

Network mask

Table 8-2 WWAN profiles – WWAN profile settings details

Item	Definition
Enable	Toggle the enable button to On or Off , as desired.
Name	The name of the APN for easy identification on the Wireless WAN profile page. This name is only used to identify the profile on the NTC-500 Series router.
APN	Enter the APN (Access Point Name) configured for the corresponding profile.
Username	The username used to log on to the corresponding APN (if required).
Password	The password used to log on to the corresponding APN (if required).
Authentication type	The authentication type required by your provider. This can be set to: None , PAP or CHAP
PDP Type	Select the PDP type (IP protocol) to use for the connection.

Item	Definition
	Ⓐ IPv4 – Sets a single stack IPv4 connection through which the NTC-500 Series router receives only IPV4 network and DNS addresses. Ⓐ IPv6 – Sets a single stack IPv6 connection through which the NTC-500 Series router receives only IPV6 network and DNS addresses.  Note: Before selecting this PDP type, check with your carrier to confirm that single stack IPV6 connectivity is supported. Ⓐ IPv4v6 – Sets a dual stack connection allowing simultaneous IPV4 and IPV6 network connectivity. The NTC-500 Series router receives both IPv4 and IPV6 network and DNS addresses. This is the default PDP type
MTU size	Sets the Maximum Transmission Unit size. This may be from 1 to 1500 bytes.
Metric number	The Metric value is used by router to prioritise routes (if multiple are available) and is set to 25 by default.
IP passthrough	Allows a downstream device, such as a router, to manage the connection. The downstream device connects to the Internet and receives a WAN IP address so that all Internet traffic is passed to the downstream device. Internet traffic is still terminated at the gateway (NTC-500 Series router) and passed through to a downstream device, so the carrier is still able to connect to the gateway.
Allow Admin Access	Select enable if remote SSH, TR-069 or WebGUI access to the device should be possible via this Wireless WAN Profile. Note: SSH/HTTP/HTTPS can be individually restricted in the Access Control menu.  It will automatically be enabled if the profile is selected in the TR-069 settings menu.
Modem profile	Assigns the WWAN profile to a specific modem profile, which may be required by your carrier.
Profile routing	See the Profile routing section below.
Save button	Select the Save button to apply the changes.

Profile routing

For advanced networking such as using dual simultaneous PDP contexts, you may wish to configure a particular profile to route only certain traffic via that profile by configuring a custom address and mask of traffic to send via that profile. To do this, in the Profile routing settings section, enter the **Network address** and **Network mask** of the remote network. If you do not want to use this feature, or are unsure, please leave these fields blank. This will not designate any particular traffic to be routed via this profile.

Band selection

Select individual bands from the following band groupings: **LTE, NR5G NSA, NR5G SA.**

Figure 8-3 NTC-500 Series router band selection

NETWORK BANDS

4G LTE BANDS On Off

☒ B1	☒ B3	☒ B5	☒ B7	☒ B8
☒ B20	☒ B28	☒ B32	☒ B38	☒ B40
☒ B41	☒ B42	☒ B43		

Select all Unselect all Reset all

5G NR NSA BANDS On Off

☒ n1	☒ n3	☒ n5	☒ n7	☒ n8
☒ n20	☒ n28	☒ n38	☒ n40	☒ n41
☒ n75	☒ n76	☒ n77	☒ n78	

Select all Unselect all Reset all

5G NR SA BANDS On Off

☒ n1	☒ n3	☒ n5	☒ n7	☒ n8
☒ n20	☒ n28	☒ n38	☒ n40	☒ n41
☒ n75	☒ n76	☒ n77	☒ n78	

Select all Unselect all Reset all

Save

To set a device up for different **LTE**, 5G non-standalone (**NR5G NSA**) and 5G Standalone (**NR5G SA**) modes, refer to: **Appendix A – Configuring Radio Access Technologies**

SIM management

The NTC-500 Series router is equipped with both a removable and an internal SIM. To configure and switch between the two SIMs, the SIM management page is used. The SIM switching page also provides several failover options to switch between the SIM cards.

Figure 8-4 SIM management

SIM SWITCHING

SIM to use on startup Removable SIM ▼

Active SIM Internal SIM Switch active SIM

Switch to internal SIM if removable SIM is removed On Off

Enable failover based on network and usage factors On Off

Save

To select the SIM which should be used on startup, set the **SIM to use on startup** field to either **Internal SIM** or **Removable SIM**.

Active SIM displays the SIM that is currently in use. Click **Switch active SIM** to use the other SIM.

To automatically switch to the internal SIM if the removable SIM card is removed, set the **Switch to internal SIM if removable SIM is removed** toggle to **On**.

To configure **Failover** options, set the **Enable failover based on network and usage factors** to **On**, then set the relevant toggles for each condition that you would like to meet.

Click **Save** to apply any changes to this page.

Operator setting

The Operator setting screen lets you select whether to have the NTC-500 Series router automatically select the most appropriate operator and access technology, or if you set it to manual, you can override and lock it to a particular carrier or access technology. The operator setting page also contains roaming controls.

Figure 8-5 Operator setting

OPERATOR SETTING

OPERATOR SELECTION MODE

Select operator mode

Current operator registration

Scan

ROAMING CONTROL

Enable ☒ On ☐ Off

Save

Operator selection mode

Figure 8-6 Operator selection mode

OPERATOR SELECTION MODE

Select operator mode automatic

Current operator registration [blurred]

Scan

To scan for available networks, set the Select operator mode from **Automatic** to **Manual** then select the Scan button. This operation can take a few minutes and requires that the packet data session be disconnected prior to scanning. A list of the detected service carriers in your area is displayed.

Figure 8-7 Operator list

OPERATOR LIST					
	Operator name	MCC	MNC	Operator status	Network type
☐	Optus	505	02	forbidden	5G NR
☒	Boost	505	01	current	4G LTE
☐	voda AU	505	03	forbidden	4G LTE
☐	Optus	505	02	forbidden	4G LTE

Select the most appropriate service from the list shown and select **Apply**.

When **Select operator mode** is set to **Automatic**, the router selects the most appropriate operator based on the inserted SIM card. This is the default option and is sufficient for most users.

Roaming control

The roaming control function allows roaming to be enabled or disabled on the NTC-500 Series router. Enable roaming by setting the **Enable** toggle to **On**, then select **Save**.

Figure 8-8 Roaming control toggle

ROAMING CONTROL

Enable On Off

Save

Cell lock

The Cell lock function allows you to specify a list of cells that the NTC-500 Series router will not deviate from. The cells are separated by LTE and NR5G.

Figure 8-9 Cell lock

CELL LOCK LIST			
LTE CELL LOCK LIST		+ Add	
PCI	EARFCN		
5G NR CELL LOCK LIST		+ Add	
gNB PCI	SSB ARFCN	SCS	NR SA band

Adding an LTE cell lock

To add an LTE cell to the list:

1. Next to **LTE Cell Lock List**, select the **Add** button.
2. Enter the **PCI** and **EARFCN** values of the cell that you want to lock to.

Figure 8-10 Cell lock – Add LTE cell lock

CELL LOCK LIST

LTE CELL LOCK SETTINGS

PCI

EARFCN

3. Select on the **Save** button. Repeat steps 1 to 3 for all the LTE cells that you wish to add.

Adding an NR cell lock

1. Next to the **NR5G Cell Lock List**, select on the **Add** button.
2. Enter the gNB, NR ARFCN, Subcarrier Spacing and NR SA band values for the NR5G cell that you want to lock to.

Figure 8-11 Cell lock – Add NR5G cell lock

CELL LOCK LIST

NR5G CELL LOCK SETTINGS

gNB PCI

SSB ARFCN

SCS 15 KHz

NR SA band

3. Select on the **Save** button. Repeat steps 1 to 3 for all the NR5G cells that you wish to add.

SIM security

The SIM security settings page can be used for authenticating SIM cards that have been configured with a security PIN.

Figure 8-12 SIM security settings

SIM SECURITY

SIM SECURITY MANAGEMENT

Status SIM OK

PIN retries remaining 3

PIN protection ☒ On ☐ Off

Current PIN

Confirm current PIN

Remember PIN ☐

If the SIM card is locked, you will receive a notice when you access the Status page after which you will be directed to the PIN settings page to enter the PIN. The PIN settings page lists the status of the SIM at the top of the page.


If you are not redirected to the PIN settings page, to unlock the SIM:

1. Select the **Networking** menu from the top menu bar, and then select **SIM security settings**.
2. Enter the PIN in the **Current PIN** field (enter numbers only).
3. Select on the **Save** button to save the PIN and unlock access.
4. Once unlocked, you may toggle the **PIN protection** switch to the **Off** position if you no longer wish to have access locked by a PIN.

5G Network slicing

The 5G Network Slicing page allows to perform network slice configuration.

Figure 8-13 Network slice configuration




You can perform automatic or manual network slice configuration.

Automatic Network Slice Configuration


To perform automatic network slice configuration:

1. Select option Automatic for Slice configuration in the 5G Network Slicing page.
2. Set Multi-slice support to On or Off.
3. Click Apply

In the case **Multi-slice support** is set to **Off**, the below success message displays.



In the case **Multi-slice support** is set to **On**, the below success message and settings display.



Manual Network Slice configuration

To perform manual network slice configuration:

1. Select option **Manual** for **Slice configuration** in the 5G Network Slicing page. The below page displays.

Figure 8-14 Manual Network Slicing

The screenshot shows the '5G NETWORK SLICING' interface. At the top, 'Slice configuration' is set to 'Manual'. Below this is the 'URSP CONFIGURATION' section, which includes a table with columns: 'Rule DNN', 'Rule priority', and 'No. of route selection descriptors'. There is an '+ Add' button to the right of the table. At the bottom of the configuration area are 'Clear' and 'Apply' buttons.

2. Click **Add** for **URSP Configuration**, then click **Add** for **Route Selection Descriptor**. The below settings display.

Figure 8-15 Manual Network Slicing Configuration

The screenshot shows the '5G NETWORK SLICING' interface with the 'TRAFFIC DESCRIPTOR' section. It contains input fields for 'Rule DNN' and 'Rule priority' (with a range of 1-255). Below this is the 'ROUTE SELECTION DESCRIPTOR' section, which includes input fields for 'S-NSSAI SST' (with a range of 0-255), 'S-NSSAI SD' (optional), 'SSC mode' (set to 'URSP_SSC_MODE_1'), 'PDU session type' (set to 'PDU_IPV4'), and 'RSD priority' (with a range of 0-255). At the bottom are 'Save' and 'Cancel' buttons.

The table below lists the manual network slicing configuration details.

Table 8-3 Manual Network Slicing Configuration Items

Item	Definition
Traffic Descriptor	
Rule DNN	Enter the Data Network Name. It identifies the external data network (e.g., "internet" or an enterprise APN) that a PDU session should connect to.

Item	Definition
Rule priority	Enter a number from 1 to 255. It Determines the order in which URSP rules are evaluated (lower number = higher priority)
Route Selection Descriptor	
S-NSSAI SST	Enter the required value. Single-Network Slice Selection Assistance Information SST (Slice/Service Type) indicates the category or type of service the slice is intended to provide.
S-NSSAI SD	Enter the required value. Single-Network Slice Selection Assistance Information SD (Slice Differentiator) complements the mandatory SST (Slice/Service Type) to further differentiate between multiple network slices that share the same SST value.
SSC mode	Select a mode. Options are: • URSP_SSC_MODE_1: The network preserves the UE's connectivity and retains the same IP address throughout the session. • URSP_SSC_MODE_2: The network may release the PDU session and re-establish a new session, possibly assigning a new IP address. • URSP_SSC_MODE_3: The network allows the PDU Session Anchor (PSA) to be relocated while the session remains active, which can result in the IP address being changed.
PDU session type	Select an option. It specifies the kind of data connectivity established between a user device (UE) and the data network (DN) for a given PDU (Packet Data Unit) session. Options are: • PDU_IPV4 • PDU_IPV6 • PDU_IPV4V6
RSD priority	Enter a number from 0 to 255. It refers to the order in which Route Selection Descriptors (RSDs) are evaluated within a UE Route Selection Policy (URSP) rule.

- Click **Save** to save the settings. The above configuration is added to Route Selection Descriptor.

Service assurance

The service assurance page allows you to run a number of tests to confirm connectivity on different WWAN profiles.

Figure 8-16 Service assurance

SERVICE ASSURANCE

Here you can perform a network connectivity status check. Select the WWAN profile below to check.

WWAN profile(s) **1**

Enter the addresses and parameters in the fields below to perform the test. Fields left empty will result in the respective tests being skipped.

Domain name for DNS test

Destination for ping test

URL for web test

Request method in web test

Start

RESULT

Status

Progress stage

Error

1. To run a service assurance test:
2. In the **WWAN profiles** field select the WWAN profile you wish to test.
3. In the **Domain name for DNS test** field enter a Domain name to check the DNS connectivity.
4. In the **Destination for ping test** field enter an IPv4 IP address to test the ping.
5. In the **URL for web test** field enter a full URL to test a web page download.
6. In the **Request method in web test** dropdown, select either GET or PUT as the request method.
7. Press the **Start** button to run the test.

In the Results section, a successful test will show a Passed whilst a failed test will show Failed and which of the tests did not pass.

LAN

LAN

The **LAN configuration** page is used to configure the LAN settings of the NTC-500 Series router. To access the LAN configuration page, select on the Networking menu at the top of the screen, then select on the LAN menu on the left.

The default IP of the LAN port is 192.168.1.1 with subnet mask 255.255.255.0. To change the IP address, Subnet mask or Hostname enter the appropriate value into the field and select the **Save** button.



Note: If you change the IP address, remember to refresh the Ethernet interface of your device, or set an appropriate IP address range, then enter the new IP address into your browser address bar to access the NTC-500 Series router.

Figure 8-17 LAN configuration

The screenshot shows the 'LAN CONFIGURATION' page. At the top, there is a header 'LAN' and a sub-header 'LAN CONFIGURATION'. Below the sub-header, there are four configuration fields: 'IP address' with a numeric input showing '192', '168', '1', and '1'; 'Subnet mask' with a numeric input showing '255', '255', '255', and '0'; 'Hostname' with a text input showing 'my.router'; and 'DNS masquerading' with a toggle switch currently set to 'Off'. At the bottom of the form is a 'Save' button.

DNS masquerading

DNS masquerading allows the device to proxy DNS requests from LAN clients to dynamically assigned DNS servers. When enabled, clients on the local LAN network can use the router as a DNS server without needing to know the dynamically assigned cellular network DNS servers.

The DNS masquerading toggle key is OFF by default.

With DNS masquerading OFF, the DHCP server hands out the upstream cellular DNS server IP addresses to downstream clients directly, so that downstream clients send DNS requests directly to the upstream DNS servers without being proxied by the NTC-500 Series router.

With DNS masquerading ON, the DHCP server embedded in the NTC-500 Series router hands out its own IP address (e.g., 192.168.1.1) as the DNS server address to LAN clients. The downstream clients then send DNS requests to the NTC-500 Series router, which proxies them to the upstream DNS servers.

You may also override the DNS Masquerading option by specifying custom DNS Server IP addresses in the DNS server configuration, detailed in [DNS server section](#). In this case the DHCP server assigns downstream devices the manually configured addresses and the DNS Masquerading option is ignored.

The DNS masquerading toggle key is OFF by default.

DHCP

The **DHCP configuration** page is used to configure the DHCP settings of the NTC-500 Series router. You can manually set the start and end address range to be used to automatically assign addresses, the lease time of the assigned address, the default domain name suffix, primary and secondary DNS server, the primary and secondary WINS server, as well as the advanced DHCP settings such as NTP, TFTP and Option 150/Option 160 (VoIP options).

Figure 8-18 DHCP configuration

DHCP

DHCP CONFIGURATION

DHCP
☒ On
☐ Off

DHCP start range
192 · 168 · 1 · 100

DHCP end range
192 · 168 · 1 · 199

DHCP lease time (seconds)
86400
(120~86400)

Default domain name suffix

DNS server 1 IP address

DNS server 2 IP address

WINS server 1 IP address

WINS server 2 IP address

NTP server (option 42)

TFTP server (option 66)

DHCP option 150

DHCP option 160

Save

DYNAMIC DHCP CLIENT LIST

Computer name	MAC address	IP address	Expiry time
---------------	-------------	------------	-------------

ADDRESS RESERVATION LIST

+ Add

Computer name	MAC address	IP address	Enable
---------------	-------------	------------	--------

Table 8-4 DHCP configuration items

Option	Description
DHCP start range	Sets the first IP address of the DHCP range
DHCP end range	Sets the last IP address of the DHCP range
DHCP lease time (seconds)	The length of time in seconds that DHCP allocated IP addresses are valid
Default domain name suffix	Specifies the default domain name suffix for the DHCP clients. A domain name suffix enables users to access a local server, for example, server1, without typing the full domain name server1.domain.com
DNS server 1 IP address	Specifies the primary DNS (Domain Name System) server's IP address.
DNS server 2 IP address	Specifies the secondary DNS (Domain Name System) server's IP address.
WINS server 1 IP address	Specifies the primary WINS (Windows Internet Name Service) server IP address
WINS server 2 IP address	Specifies the secondary WINS (Windows Internet Name Service) server IP address
NTP server (Option 42)	Specifies the IP address of the NTP (Network Time Protocol) server
TFTP Server (Option 66)	Specifies the TFTP (Trivial File Transfer Protocol) server
DHCP option 150	This is used to configure Cisco IP phones. When a Cisco IP phone starts, if it is not pre-configured with the IP address and TFTP address, it sends a request to the DHCP server to obtain this information. Specify the string which will be sent as a reply to the option 150 request.
DHCP option 160	This is used to configure Polycom IP phones. When a Polycom IP phone starts, if it is not pre-configured with the IP address and TFTP address, it sends a request to the DHCP server to obtain this information. Specify the string which will be sent as a reply to the option 160 request.

Enter the desired DHCP options and select the **Save** button.

Address Reservation List

DHCP clients are dynamically assigned an IP address as they connect, but you can reserve an address for a particular device using the **ADDRESS RESERVATION LIST**.

Figure 8-19 Address reservation list

ADDRESS RESERVATION LIST			
Computer name	MAC address	IP address	Enable
+ Add			

To add a device to the address reservation list:

1. Select the **+Add** button. The Static DHCP page appears.

Figure 8-20 Address reservation list – Add Static DHCP settings

1. In the **Computer Name** field enter a name for the device.
2. In the **MAC Address** field, enter the device's MAC address.
3. In the **IP Address** fields, enter the IP address that you wish to reserve for the device.
4. Set the **Enable** toggle to **On** to enable the setting.
5. Select the **Save** button to save the settings.

To delete a port forwarding rule, select the  button on the **ADDRESS RESERVATION LIST** for the corresponding rule that you would like to delete.

Dynamic DHCP client list

The **Dynamic DHCP client list** displays a list of the DHCP clients. If you want to reserve the current IP address for future use, select the **Clone**  button and the details will be copied to the address reservation list fields.

Figure 8-21 Dynamic DHCP client list

DYNAMIC DHCP CLIENT LIST			
Computer name	MAC address	IP address	Expiry time
[blurred]	[blurred]	192.168.1.124	Tue Feb 13 08:03:47 AEDT 2024 

VLAN

A Virtual Local Area Network (VLAN) is a subnetwork used to group devices located on separate physical networks. This is useful since it allows you to partition your network without the need for additional cabling or wireless access.

Figure 8-22 VLAN

VLAN

Configuring VLAN rules may cause your device to reboot.

Device will reboot when going from zero to one or more enabled VLANs, and the reverse. The reboot will take a few minutes, during which you won't be able to access your device.

VLAN CONFIGURATION

Enable ☐ On ☒ Off

VLAN RULES

Name	Interface	Address	Subnet mask	DHCP range	DHCP	Allow admin access	Enabled

VLAN Settings

To create a VLAN:

1. Select on the **+Add** button on the VLAN Configuration page.
2. In the **Rule name** field, enter a name for the VLAN rule. This is a name that allows you to easily identify the VLAN.
3. In the **VLAN ID** field, enter a number between 0 and 4094 which will be used by the network to identify the VLAN uniquely.
4. In the **IP address** field, enter the IP address for this device on the VLAN.
5. In the **Subnet mask** field, enter the Subnet mask for the device on the VLAN.
6. To use DHCP, set the **DHCP enable** setting to the on position. In the **DHCP start range** and **DHCP end range** fields, enter the IP address range for the VLAN. Addresses within this range will be assigned automatically to devices connecting to this VLAN.
7. In the **DHCP lease time (seconds)** field, enter the number of seconds that the DHCP lease will be valid for. This value must be 120 or higher.
8. To allow access to the administration web interface, set the **Allow admin access** toggle to the on position.
9. Set the **Enable** toggle to the **ON** position.
10. Select on the **Save** button to apply the settings.

Figure 8-23 VLAN – VLAN rule configuration

VLAN

Configuring VLAN rules may cause your device to reboot.

Device will reboot when going from zero to one or more enabled VLANs, and the reverse. The reboot will take a few minutes, during which you won't be able to access your device.

VLAN SETTINGS

Rule name

VLAN ID

0~4094 (excl. 253, 254, 255)

IP address

Subnet mask

DHCP

Allow admin access

Enable

Save

Cancel

Routing settings

Static routes

Static routing is the alternative to dynamic routing used in more complex network scenarios and is used to facilitate communication between devices on different networks. Static routing involves configuring the routers in your network with all the information necessary to allow the packets to be forwarded to the correct destination. If you change the IP address of one of the devices in the static route, the route will be broken.

To access the Static routing page, select on the **Networking** menu at the top of the screen, select on the **Routing** menu on the left, then select on the **Static** menu item.

Figure 8-24 Static routing

STATIC ROUTES

STATIC ROUTING LIST

+ Add

Route name	Destination	Netmask	Gateway	Interface	Metric
------------	-------------	---------	---------	-----------	--------

ACTIVE ROUTING LIST

Destination	Gateway	Netmask	Flags	Metric	Ref	Use	Interface
0.0.0.0	10.141.177.204	0.0.0.0	UG	25	0	0	rmnet_data0
10.3.8.2	0.0.0.0	255.255.255.255	UH	10	0	0	rmnet_data0
10.3.56.162	0.0.0.0	255.255.255.255	UH	10	0	0	rmnet_data0
10.141.177.200	0.0.0.0	255.255.255.248	U	0	0	0	rmnet_data0
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0	bridge0

Adding Static Routes

To add a new route to the static routing list, select the **+Add** button. The **Static routes** page appears.

1. In the **Route name** field, type a name for the route so that it can be identified in the static routing list.
2. From the **Network interface** drop-down list, select the interface for which you would like to create a static route.
3. In the **Destination IP address** field, enter the IP address of the destination of the route.
4. In the **Destination netmask** field, enter the subnet mask of the route.
5. In the **Gateway IP address** field, enter the IP address of the gateway that will facilitate the route.
6. In the **Metric field** enter the metric for the route. The metric value is used by the router to prioritise routes. The lower the value, the higher the priority. To give the route the highest priority, set it to 0.
7. Select the **Save** button to save your settings.

Figure 8-25 Static routing – Route configuration

STATIC ROUTES

ROUTE CONFIGURATION

Route name

Destination IP address

Netmask

Gateway IP address

Network interface

auto

Metric

0-32766

Save

Cancel

Active Routing List

Static routes are displayed in the **Active routing list**.

Figure 8-26 Static routing – Active routing list

ACTIVE ROUTING LIST							
Destination	Gateway	Netmask	Flags	Metric	Ref	Use	Interface
0.0.0.0	10.141.177.204	0.0.0.0	UG	25	0	0	rmnet_data0

Static Routing List

From the static routing list, select the **Delete**  icon to the right of the entry you wish to delete.

Figure 8-27 Static routing – Static routing list

STATIC ROUTING LIST						+ Add	
Route name	Destination	Netmask	Gateway	Interface	Metric		
MyRoute	192.168.1.20	255.255.255.0	192.168.1.101	auto	0		

Firewall

The Firewall on the NTC-500 Series router implements an Intrusion Prevention Systems (IPS). The IPS works together with, but in a different manner than, system firewalls to prevent unauthorised access to your network and potentially malicious attacks. It provides a few more levels of security protection for your system from external threats.

Firewalls are rules-based and allow or exclude broad ranges of types of traffic that do not meet the criteria. IPS monitors and analyses individual inbound data packets to identify threats. Be aware that an IPS should not be considered a replacement for a well-defined firewall but should be seen as one more defensive weapon in your network security arsenal: firewalls, anti-virus software, etc.

IPS filters are interposed between the firewall and the other NTC-500 Series router functionality. It uses a variety of sophisticated techniques to monitor traffic flows and analyse inbound packets to determine whether they constitute network threats and, if so, to deny them access. The IPS firewall allows different levels of protection to be selectively applied, to thwart a threat specifically identified.

Figure 8-28 IPS router firewall

The screenshot shows the 'FIREWALL' configuration page with the 'IPS FIREWALL SETTINGS' section. The settings are as follows:

Setting	Value	Range/Unit
Enable IPS firewall	On	
Logging	On	
SYN flood defence	On	
	10	Packets/Second (10-10000)
Ping flood defence	On	
	10	Packets/Second (10-10000)
UDP flood defence	On	
	10	Packets/Second (10-10000)
IPv4 Ping Max Size (bytes)	On	
	512	Packets Size (0-65535)

A 'Save' button is located at the bottom of the settings area.


To enable the IPS, set the **Enable router firewall** toggle to **On** and then select the **Save** button.

DMZ

The Demilitarized Zone (DMZ) allows you to configure all incoming traffic on all protocols to be forwarded to a selected device behind the router. This feature can be used to avoid complex port forwarding rules, but it exposes the device to untrusted networks as there is no filtering of what traffic is allowed and what is denied. The DMZ configuration page is used to specify the IP Address of the device to use as the DMZ host.

To access the DMZ page, select on the **Networking** menu at the top of the screen, select on the **Routing** menu on the left, then select on the **DMZ** menu item.

Figure 8-29 DMZ configuration



DMZ

DMZ CONFIGURATION

Enable ☒ On ☐ Off

WWAN profile no. 1-6

DMZ IP address

Enabling the DMZ

1. Select the **DMZ** toggle key to turn the DMZ function **ON**.
2. Enter the IP Address of the device to be the DMZ host into the **DMZ IP Address** field.
3. Enter the WWAN profile number that you wish to associate the DMZ configuration with.
4. Select the **Save** button to save your settings.

Port forwarding

The Port forwarding list is used to configure the Network Address Translation (NAT) rules currently in effect on the NTC-500 Series router. To access the Port forwarding page, select on the **Networking** menu at the top of the screen, select on the **Firewall** menu on the left.

Figure 8-30 NAT

Name	Profile no.	Protocol	Public port	Local IP address	Local port	Enable
+ Add						

The purpose of the port forwarding feature is to allow mapping of inbound requests to a specific port on the WAN IP address to any connected device.



Note: Some carriers block inbound connections or require a public IP address in order to get inbound requests.

Adding a port forwarding rule

To create a new port forwarding rule:

1. From the **Port forwarding list**, select on the **+Add** button. The port forwarding settings screen is displayed.

Figure 8-31 IPv4 Port Forwarding Settings

PORT FORWARDING

PORT FORWARDING SETTINGS

Rule name: DemoRule

Profile no.: 1 (range 1-6)

Protocol: TCP

Public port: 443 (range 1-65535)

Local IP address: 192.168.1.5

Local port: 10000 (range 1-65535)

Enable: On

Save Cancel

1. In the **Rule name** field, enter a name for the rule so that it can be easily identified.
2. In the **Profile no.** field, enter a number that corresponds to the Wireless WAN Profile that you want to use for the rule.
3. Use the **Protocol** drop-down list to select the type of protocol you want to use for the rule. The protocols selections available are **TCP**, **UDP** and **TCP/UDP**.

4. In the **Public port** field, enter a number between 1 and 65535 to use for the communication port from the NTC-500 Series router out to the mobile network.
5. In the **Local IP Address** field, enter the IP address of LAN equipment to which traffic should be routed or a wildcard IP address (0.0.0.0) that allows all IP addresses to access the traffic.
6. In the **Local port** field, enter a port number to use for traffic to the local device. This may be an integer between 1 and 65535.
7. Ensure that the **Enable** toggle button is set to the **ON** position.
8. Select the **Save** button to confirm your settings.

To delete a port forwarding rule, select the  button on the **Port forwarding list** for the corresponding rule that you would like to delete. To edit an existing rule, select on the  button.

Filtering

The MAC whitelist feature allows you to restrict devices that are allowed to connect to the NTC-500 Series router by their MAC address.

Figure 8-32 Filtering

FILTERING

MAC FILTERING

Enable
☒ On
☐ Off

MAC WHITELIST

+ Add

Name	MAC address	Enable		
DemoDevice	3e:00:00:00:00:00	1		

MAC / IP / PORT FILTERING

Enable
☐ On
☒ Off

Default rule (inbound/forward)
Accepted

MAC / IP / PORT FILTERING RULES IN EFFECT

+ Add

Index	Protocol	Action	Comment		
0	ALL	Drop	DemoRule		

Save

To enable MAC filtering, set the **Enable** toggle to **On**, then press **Save**.

MAC whitelist

To add or remove a device from the MAC whitelist:

1. To add a device to the whitelist first press the **+Add** button. The **MAC whitelist settings** page appears.
2. In the **Name** field, enter a name to identify the device.
3. In the **MAC address** field, enter the MAC address of the device.
4. Set the Enable toggle to **On**.
5. Select the **Save** button.
6. The device appears in the **MAC Whitelist** section.

Figure 8-33 MAC - MAC filtering whitelist settings

To remove the device, select the  button to the right of the entry. To edit the device, including to temporarily disable it, select the  button.

MAC / IP / Port filtering

The MAC/IP/Port filter feature allows you to apply a policy to the traffic that passes through the router, both inbound and outbound, so that network access can be controlled. When the filter is enabled with a default rule of “Accepted”, all connections will be allowed except those listed in the “Current MAC / IP / Port filtering rules in effect” list. Conversely, when the default rule is set to “Dropped”, all connections are denied except for those listed in the filtering rules list.

Figure 8-34 Firewall Filtering

Index	Protocol	Action	Comment
0	ALL	Drop	DemoRule



Important: When enabling MAC / IP / Port filtering and setting the default rule to “Dropped”, you should ensure that you have first added a filtering rule which allows at least one known MAC/IP to access the router, otherwise you will not be able to access the user interface of the router without resetting the router to factory default settings.

Creating a MAC / IP / Port filtering rule

To create a filtering rule:

1. Select the **MAC / IP / Port** filtering toggle key to switch it to the ON position.
2. Using the **Default rule (inbound/forward)** drop-down list, select the default action for the router to take when traffic reaches it. By default, this is configured to Accepted. If you change this to Dropped, you should first configure a filter rule that allows at least one device access to the router, otherwise you will effectively be locked out of the router.
3. Select the **Save** button to confirm the default rule.
4. In the Current MAC / IP / Port filtering rules in the effect section, select the **+Add** button.
5. Enter the details of the rule in the section that is displayed and select the **Save** button.
6. The new rule is displayed in the filtering rules list. You can edit the rule by selecting the  Edit button or delete the rule by selecting the  button.

Redundancy (VRRP)

Virtual Router Redundancy Protocol (VRRP) is a non-proprietary redundancy protocol designed to increase the availability of the default gateway servicing hosts on the same subnet. This increased reliability is achieved by advertising a “virtual router” (an abstract representation of master and backup routers acting as a group) as a default gateway to the host(s) instead of one physical router. Two or more physical routers are then configured to stand for the virtual router, with only one doing the actual routing at any given time. If the current physical router that is routing the data on behalf of the virtual router fails, an arrangement is made for another physical router to automatically replace it. The physical router that is currently forwarding data on behalf of the virtual router is called the master router. Routers are given a priority of between 1 and 255 and the router with the highest priority is assigned as the master.

A virtual router must use 00-00-5E-00-01-XX as its (MAC) address. The last byte of the address (XX) is the Virtual Router Identifier (VRID), which is different for each virtual router in the network. This address is used by only one physical router at a time and is the only way that other physical routers can identify the master router within a virtual router.

Figure 8-35 Redundancy

REDUNDANCY (VRRP)

REDUNDANCY (VRRP) CONFIGURATION

Redundancy (VRRP) ☒ On ☐ Off

Virtual ID (1-255)

Router priority (1-255)

Virtual IP address . . .

VRRP WAN WATCHDOG

VRRP WAN watchdog ☐ On ☒ Off

Configuring VRRP

To configure VRRP, configure multiple devices as follows and connect them together via an Ethernet network switch to downstream devices.

1. Set the **Redundancy (VRRP)** toggle to **On** to enable VRRP.
2. In the **Virtual ID** field, enter an ID between 1 and 255. This is the VRRP ID which is different for each virtual router on the network.
3. In the **Router priority** field, enter a value for the priority – a higher value is a higher priority.
4. The **Virtual IP address** field is used to specify the VRRP IP address – this is the virtual IP address that both virtual routers share.
5. Select the Save button to apply the new settings.

Note: *Configuring VRRP changes the MAC address of the Ethernet port which may interrupt the connection to the router. If you want to resume with the web configuration you must use the new IP address (VRRP IP) or clear the arp cache (old MAC address). On Windows, run the following command in command prompt:*



```
arp -d <ip address> (i.e. arp -d 192.168.1.1)
```

Configuring the VRRP WAN watchdog

By default, VRRP WAN watchdog is disabled. When it is disabled, VRRP monitors the status of the primary and secondary by the physical link. When enabled, the VRRP WAN watchdog feature monitors the status of the connection by both the physical link and controlled ping packets.

Figure 8-36 Redundancy – VRRP WAN Watchdog

VRRP WAN WATCHDOG

VRRP WAN watchdog ☒ On ☐ Off

Verbose logging ☐ On ☒ Off

First destination address

Second destination address

Periodic Ping timer (3-65535) secs

Retry timer (2-65535) secs

CONSECUTIVE ERROR MONITOR

Consecutive error monitor ☒ On ☐ Off

Failover fail count (3-65535) times

Failback success count (3-65535) times

PERIODIC RATIO MONITOR

Periodic ratio monitor ☒ On ☐ Off

Monitor total count (3-65535) times

Failover fail count (3-65535) times

Failback success count (3-65535) times

The following table details each field on the VRRP WAN Watchdog page.

Table 8-5 VRVP WAN Watchdog configuration items

Parameter	Description
VRRP WAN Watchdog	Set the VRRP WAN Watchdog to On to enable the watchdog.
Verbose logging	When enabled verbose comments are logged in the system log related to the failover monitoring.

Parameter	Description
First destination address	The first address the router that the router should ping in order to confirm the connection is up. This may be an IP address or a domain name.
Second destination address	The second address the router that the router should ping in order to confirm the connection is up. This may be an IP address or a domain name.
Periodic Ping timer	The time in seconds between ping attempts.
Retry timer	The time in seconds between attempts when a ping failure occurs.
Consecutive error monitor	
Consecutive Error Monitor	Set the Consecutive Error Monitor toggle to On to enable the consecutive error monitor. Using this method, the router will determine the availability of an interface based on a set number of consecutive ping instance responses.
Failover fail count	The number of failed pings that must occur before the monitor fails the connection over to the next interface.
Failback success count	The number of successful pings that must occur before the monitor fails the connection back to the higher priority interface.
Periodic ratio monitor	
Periodic ratio monitor	Set the Periodic ratio monitor toggle to On to enable the Periodic ratio monitor. Using this method, the router will determine the availability of an interface based on a set ratio of ping instance successes or failures to the number of attempts.
Monitor total count	This field specifies a Series of pings to consider when calculating whether to fail over or fail back. When the Series is completed, the router repeats the ping test and resets the Failover fail count/Failback success count, therefore, in order for the failover or failback ratio to be met, the number of Failover fail counts/Failback success counts must occur within a particular Series.
Failover fail count	This field specifies the number of failed ping results that must occur within a Series of pings configured in the Monitor total count before the router fails over to the next highest priority interface. For example, at the default setting of 5, the router fails over to the next interface when 5 out of 10 ping attempts in a particular Series have failed. The failures need not be consecutive to meet the failover criteria. If any 5 of the 10 pings in a Series have failed, the router deems the interface connection to be down and fails over.
Failback success count	Like the Failover fail count field, this field specifies the number of ping successes that must be registered on a higher priority interface within a Series of pings configured in the Monitor total count before the router fails back to that interface.

RIP

RIP (Routing Information Protocol) is used for advertising routes to other routers. By enabling RIP all the routes in the router's routing table will be advertised to other nearby routers. For example, the route for the router's Ethernet subnet could be advertised to a router on the PPP interface side so that a router on this network will know how to route to a device on the router's Ethernet subnet. Static routes must be added manually according to your requirements. See Adding Static Routes for more information.

Figure 8-37 RIP configuration

 **Note:** Other routers may ignore RIP.

To enable Routing Information Protocol (RIP)


1. Set the **RIP** toggle to **On** to enable RIP.
2. Using the **Version** drop-down list, select the version of RIP that you would like to use.
3. Select the **Interface** that RIP should apply on. Options are **LAN**, **WWAN** or **Both**.
4. If you wish to turn on authentication, toggle the **Authentication** toggle key to the **ON** position, use the Authentication type drop-down list to select the method of authentication then enter password in the Password field.
5. Select the **Save** button to confirm your settings.

VPN

IPSec

IPSec operates on Layer 3 of the OSI model and as such can protect higher layered protocols. IPSec is used for both site to site VPN and Remote Access VPN. The NTC-500 Series router supports IPsec end points and can be configured with Site to Site VPN tunnels for third party VPN routers.

Figure 8-38 VPN – IPSec



IPSEC					
IPSEC TUNNEL LIST					
#	Name	Remote LAN address/mask	Remote gateway	Local LAN address/mask	Enable

Configuring an IPSec VPN

From the menu at the top of the screen, click **Networking** and under the VPN section, click **IPSec**. A list of configured IPSec VPN connections is displayed. Click the **+Add** button to begin configuring an IPSec VPN connection.

Figure 8-39 VPN – IPsec Profile Edit

IPSEC

IPSEC PROFILE EDIT

IPSec profile ☐ On ☐ Off

Profile name

PHASE 1 PARAMETERS

Remote IPSec address

Key mode

Pre-shared key

Remote ID (xy.sample.com or blank)

Local ID (xy.sample.com or blank)

IKE version

IKE mode

IKE encryption

IKE hash

DH group

IKE re-key time (0-78400, 0=Unlimited) secs

DPD action

DPD keep alive time secs

DPD timeout secs

SA life time (0-78400, 0=Unlimited) secs

PHASE 2 PARAMETERS

Remote LAN address

Remote LAN subnet mask

Local LAN address

Local LAN subnet mask

Encapsulation type

IPSec encryption

IPSec hash

The following table describes each of the fields of the IPsec VPN configuration page.

Table 8-6 IPsec configuration items

Parameter	Description
IPsec profile	Enables or disables the VPN profile.
Profile name	A name used to identify the VPN connection profile.
Phase 1 parameters	
Remote IPsec address	The IP address or domain name of the IPsec server.
Key mode	Select the type of key mode in use for the VPN connection. You can select from: Pre Shared Key RSA keys Certificates SCEP client
Pre-shared key	The pre-shared key is the key that peers used to authenticate each other for Internet Key Exchange. The pre-shared key must meet the requirements for a strong password. See the Configuring a strong password section. This field appears if using Pre-shared key as the key mode.
Remote ID	Remote ID of the connection. Refer to the documentation of the remote IPsec server for further details. This field may be left blank.
Local ID	Local ID of the connection. Refer to the documentation of the remote IPsec server for further details. This field may be left blank.
Local RSA key upload	Upload the Local RSA key if using RSA Keys as the Key mode.
Remote RSA key upload	Upload the Remote RSA key if using RSA Keys as the Key mode
Private key passphrase	The Private key passphrase is required if using Certificates as the Key mode.
Key / Certificate	Select the Key / Certificate type for the IPsec connection if using Certificates as the Key mode.
IPsec certificate upload	Upload the IPsec certificate if using Certificates as the Key mode.
SCEP remote id	Enter the SCEP remote ID if using SCEP client as the Key mode.
IKE version	Set the IKE version for the connection. There are two options available IKE V1 and IKE V2 .
IKE mode	Set the IKE mode for the connection. There are three options Any , Main and Aggressive .
IKE encryption	Select the cipher type to use for the Internet Key Exchange.

Parameter	Description
IKE hash	Select the IKE Hash type to use for the VPN connection. The hash is used for authentication of packets for the key exchange.
DH group	Select the desired Diffie-Hellman group to use. Higher groups are more secure but also require longer to generate a key.
IKE re-key time	Enter the time in seconds between changes of the encryption key. To disable changing the key, set this to 0.
DPD action	Select the desired Dead Peer Detection action. This is the action to take when a dead Internet Key Exchange Peer is detected.
DPD keep alive time	Enter the time in seconds for the interval between Dead Peer Detection keep alive messages.
DPD timeout	Enter the time in seconds of no response from a peer before Dead Peer Detection times out.
SA life time	Enter the time in seconds for the security association lifetime.
Phase 2 parameters	
Remote LAN address	Enter the IP address of the remote network for use on the VPN connection.
Remote LAN subnet mask	Enter the subnet mask in use on the remote network.
Local LAN address	Enter the IP address of the local network for use on the VPN connection.
Local LAN subnet mask	Enter the subnet mask in use on the local network.
Encapsulation type	Select the encapsulation protocol to use with the VPN connection. You can choose ESP, AH or Any.
IPSec encryption	Select the IPSec encryption type to use with the VPN connection.
IPSec hash	Select the IPSec hash type to use for the VPN connection. The hash is used for authentication of packets for the VPN connection.

OpenVPN

OpenVPN is an open-source virtual private network (VPN) program for creating point-to-point or server-to-multi-client encrypted tunnels between host computers. It can traverse network address translation (NAT) and firewalls and allows authentication by certificate, pre-shared key or username and password. OpenVPN works well through proxy servers and can run over TCP and UDP transports. Support for OpenVPN is available on most operating systems, including Windows, Linux, macOS, Solaris, OpenBSD, FreeBSD, NetBSD and QNX.

From the menu at the top of the screen, select Networking, then from the VPN section on the left, select OpenVPN. A list of configured OpenVPN VPN connections is displayed.

Figure 8-40 VPN - OpenVPN

The screenshot shows the OpenVPN configuration interface. It has a header 'OPENVPN' and three main sections, each with a table and an 'Add' button:

- OPENVPN SERVER LIST**: Table with columns: Profile Name, VPN Network Address, Authentication type, Username, Status, Edit.
- OPENVPN CLIENT LIST**: Table with columns: Profile Name, Server IP address, Authentication type, Username, Status, Edit.
- OPENVPN P2P LIST**: Table with columns: Profile Name, Server IP address, Local IP Address, Remote IP Address, Remote Subnet Mask, Status, Edit.

Configuring an OpenVPN Server

To add an OpenVPN server, select the **Add** button to the right of the OpenVPN Server List heading. Each time the **Add** button is selected, the router checks if there are existing server certificates. If no server certificate is found, you are informed that you must generate a certificate before configuring the OpenVPN server.

Figure 8-41 VPN – OpenVPN – Generate server certificate prompt

The dialog box contains the following text: "You must generate a certificate before configuring an OpenVPN server. Select OK to proceed to the OpenVPN server certificate configuration page." Below the text are two buttons: "OK" and "Cancel".

Select the **OK** button to be taken to the **Server Certificate** page. For more information on generating server certificates, refer to the [Server Certificate](#) section of this guide. When you have created the certificate, return to the OpenVPN server configuration page to continue the setup.

To configure an OpenVPN server:

1. Select the **OpenVPN profile** toggle key to switch it to the **ON** position.
2. Type a name for the OpenVPN server profile you are creating.
3. In the **Type** drop-down list, select the **OpenVPN connection type (TUN/TAP)**. Default is **TUN**.
4. Use the **Port type** field and **Server port** field to select a port number and use the drop-down list to select a packet type to use for your OpenVPN Server. The default OpenVPN port is 1194 and default packet type is UDP.
5. Use the **Encryption cipher** field to select the encryption type for the connection. The default is **AES-256** as this is the strongest encryption level.
6. Enter a maximum transmission unit value into the **MTU** field. The default is 1500.
7. In the **VPN network address** and **VPN network subnet mask** fields, enter the IP address and network subnet mask to assign to your VPN. This is ideally an internal IP address which differs from your existing address scheme.
8. The Server certificates section displays the details of the certificate. If you wish to change the certificate, select the **Change** button.
9. HMAC or Hash-based Message Authentication Code is a means of calculating a message authentication code using a cryptographic hash function and a cryptographic key. If you wish to use the HMAC signature as an additional key and level of security, under the SSL/TLS handshake section, click the **Use HMAC Signature** toggle key so that it is in the **ON** position, then select the **Generate** button so that the router can randomly generate the key. The **Server key timestamp** field is updated with the time that the key was generated. Select the **Download** button to download the key file so that it can be uploaded on the client.
10. Select an **Authentication type**. Authentication may be done using a Certificate or Username / Password. See the below sections for information on each of the certificate types.

Certificate authentication

In the Certificate Management section, enter the required details to create a client certificate. All fields are required. After filling out the required fields, select the Generate button.

Figure 8-42 VPN – OpenVPN – Certificate Authentication type

The screenshot shows a web form titled "AUTHENTICATION TYPE". It contains the following elements:

- Authentication type:** A dropdown menu with "Certificate" selected.
- Certificate:** A dropdown menu with "New..." selected.
- Name:** A text input field.
- Country:** A text input field.
- State:** A text input field.
- City:** A text input field.
- Organisation:** A text input field.
- Email:** A text input field.
- Buttons:** A grid of buttons at the bottom: "Generate" (blue), "Revoke" (grey), "Download P12" (grey), "Download TGZ" (grey), "Save" (blue), and "Cancel" (blue).

Once the certificate is generated, select the **Download P12 button** or the **Download TGZ button** to save the certificate file, depending on which format you would like. If for some reason the integrity of your network has been compromised, return to this screen, use the Certificate drop-down list to select the certificate and then select the Revoke button to make the certificate invalid.

Optional: To inform the OpenVPN server of the network address scheme of the currently selected certificate, enter the network address and network subnet mask in the respective fields and click the Set network information button. If you do not enter the remote subnet here, any packet requests from the server to the client will not be received by the client network because it is not aware of the remote client's subnet.

Username / Password Authentication

In the Username/Password section, enter the username and password you would like to use for authentication on the OpenVPN Server. Select the Download CA certificate or Download CA TGZ depending on file format button to save the ca.crt file. This file will need to be provided to the client.



Note: If you wish to have more than one client connect to this OpenVPN server, you must use Certificate authentication mode as Username/Password only allows for a single client connection.

Figure 8-43 VPN – OpenVPN – Username / Password Authentication type

AUTHENTICATION TYPE

Authentication type Username / Password

Username

Password

[Download CA TGZ](#)

[Download CA certificate](#)

Remote network address

Remote network subnetmask

[Set network information](#)

[Save](#) [Cancel](#)

Optional: To inform the OpenVPN server of the network address scheme of the currently selected certificate, enter the network address and network subnet mask in the respective fields and click the Set Network Information button. If you do not enter the remote subnet here, any packet requests from the server to the client will not be received by the client network because it is not aware of the remote client's subnet.

When you have finished entering all the required information, select Save to finish configuring the OpenVPN server.

Configuring an OpenVPN client

1. From the OpenVPN page select the **Add** button to the right of **OpenVPN Client List**. The OpenVPN Client Edit page is shown.

Figure 8-44 VPN – OpenVPN – Configure OpenVPN client


2. Set the **OpenVPN profile** toggle key to the **On** position.
3. In the Profile name field, enter a name for the OpenVPN client profile you are creating.
4. In the Server IP address field, enter the WAN IP address / host domain name of the OpenVPN server.
5. Select OpenVPN connection type (TUN/TAP). Default is TUN.
6. Use the Server port field to select a port number and then use the drop-down list to select a packet type to use for the OpenVPN server. The default OpenVPN port is 1194 and default packet type is UDP.
7. If the Default gateway option is applied on the OpenVPN client page, the OpenVPN server will enable connections to be made to other client networks connected to it. If it is not selected, the OpenVPN connection allows for secure communication links between this router and the remote OpenVPN server only.
8. Use the Authentication type options to select the Authentication type that you would like to use for the OpenVPN client. The available options are **Certificate**, **Username and Password**, or **Combination Certificate and Username / Password**. See the below sections to understand the different authentication types.

Certificate Authentication

To use Certificate Authentication, a certificate must be uploaded.

1. Set the Authentication Type field to Certificate.
2. Scroll down to the Select certificate to upload field and select the Choose a file button.

Figure 8-45 OpenVPN – Certificate upload




The screenshot shows a configuration section for certificate upload. It includes a label "Select certificate to upload", a blue button labeled "Choose a file", and a status indicator "Not uploaded". Below these is a grey button labeled "Upload".

3. Locate the certificate on your computer, select **Open**, then select **Upload**.
4. Once the certificate is uploaded, select the **Save** button to confirm the connection.

Username / Password Authentication

To use Username / Password Authentication, the credentials for the OpenVPN VPN server are required.

Figure 8-46 OpenVPN – Username / Password Authentication



The screenshot shows the "USERNAME / PASSWORD" section with input fields for "Username" and "Password". Below this is the "CA UPLOAD" section, which includes a label "Select certificate to upload", a blue button labeled "Choose a file", a status indicator "Not uploaded", and a grey button labeled "Upload".

1. Set the Authentication Type field to Username / Password.
2. In the Username field, enter the username of the OpenVPN server.
3. In the Password field, enter the password of the OpenVPN server.
4. Use the Choose a file button to locate the CA certificate file you saved from the OpenVPN Server and then select the Upload button.
5. If you have an additional SSL/TLS key created on the server, click on the Use HMAC Signature toggle key so that it is in the ON position. Select the Choose a file button then locate the key file on your computer. Select the Upload button to upload it to the router.
6. Select the Save button to confirm the connection.

Certificate and Username / Password authentication

The Certificate and Username / Password Authentication options is a combination of both the Certificate and Username / Password authentication methods. This provides additional levels of security since the client must know the username / password combination and be in possession of the certificate. Set the authentication type to **Certificate and Username / Password Authentication**, then follow both of the above sections to complete the configuration.

Configuring an OpenVPN P2P Connection

The OpenVPN P2P connection allows you to create a Peer-to-Peer VPN connection with another router. One router should be the primary router, and the other router should be a secondary router.

1. From the OpenVPN page select the Add button to the right of OpenVPN P2P List. The OpenVPN Peer Edit page is shown.

Figure 8-47 OpenVPN – P2P Peer Edit Page

The screenshot shows the 'OPENVPN PEER EDIT' configuration page. It includes a toggle for 'OpenVPN profile' (set to 'On'), a 'Profile name' text field, a 'Server IP address' text field with a note 'leave empty if peer-to-peer server', a 'Port type' dropdown (set to 'TCP'), a 'Server port' text field (set to '1194') with a range '1-65535', an 'Encryption cipher' dropdown (set to 'AES-256'), an 'MTU' text field (set to '1500') with a range '(576-1600)', 'Local IP address' and 'Remote IP address' four-part text boxes, a 'REMOTE NETWORK' section with 'Remote Network LAN address' and 'Remote Network LAN mask' four-part text boxes, a 'SERVER SECRET KEY' section with an 'Update time' label, 'Generate', and 'Download' buttons, a 'CLIENT SECRET KEY' section with an 'Update time' label, a 'Delete' button, a 'Client secret key upload' section with a 'Choose a file' button and 'Not uploaded' text, and 'Save' and 'Cancel' buttons at the bottom.

2. Set the **OpenVPN profile** toggle key to switch it to the **ON** position.
3. In the **Profile** name field, type a name for the OpenVPN P2P profile you are creating.
4. On the router designated as the server, leave the **Server IP address** field empty. On the router designated as the client, enter the WAN IP address/host domain name of the server.
5. Use the **Port type** and **Server port** fields to select a port number and then use the drop-down list to select a packet type to use for the OpenVPN server. The default OpenVPN port is 1194 and default packet type is UDP.
6. In the **Local IP Address** and **Remote IP Address** fields, enter the respective local and remote IP addresses to use for the OpenVPN tunnel. The secondary router should have the reverse settings of the primary router.

7. Under the **Remote network** section, In the **Local IP Address** and **Remote IP Address** fields, enter the respective local and remote IP addresses to use for the OpenVPN tunnel. The secondary router should have the reverse settings of the primary router.
8. Press the **Generate** button to create a secret key to be shared with the other router. When the timestamp appears, you can click the **Download** button to save the file to exchange with the other router.
9. When you have saved the secret key file on each router, use the **Choose a file** button to locate the secret key file for the master and then select the Upload button to send it to the secondary router. Perform the same for the other router, uploading the secondary secret key file to the primary router.
10. Select the **Save** button to confirm the peer-to-peer VPN connection.

GRE Tunnelling

The Generic Route Encapsulation (GRE) protocol creates a point-to-point connection similar to a VPN between clients and servers or between clients only. GRE is used to encapsulate the data or payload.

Figure 8-48 VPN – GRE Tunnelling

Name	GRE server address	Local tunnel address	Remote tunnel address	Status
DemoClient	10.10.10.100	10.20.30.40	20.30.30.1	disabled

Configuring GRE tunnelling

To configure GRE tunnelling:

1. To the right of the GRE client list, select the **Add** button. The **GRE client edit** screen is displayed.

Figure 8-49 VPN – GRE Tunnelling – GRE Client Edit

2. Set the **Enable VPN** toggle to **On**.
3. In the **Profile name** field, enter a profile name for the tunnel. This name is used to identify the tunnel on the router.
4. In the **GRE server address** field, enter the IP address or domain name of the GRE server.
5. In the **Local tunnel address** field, enter the IP address you want to assign the tunnel locally.
6. In the **Remote tunnel address** field, enter the IP address you want to assign to the remote tunnel.
7. In the **Remote network address** field, enter the IP address scheme of the remote network.
8. In the **Remote network subnetmask** field, enter the subnet mask of the remote network.
9. The **TTL** (Time To Live) field is an 8-bit field used to remove an undeliverable data packet from a network to avoid unnecessary network traffic across the internet. The default value of 255 is the upper limit on the time that an IP datagram can exist. The value is reduced by at least one for each hop the data packet takes to the next router on the route to the datagram's destination. If the TTL field reaches zero before the datagram arrives at its destination the data packet is discarded and an error message is sent back to the sender.
10. The **Reconnect delay** is the time in seconds that the router will wait before attempting to connect to the GRE server if the connection is broken. The minimum time to wait is 30 seconds so as to not flood the GRE server with connection requests, while the maximum time to wait is 65335 seconds.
11. The **Reconnect retries** is the number of connection attempts that the router will make if the GRE connection goes down. If set to 0, the router will retry the connection indefinitely, otherwise the maximum number of times to retry cannot be greater than 65335.
12. Select the **Save** button to save the changes. The VPN will attempt to connect after your click Save. Select the Status button at the top left of the interface to return to the status window and monitor the VPN's connection state.


Server Certificate

The **Server Certificate** page is used to generate a certificate for use with OpenVPN.

Generating Diffie-Helman files


On first use of the certificate page, you will see the following prompt, where **dh** refers to **Diffie-Hellman**.

Figure 8-50 VPN – Server Certificate – Missing dh related files




To proceed with generating the certificate, the Diffie-Hellman parameters must first be generated. Select **OK** on the prompt to close it. The OpenVPN Server Certificate page is shown.


Figure 8-51 VPN – Server Certificate – Missing dh related files

A screenshot of the 'OPENVPN SERVER CERTIFICATE' web page. The page has a gray header with 'OPENVPN' in white. Below the header, the title 'OPENVPN SERVER CERTIFICATE' is in blue. The form contains several sections: 'Server key size' with a dropdown menu showing '2048'; 'Diffie-Hellman parameters' with a blue 'Generate' button; 'Certificate serial number' with a text input field; 'Not before' and 'Not after' with text input fields; 'Country', 'State', 'City', 'Organization', and 'Email' each with a text input field; and 'Generate server certificate' with a blue 'Generate' button.

To the left of **Diffie-Hellman Parameters**, select **Generate**. The following prompt is shown.

Figure 8-52 VPN – Server Certificate – Missing dh related files

Selecting the **OK** button will delete and invalidate all previous server and client keys, if they exist, and generates new parameters. This process will take up to five minutes to complete. Once the files are generated, the Success prompt is shown.

Figure 8-53 VPN – Server Certificate – Missing dh related files

The Server Certificate can now be generated.

Generating the OpenVPN Server Certificate

To generate an OpenVPN Server Certificate:

1. In the **Country** field, enter the SSL Country code for the country the certificate is issued for.
2. In the **State** field, enter the state the certificate is issued for.
3. In the **City** field, enter the city the certificate is issued for.
4. In the **Organization** field, enter the name of the organization for the certificate.
5. In the **Email** field, enter a contact email for the certificate.
6. To the right of **Generate Server Certificate** select **Generate** to generate the certificate. A success prompt is shown, and the certificate serial number and validity dates are shown in **Certificate serial number**, **Not before** and **Not after fields**.

Figure 8-54 VPN – Server Certificate – Generate certificate

OPENVPN

OPENVPN SERVER CERTIFICATE

Server key size

2048

▼

Diffie-Hellman parameters

Generate

Certificate serial number

72A7D54CE506F92C80D96F3311F34FA1

Not before

Feb 15 01:01:23 2024 GMT

Not after

Feb 12 01:01:23 2034 GMT

Country

AU

State

NSW

City

Sydney

Organization

NetComm Wireless

Email

example@casa-systems.com

Generate server certificate

Generate

9. Services

Network time (NTP)

The NTP (Network Time Protocol) settings page allows you to configure the NTC-500 Series router to synchronize its internal clock with a global Internet Time server and specify the time zone for the location of the router. This provides an accurate timekeeping function for features such as System Log entries and Firewall settings where the current system time is displayed and recorded. Any NTP server available publicly on the internet may be used.

To access the Network time (NTP) page, select on the **Services** menu at the top of the screen then select on the **Network time (NTP)** menu item on the left.

Figure 9-1 NTP

Configuring Timezone settings

To configure time zone settings:

1. The Current time field shows the time and date configured on the router. If this is not accurate, use the Timezone drop-down list to select the correct time zone for the router. If the selected zone observes daylight savings time, a Daylight savings time schedule link appears below the drop-down list. Select the link to see the start and end times for daylight savings.
2. When you have selected the correct time zone, select the **Save** button to save the settings.

Configuring NTP settings

To configure NTP settings:


1. Select the **Network time (NTP)** toggle key to switch it to the **ON** position.
2. In the **NTP service field**, enter the address of the NTP server you wish to use.
3. The **Synchronization on WWAN** connection toggle key enables or disables the router from performing a synchronization of the time each time a mobile broadband connection is established.

4. The **Daily synchronisation** toggle key enables or disables the router from performing a synchronization of the time each day.
5. When you have finished configuring NTP settings, select the **Save** button to save the settings.

SNMP

The Simple Network Management Protocol (SNMP) allows a network administrator to monitor a network by retrieving settings on remote network devices. To do this, the administrator typically runs an SNMP management station program such as MIB browser on a local host to obtain information from the SNMP agent, in this case the NTC-500 Series router (if SNMP is enabled). An SNMP 'community' performs the function of authenticating SNMP traffic. A 'community name' acts as a password that is typically shared among SNMP agents and managers.

Figure 9-2 SNMP Configuration



The image shows a web-based configuration interface for SNMP. It is divided into two main sections: 'SNMP CONFIGURATION' and 'SNMP TRAPS'. The 'SNMP CONFIGURATION' section includes a toggle for 'SNMP' (set to 'On'), a text field for 'SNMP Port' (set to '161'), a dropdown for 'Version' (set to 'v1v2c'), text fields for 'Read-only community name' (set to 'public') and 'Read-write community name' (set to 'private'), a 'Download MIB' button, and a 'Save' button at the bottom. The 'SNMP TRAPS' section includes a toggle for 'SNMP TRAPS' (set to 'On'), a text field for 'Trap destination', and three text fields for 'Heartbeat interval' (43200), 'Trap persistence time' (500), and 'Trap retransmission time' (21600), all with 'seconds' units. It also features a 'Send heartbeat' button and a 'Save' button at the bottom.

Configuring SNMP

To configure SNMP:

1. Set the **SNMP** toggle to **On** to enable SNMP.
2. In the **SNMP Port** field, enter the SNMP port to be used.
3. Use the **Version** dropdown to set the SNMP version to be used. Available options are **v1v2c** and **v3**.
4. In the **Read-only community name** enter the read community name of the network.
5. In the **Read-write community name** enter the write community name of the network.
6. Select the **Save** button below the **SNMP Traps** section to apply the configuration.

Configuring SNMP traps

The NTC-500 Series router can be configured to send SNMP traps to a central SNMP Network Management System (NMS) when certain events occur. To configure the SNMP traps:

1. Set the **SNMP Traps** toggle to **On**.
2. In the **Trap Destination** field, enter the address of the SNMP NMS.
3. In the **Heartbeat interval** field, enter the interval in seconds which the NTC-500 Series router should send a heartbeat.
4. In the **Trap persistence time** field, enter the interval in seconds that the NTC-500 Series router should attempt to send a specific trap after the initial occurrence that triggered the trap.
5. In the **Trap retransmission time** field, enter the interval in seconds that the NTC-500 Series router should wait before retransmitting the trap.
6. Use the **Send heartbeat** button to send a test heartbeat.
7. Select the **Save** button to apply the changes.

TR-069

To access the TR-069 configuration page, select the **Services** menu item, then select the **TR-069** menu item on the left.

Figure 9-3 TR069 configuration

TR-069

TR-069 CONFIGURATION

Enable TR-069 On Off

ACS URL

ACS username

ACS password 

Verify ACS password 

Connection request username

Connection request password 

Verify connection request password 

Connection request port 1-65535

Management wwan profile no. Default route 

Enable periodic ACS informs On Off

Inform period (30-2592000) secs

Randomise initial inform On Off

LAST INFORM STATUS

Start at

End at

TR-069 DEVICEINFO

Manufacturer NetComm Wireless

Manufacturer OUI 08:00:5E:00:00:00

Model name NTC-500

Description NTC-500 Series NTC-500

Product class NTC-500

Serial number 000000000000

Save

The TR-069 (Technical Report 069) protocol is a technical specification also known as CPE WAN Management Protocol (CWMP). It is a framework for remote management and auto-configuration of end-user devices such as customer-premises equipment (CPE) and Auto Configuration Servers (ACS). It is particularly efficient in applying configuration updates across networks to multiple CPEs.

TR-069 uses a bi-directional SOAP/HTTP-based protocol based on the application layer protocol and provides several benefits for the maintenance of a field of CPEs:

- Simplifies the initial configuration of a device during installation
- Enables easy restoration of service after a factory reset or replacement of a faulty device
- Firmware and software version management
- Diagnostics and monitoring

Note: You must have your own compatible ACS infrastructure to use TR-069. To access and configure the TR-069 settings, you must be logged into the router with the root account.



When a factory reset of the router is performed via TR-069, the TR-069 settings are preserved.

The NTC-500 Series router sends “inform” messages periodically to alert the ACS server that it is ready. These inform messages can also be configured to accept a connection request from the ACS server. When a connection is established, any tasks queued on the ACS server are executed. These tasks may be value retrieval or changes and firmware upgrades.

TR-069 configuration

To configure TR-069:

1. Select the **Enable TR-069** toggle key to switch it to the **ON** position.
2. In the **ACS URL** field, enter the Auto Configuration Server’s full domain name or IP address.
3. Use the **ACS username** field to specify the username used by the server to authenticate the CPE when it sends an “inform” message.
4. In the **ACS password** and **Verify ACS password** fields, enter the password used by the server to authenticate the CPE when it sends an “inform” message.
5. In the **Connection request** username field, enter the username that the CPE uses to authenticate the Auto Configuration Server during a connection request to the CPE.
6. In the **Connection request password** and **Verify password** fields, enter the password that the CPE uses to authenticate the Auto Configuration Server during a connection request to the CPE.
7. In the **Connection request port** field, enter the port that the request should connect to.
8. In the **Management wwan profile no.** field, enter the WAN profile that should handle the request.
9. The inform message acts as a beacon to inform the ACS of the existence of the router. Select **Enable periodic ACS informs** toggle key to ON in order to turn on the periodic ACS inform messages.
10. In the **Inform Period** field, enter the number of seconds between the inform messages.
11. Select the **Save** button to save the settings.

DNS server

The NTC-500 Series router can be configured to use custom DNS servers if required.

Figure 9-4 DNS configuration

DNS SERVER

DNS SERVER CONFIGURATION

Primary DNS server 9 9 9 9

Secondary DNS server 1 1 1 1

DNS cache size 1000 (0~5000)

DNS local TTL 3600 (0~86400 seconds)

Save

To set the DNS servers:

1. In the **Primary DNS server** field, enter the primary DNS server.
2. In the **Secondary DNS server** field, enter the secondary DNS server.
3. In the **DNS Cache Size** field, enter the size of the cache that should be kept on the router.
4. In the **DNS local TTL** field, enter the time to live (TTL) value, which indicates how long a cached request should remain in the router.
5. Select the **Save** button to save the configuration.

SMS messaging

The NTC-500 Series router offers an advanced SMS feature set, including sending messages, receiving messages, redirecting incoming messages to another destination, as well as supporting remote commands and diagnostics messages.

Some of the functions supported include:

- Ability to send a text message via a cellular network and store it in permanent storage.
- Ability to receive a text message via a cellular network and store it in permanent storage.
- Ability to forward incoming text messages via a cellular network to another remote destination which may be a TCP/UDP server or other mobile devices.
- Ability to receive run-time variables from the device (e.g. uptime) on request via SMS
- Ability to change live configuration on the device (e.g. network username) via SMS.
- Ability to execute supported commands (e.g. reboot) via SMS.
- Ability to trigger the NTC-500 Series router to download and install a firmware upgrade.
- Ability to trigger the NTC-500 Series router to download and apply a configuration file.

To access the SMS messaging functions of the NTC-500 Series router, select on the Services menu item from the top menu bar, and then select one of the options under the SMS messaging section on the left-hand menu.

Setup

The Setup page provides the options to enable or disable the SMS messaging functionality and SMS forwarding functionalities of the router. SMS messaging is enabled by default.

Figure 9-5 SMS - SMS setup configuration

SMS SETUP

GENERAL SMS CONFIGURATION

Messages per page 10-50

Encoding scheme ▼

SMSC address

SMS FORWARDING CONFIGURATION

Forwarding ☒ On ☐ Off

Redirect to mobile

TCP server address

TCP port 1-65535

UDP server address

UDP port 1-65535

Table 9-1 SMS - SMS setup configuration items

Option	Definition
General SMS configuration	
Messages per page (10-50)	The number of SMS messages to display per page. Must be a value between 10 and 50.
Encoding scheme	The encoding method used for outbound SMS messages. GSM 7-bit mode permits up to 160 characters per message but drops to 50 characters if the message includes special characters. UCS-2 mode allows the sending of Unicode characters and permits a message to be up to 50 characters in length.
SMS forwarding configuration	
Forwarding	Toggles the SMS forwarding function of the router on and off.
Redirect to mobile	Enter a mobile number as the destination for forwarded SMS messages.
TCP server address	Enter an IP address or domain name as the destination for forwarded SMS messages using TCP.
TCP port	The TCP port on which to connect to the remote destination.
UDP server address	Enter an IP address or domain name as the destination for forwarded SMS messages using UDP.

Option	Definition
UDP port	The UDP port on which to connect to the remote destination.

SMS forwarding configuration

Incoming text messages can be redirected to another mobile device and/or a TCP/UDP message server.

Redirect to mobile

You can forward incoming text messages to a different destination number. This destination number can be another mobile phone or a router phone number.

For Example:

If someone sends a text message and Redirect to mobile is set to “+61412345678”, the text message is stored on the router and forwarded to “+61412345678” at the same time.

To disable redirection to a mobile, clear the Redirect to mobile field and select the Save button.

Redirect to TCP / UDP server address

You can also forward incoming text messages to a TCP/UDP based destination. The TCP or UDP server can be any kind of public or private server if the server accepts incoming text-based messages.

The TCP/UDP address can be an IP address or domain name. The port number range is from 1 to 65535. Please refer to your TCP/UDP based SMS server configuration for which port to use.

For Example:

If someone sends a text message and TCP server address is set to “192.168.20.3” and TCP port is set to “2002”, this text message is stored in the router and forwarded to “192.168.20.3” on port “2002” at the same time.

To disable redirection to a TCP or UDP address, clear the TCP server address and UDP server address fields and select the Save button.

Diagnostics

The Diagnostics page is used to configure the SMS diagnostics and command execution configuration. This allows you to change the configuration, perform functions remotely and check on the status of the router via SMS commands.

To access the Diagnostics page, select on the **Services** menu item then select the **SMS** menu on the left and finally select **Diagnostics** beneath it.

Figure 9-6 SMS – SMS diagnostics configuration

SMS MESSAGING

SMS DIAGNOSTICS AND COMMAND EXECUTION CONFIGURATION

Enable remote diagnostics and command execution

On Off

Only accept authenticated SMS messages

On Off

Send Set command acknowledgement replies

On Off

Access advanced RDB variables

On Off

Allow execution of advanced commands

On Off

Send acknowledgement replies to

The sender's number

Send command error replies

On Off

Send error replies to

The sender's number

Send a maximum number of

100

replies per

day

(0 / 100 messages sent)

Limit the number of diagnostic text messages that can be sent in a designated time period. Currently, the 'messages sent' count automatically resets at the end of the designated time period. For example, it will reset to zero at 01:00, 02:00, 03:00 etc for 'hour', 00:00 for 'day', 00:00 on Monday for 'week' and the first day of the month for 'month', or at anytime the unit reboots.

WHITE LIST FOR DIAGNOSTIC OR EXECUTION SMS

+ Add

#	Destination number	Password

Save

Cancel

SMS diagnostics and command execution

Enables or disables the remote diagnostics feature. If this setting is enabled all incoming text messages are parsed and tested for remote diagnostics commands.

If remote diagnostics commands are found, the router executes those commands. This feature is enabled by default. All remote diagnostic commands that are received are stored in the Inbox.



Note: It is possible to adjust settings and prevent your router from functioning correctly using remote diagnostics. If this occurs, you will need to perform a factory reset in order to restore normal operation.



Important: We highly recommended that you use the white list and a password when utilising this feature to prevent unauthorised access. See the White list description for more information.

Only accept authenticated SMS messages

Enables or disables checking the sender's phone number against the allowed sender white list for incoming diagnostics and command execution SMS messages.

If authentication is enabled, the router will check if the sender's number exists in the white list. If it exists, the router then checks the password (if configured) in the incoming message against the password in the white list for the corresponding sending number. If they match, the diagnostic or command is executed.

If the number does not exist in the white list or the password does not match, the router does not execute the incoming diagnostic or command in the SMS message.

This is enabled by default and it is strongly advised that you leave this feature enabled to maintain security.

Sent set command acknowledgement replies

The NTC-500 Series router will automatically reply to certain types of commands received, such as get commands, or execute commands. However, acknowledgement replies from the NTC-500 Series router are optional with set commands and the Wakeup command. This option Enables or disables sending an acknowledgment message after execution of a set command or SMS Wakeup command. If disabled, the router does not send any acknowledgement after execution of a set command or SMS Wakeup command. All acknowledgment replies are stored in the Outbox after they have been sent. This can be useful to determine if a command was received and executed by the router. This option is disabled by default.

Access advanced RDB variables

This option allows access to the full list of RDB variables via SMS. When it is turned off, you are only allowed access to the basic RDB variables listed later in this guide.

Allow execution of advanced commands

This option allows execution of advanced commands such as those which are common to the Linux command line. For example: “execute ls /usr/bin/sms*” to list the contents of the /etc folder on the router.

When it is turned off you are only allowed to execute the basic commands listed later in this guide.

Send acknowledgment replies to

This option allows you to specify where to send acknowledgment messages after the execution of a set, get, or exec command.

If a fixed number is selected, the acknowledgement message will be sent to the number defined in the Fixed number to send replies to field. If the sender’s number is selected, the acknowledgement message will be sent to the number that the SMS diagnostic or command message originated from. The default setting is to use the sender’s number.

Fixed number to send replies to

This field defines the destination number to which error messages are sent after the execution of a get, set, or exec command. This field is only displayed when Send Error SMS to is set to Fixed Number.

Send a maximum number of

You can set the maximum number of acknowledgement and error messages sent when an SMS diagnostic or command is executed. The maximum limit can be set per hour, day, week or month. The router will send a maximum of 100 replies per day by default.

The number of messages sent is shown below the options. The total transmitted message count resets after a reboot or at the beginning of the time frame specified.

White list for diagnostic execution SMS

The white list is a list of mobile numbers that you can create which are considered “friendly” to the router. If **Only accept authenticated SMS** messages is enabled in the diagnostics section, the router will compare the mobile number of all incoming diagnostic and command messages against this white list to determine whether the diagnostic or command should be executed. You must configure a password for each number added to the white list to give an additional level of security.

Up to 20 numbers may be stored in the white list. To add a number to the white list, select the “+Add” button.

Figure 9-7 SMS - SMS diagnostics configuration – White list settings

To add a number to the white list, enter it in the Destination number field and define a password in the Password field. The SMS white list password must meet the following criteria for a strong password:

- Be a minimum of eight characters and no more than 128 characters in length.
- Contain at least one upper case, one lower case character and one number.
- Contain at least one of the following special characters: !*()?/

When you have finished adding numbers select the **Save** button to save the entries.

Sending an SMS diagnostic command

Follow the steps below to configure the router to optionally accept SMS diagnostic commands only from authenticated senders and learn how to send SMS diagnostic commands to the router.

1. Navigate to the Services > SMS messaging > Diagnostics page.
2. Confirm that the Enable remote diagnostics and command execution toggle key is set to the ON position. If it is set to OFF select the toggle key to switch it to the ON position.
3. If you wish to have the router only accept commands from authenticated senders, ensure that Only accept authenticated SMS messages is set to the ON position. In the White list for diagnostic or execution SMS messages section, select the +Add button and enter the sender’s number in international format into the Destination number field that appears. You must enter a password in the Password field corresponding to the destination number.
4. If you would prefer to accept SMS diagnostic commands from any sender, set the **Only accept authenticated SMS messages** toggle key to the **OFF** position.

Note: An alternative method of adding a number to the white list is to send an SMS message to the router, navigate to **Services > SMS messaging > Inbox** and then select the  button next to the message which corresponds to the sender’s number.

You will then need to set a Password in the White list for diagnostic execution SMS list.

5. Select the **Save** button.

Types of SMS diagnostic commands

There are three types of commands that can be sent; execute, get and set. The basic syntax is as follows:

- execute COMMAND
- get VARIABLE
- set VARIABLE=VALUE

If authentication is enabled, each command must be preceded by the password:

- PASSWORD execute COMMAND
- PASSWORD get VARIABLE
- PASSWORD set VARIABLE=VALUE

The following are some examples of SMS diagnostic commands:

- password6657 execute reboot
- get rssi
- set apn1=testAPNvalue

SMS acknowledgement replies

The router automatically replies to get commands with a value and execute commands with either a success or error response. Set commands will only be responded to if the Send Set command acknowledgement replies toggle key is set to ON. If the Send command error replies toggle key is set to ON, the router will send a reply if the command is correct but a variable or value is incorrect, for example, due to misspelling.

SMS command format

Generic Format for reading variables:

```
get VARIABLE
PASSWORD get VARIABLE
```

Generic Format for writing to variables:

```
set VARIABLE=VALUE
PASSWORD set VARIABLE=VALUE
```

Generic Format for executing a command:

```
Execute COMMAND
PASSWORD execute COMMAND
```

Replies

Upon receipt of a successfully formatted, authenticated (if required) command, the gateway will reply to the SMS in the following format:

Table 9-2 SMS – SMS diagnostics command syntax

Type	SMS Contents	Notes
get command	"VARIABLE=VALUE"	
set command	"Successfully set VARIABLE to VALUE"	Only sent if the acknowledgment message function is enabled
execute command	"Successfully executed command COMMAND"	

Where "VARIABLE" is the name of the value to be read

Where “VARIABLE (x)” is the name of another value to be read

Where “VALUE” is the content to be written to the “VARIABLE”

Where “COMMAND” is a supported command to be executed by the device (e.g. reboot)

Where “PASSWORD” is the password (if configured) for the corresponding sender number specified in the White List

Multiple commands can be sent in the same message, if separated by a semicolon.

For Example:

```
get VARIABLE1; get VARIABLE2; get VARIABLE3
PASSWORD get VARIABLE1; get VARIABLE2
set VARIABLE=VALUE1 ; set VARIABLE2=VALUE2
PASSWORD set VARIABLE1=VALUE1; set VARIABLE2=VALUE2; set VARIABLE3=VALUE3
```

If required, values can also be bound by an apostrophe, double apostrophe, or back tick.

For Example:

```
“set VARIABLE='VALUE'”
“set VARIABLE="VALUE"”
“set VARIABLE=`VALUE`”
“get VARIABLE”
```

A password (if required) only needs to be specified once per SMS, but can be prefixed to each command if desired.

```
“PASSWORD get Variable1”; “get VARIABLE2”
“PASSWORD set VARIABLE1=VALUE1”; “set VARIABLE2=VALUE2”
```

If the command sent includes the “reboot” command and has already passed the white list password check, the device keeps this password and executes the remaining command line after the reboot with this same password.

For Example:

```
“PASSWORD execute reboot; getVariable1”; “get VARIABLE2”
“PASSWORD execute reboot; PASSWORD get Variable1”; “get VARIABLE2”
```



Important: Commands, variables and values are case sensitive.

List of basic commands

A list of basic commands which can be used in conjunction with the execute command are listed below:

“pdpcycle”, “pdpdown” and “pdpup” commands can have a profile number suffix ‘x’ added. Without the suffix specified, the command operates against the default profile configured on the profile list page of the Web-UI.

Table 9-3 List of basic SMS diagnostic commands

Item	Command	Definition
1	reboot	Immediately performs a soft reboot.
2	pdpcycle	Disconnects (if connected) and reconnects the data connection. If a profile number is selected in the command, try to disconnect/reconnect the specified profile in case the profile is active. If no profile number is selected, try to disconnect/reconnect the

Item	Command	Definition
		current active profile. Reports an error if no profile number is selected and there is no currently activated profile.
3	pdpdown	Disconnects the PDP. If a profile number is selected in the command, the router tries to disconnect the specified profile in case the profile is active. If no profile number is selected, try to disconnect the current active profile. Reports an error if no profile number is selected and there is no currently activated profile.
4	pdpup	Reconnects the PDP. If a profile number is selected in the command, the router tries to connect with the specified profile. If no profile number is selected, the router tries to connect to the last active profile. The gateway will check the currently activated profile and disconnect this profile before executing the command. The router reports an error if no profile number is selected and there is no stored last active profile number.
5	factorydefaults	Performs a factory reset on the router. Be aware that this command also clears the SMS white list on the router.
6	download	Performs a download and install of a Firmware Upgrade (.cdi), Config File (.tar.gz) or a help document (.pdf) file. If the file is a firmware image as in the case of a .cdi file, the router will apply the recovery image first and then the main firmware image. The download location is specified immediately after the command and may be from an HTTP or FTP source URL. If the file is a .cdi file, the router will apply the file as a configuration file update for the device and reboot afterwards. If the file is a .pdf, the router will assume this is a user guide document and save it to the router and make the file available for viewing via the help menu on the Web-UI. Note: If your download URL includes any space characters, please encode these prior to transmission according to RFC1738, for example: ftp://username:password@serveraddress/directory%20with%20spaces/filename.cdi Note: Authenticated FTP addresses may be used following the format as defined in RFC1738, for example: ftp://username:password@serveraddress/directory/filename.cdi
10	ssh.genkeys	Instructs the router to generate new public SSH keys.
11	ssh.clearkeys	Instructs the router to clear the client public SSH key files.

List of get/set commands

The following table is a partial list of get and set commands which may be performed via SMS.

Table 9-4 SMS - List of get/set commands

Command name	Example	Description
get status	get status	Returns the Module firmware version, LAN IP Address, Network State, Network operator and Signal strength.
get sessionhistory	get sessionhistory	Returns the time and date of recent sessions along with the total amount of data sent and received for each session.
set syslogserver	set syslogserver=123.45.67.89:514	Sets a remote syslog server IP or hostname and port.
get plmnscan	get plmnscan	Instructs the router to perform a network scan and returns the results by SMS.
set forceplmn	set forceplmn=505,3	Sets the operator to a manual selection made by the user where “505” is the Mobile Country Code for Australia. As no network type (e.g.. LTE/5G) is specified, it is selected automatically.
get forceplmn	get forceplmn	Returns the operator and network type selection mode (Automatic/Manual), in addition to the MCC and MNC values
get ledmode	get ledmode	Returns the status of the LED operation mode.
set ledmode	set ledmode=10	Sets the LED operation mode to be always on or to turn off after the specified number of minutes.
get ssh.proto	get ssh.proto	Returns the SSH protocol in use.
set ssh.proto	set ssh.proto=1,2	Sets the SSH Protocol to protocol 1, 2 or both (1,2).
get ssh.passauth	get ssh.passauth	Returns the status of the SSH Enable password authentication option.
set ssh.passauth	set ssh.passauth=1	Sets the SSH Enable password authentication option on or off.
get ssh.keyauth	get ssh.keyauth	Returns the status of the SSH Enable key authentication option.
set ssh.keyauth	Set ssh.keyauth=1	Sets the SSH Enable key authentication option on or off.
get download.timeout	get download.timeout	Returns the time in minutes that the router waits before a download times out.
set download.timeout	set download.timeout=20	Sets the time in minutes that the router waits before a download times out. This is set to 10

Command name	Example	Description
		minutes by default. Supported range is 10 – 1440 minutes.
get install.timeout	get install.timeout	Returns the time in minutes that the router waits before a file that is being installed times out.
set install.timeout	set install.timeout=5	Sets the time in minutes that the router waits before a file that is being installed times out. This is set to 3 minutes by default. Supported range is 3 – 300 minutes.
get sw.version	get sw.version	Returns the software version of the router.

List of basic RDB variables

The following table lists valid variables where “x” is a profile number (1-6). If no profile is specified, variables are read from or written to for the current active profile. If a profile is specified, variables are read from or written to for the specified profile number (‘x’).

Table 9-5 SMS - List of basic SMS diagnostics RDB variables

#	RDB variable name	SMS variable name	Read/Write	Description	Example VALUE
0	link.profile.1.enable link.profile.1.apn link.profile.1.user link.profile.1.pass link.profile.1.auth_type link.profile.1.iplocal link.profile.1.status	profile	RW	Profile	Read: (profile no,apn,user,pass,auth,iplocal,status) 1,apn,username,password, chap,202.44.185.111,up Write: (apn, user, pass,auth) apn,username,password
2	link.profile.1.user	username	RW	Cellular broadband username	Guest, could also return “null”
3	link.profile.1.pass	password	RW	Cellular broadband password	Guest, could also return “null”
4	link.profile.1.auth_type	authtype	RW	Cellular broadband Authentication type	”pap” or”chap”
5	link.profile.1.iplocal	wanip	R	WAN IP address	202.44.185.111

#	RDB variable name	SMS variable name	Read/Write	Description	Example VALUE
6	wwan.0.radio.information.signal_strength	rsi	R	Cellular signal strength	-65 dBm
7	wwan.0.imei	imei	R	IMEI number	3.57347E+14
8	statistics.usage_current	usage	R	Cellular broadband data usage of current session	"Rx 500 bytes, Tx 1024 bytes, Total 1524 bytes" or "Rx 0 byte, Tx 0 byte, Total 0 byte" when wwan down
9	statistics.usage_current	wanuptime	R	Up time of current cellular broadband session	1 days 02:30:12 or 0 days 00:00:00 when wwan down
10	/proc/uptime	deviceuptime	R	Device up time	1 days 02:30:12
11	wwan.0.system_network_status.current_band	band	R	Current band	NR5G BAND 78

Network scan and manual network selection by SMS

Performing a network scan:

The get plmnscan SMS command enables you to perform a scan of the cellular networks available at the time of the scan.

It returns the following semi-colon separated information for each network in range:

- MCC
- MNC
- Network Type (LTE, 5G)
- Provider's Name
- Operator Status (available, forbidden, current)

The following is an example of a response from the get plmnscan SMS command:

```
plmnscan=505,03,7,vodafone AU,1;505,03,1,vodafone AU,1;505,03,9,vodafone AU,4;505,01,7,Telstra Mobile,1;505,01,1,Telstra Mobile,1;505,02,9,YES OPTUS,1;505,02,1,YES OPTUS,1;505,01,9,Telstra
```

Table 9-6 Operator status codes returned by get plmnscan SMS command

Operator status	Description
1	Indicates an available operator which may be selected.
2	Indicates a forbidden operator which may not be selected (applies only to generic SIM cards).

Operator status	Description
4	Indicates the currently selected operator.

Note:

- If the connection status is Up and connection mode is Always on, the get plmnscan SMS will cause the connection to disconnect, perform the scan, send the result through SMS and then bring the connection back up again. If the connection status is Down, the router will perform the PLMN scan, send the result and keep the connection status down.
-  If the connection status is Waiting and connection mode is Connect on demand, the get plmnscan SMS will change the connection status to Down, perform the scan, send the result through SMS and then restore the connection status to the Waiting state.
- If the connection status is Up and connection mode is Connect on demand, the get plmnscan SMS will cause the connection to disconnect, perform the scan, send the result through SMS, and then restore the connection status to the Waiting state unless there is a traffic which triggers a connection in which case the connection status will be set to Up.

Setting the router to connect to a network

The router can be instructed by SMS to connect to one of the networks returned by the `get plmnscan` command. The `set forceplmn` command forces the router to connect to a specified operator network (if available) while the `get forceplmn` command retrieves the currently configured network on the router.

The command format for the set forceplmn command is:

```
set forceplmn=0|MCC,MNC| MCC,MNC,Network Type
```

For example:

```
set forceplmn=0
```

Sets the selection of operator and network type to automatic mode.

```
set forceplmn=505,1
```

Sets the operator to a manual selection made by the user where “505” is the Mobile Country Code for Australia and “1” is the Mobile Network Code for Telstra. As no network type (e.g. LTE/5G) is specified, it is selected automatically.

```
set forceplmn=505,1,9
```

Sets the operator and network type to a manual selection made by the user where “505” is the Mobile Country Code for Australia, “1” is the Mobile Network Code for Telstra and “9” is the LTE network type.

Table 9-7 SMS - Mobile Network Provider codes (Australia)

Mobile Network Code	Mobile Network Provider
1	Telstra
2	Optus
3	Vodafone

Confirming the currently configured operator and network type

You can retrieve the currently configured operator and network type using the **get forceplmn** command.

The **get forceplmn** command returns the operator and network type selection mode (Automatic/Manual), in addition to the MCC and MNC values, for example:

```
Automatic,505,1
```

This response indicates that the operator/network selection mode is Automatic, and the network used is Telstra.

SMS diagnostics examples

The examples below demonstrate various combinations of supported commands. This is not an exhaustive list and serves as an example of possibilities only.

If the default setting of **Only accept authenticated SMS messages** is enabled, then password authentication is required. Add your password followed by a space as a prefix to the command, for example

If authentication required:

```
PASSWORD set username= "CasaSystems"
```

If authentication not required:

```
set username='CasaSystems'
```



Note: The authentication setting is in the user interface at Services > SMS messages > Diagnostics.

Table 9-8 SMS – SMS diagnostics example commands

Description	Input Command (without PASSWORD prefix)
Send SMS to change the data connection username	set username='username'
Send SMS to change the data connection password	set password= `password`
Send SMS to change the data connection authentication	set authtype= 'pap'
Send SMS to reboot	execute reboot
Send SMS to check the WAN IP address	get wanip
Send SMS to check the mobile signal strength	get rssi
Send SMS to check the IMEI number	get imei
Send SMS to check the current band	get band
Send SMS to Disconnect (if connected) and reconnect the data connection	execute pdpcycle
Send SMS to disconnect the data connection	execute pdpdown
Send SMS to connect the data connection	execute pdpup

Description	Input Command (without PASSWORD prefix)
Send multiple get command	<code>get wanip; get rssi</code>
Send multiple set command	<code>set ssh.genkeys=1; set username=test; set auth=pap</code>
Send SMS to reset to factory default settings	<code>execute factorydefaults</code>
Send SMS to retrieve status of router	<code>get status</code>
Send SMS to retrieve the history of the session, including start time, end time and total data usage	<code>get sessionhistory</code>
Send SMS to configure the router to send syslog to a remote syslog server	<code>set syslogserver=123.209.56.78</code>
Send SMS to perform firmware upgrade when firmware is located on HTTP server	<code>execute download http://download.com:8080/firmware_image.cdi</code> <code>execute download http://download.com:8080/firmware_image_r.cdi</code>
Send SMS to perform firmware upgrade when firmware is located on FTP server	<code>execute download ftp://username:password@download.com/firmware_image.cdi</code> <code>execute download ftp://username:password@download.com/firmware_image_r.cdi</code>
Send SMS to download and install IPK package located on HTTP server	<code>execute download http://download.com:8080/package.ipk</code>
Send SMS to download and install IPK package located on FTP server	<code>execute download ftp://username:password@download.com:8080/package.ipk</code>
Send SMS to set the LED mode timeout to 10 minutes	<code>set ledmode=10</code>
Send SMS to retrieve the current LED mode	<code>get ledmode</code>
Retrieve current SSH protocol	<code>get ssh.proto</code>
Select SSH protocol	<code>set ssh.proto=1</code>
Retrieve password authentication status	<code>get ssh.passauth</code>
Enable/disable password authentication on host	<code>set ssh.passauth=1</code> or <code>set ssh.passauth=0</code>
Generate set of public/private keys on the host	<code>execute ssh.genkeys</code>
Clear client public keys stored on host	<code>execute ssh.clearkeys</code>
Send SMS to initiate a Network Quality test	<code>get networkquality</code>

Inbox

The Inbox displays all received messages that are stored on the router.

Figure 9-8 SMS – Inbox




Table 9-9 SMS - Inbox

Icon	Name	Description
	Forward	Opens a new message window where you can forward the corresponding message to another recipient.
	Reply	Opens a new message window where you can reply to the sender.
	Add to White list	Add the sender's mobile number to the white list on the router.
	Delete	Delete the corresponding message.
	Refresh	Refresh the inbox to see new messages.

New message

The New message page can be used to send SMS text messages to a single or multiple recipients. To access the New message page, select on the Services menu item from the top menu bar, select the SMS messaging menu on the left then select the New message menu item.

A new SMS message can be sent to a maximum of 9 recipients at the same time. After sending the message, the result is displayed next to the destination number as “Success” or “Failure” if the message failed to send. By default, only one destination number field is displayed. Additional destination numbers may be added one at a time after entering a valid number for the current destination number field. To add a destination number, select the  button and to remove the last destination in the list, select the  button.

Figure 9-9 SMS – New message

SMS MESSAGING

NEW MESSAGES

Destination number + -

NEW MESSAGES

This is where the content of the message is filled out.

55

Send Clear

Destination numbers should begin with the “+” symbol followed by the country calling code. To send a message to a destination number, enter the “+” symbol followed by the country calling code and then the destination number.

For example:

To send a message to the mobile destination number 0412345678 in Australia (country calling code 61), enter “+61412345678”.

After entering the required recipient numbers, type your SMS message in the New message field. As you type your message, a counter shows how many characters you have entered out of the total number available for your chosen encoding scheme. When you have finished typing your message and you are ready to send it, select the Send button.

Outbox

The outbox displays all sent messages.

Figure 9-10 SMS - Outbox

SMS MESSAGING

SENT MESSAGES (0) ↻

< Previous 1 of 1 Next > Delete All

To	Time	Message
----	------	---------

Use the **Delete All** button to empty the outbox.

MQTT

The MQTT page is used to configure the NTC-500 Series router to use the MQTT protocol. MQTT is a standards-based messaging protocol used for machine-to-machine communication. Information is sent to clients in the form of a ‘topic’. The NTC-500 Series router can be configured to send device information and neighbouring cells as a topic to common IoT monitoring applications, such as Microsoft Azure IoT Hub and Amazon IoT, using MQTT.

Figure 9-11 MQTT Client

MQTT CLIENT

MQTT CLIENT CONFIGURATION

MQTT client enable ☒ On ☐ Off

[Save](#)

CLIENT LIST

[+ Add](#)

Name	Client ID		
IoT MQTT Demo Server	myclientid		

Configuring MQTT

Prerequisites

Before configuring MQTT on the NTC-500 Series router, you may need to create the device on your external MQTT client provider, and generate certificates and keys as required for secure authentication. Refer to your external MQTT provider's documentation for the required authentication configuration.

Configuration

1. Set the MQTT client enable toggle to **On**, then select the **Save** button.
2. Select the **Add+** button to add a new client. The **MQTT client** page is displayed.

Figure 9-12 MQTT – MQTT Client configuration

MQTT CLIENT

MQTT CLIENT SETTING

Name

Host name

Client ID

MQTT port MQTT: 1883, MQTTS: 8883, default: automatic

Auth username

Auth password

Keepalive (0-65535) secs

MQTT protocol

CA file Not uploaded

Client cert file Not uploaded

Client key file Not uploaded

DEVICE ID DATA

Enable

NEIGHBOUR CELLS

Enable

SERVING CELLS

Enable

3. Under MQTT configuration, enter the parameters as required. The following table details each field:

Table 9-10 MQTT Client configuration parameters

Parameter	Description
Name	Name of the client which will identify the client on the NTC-500 Series router
Host name	Hostname of your client
Client ID	Client Id of the client. The Client Id may match the name of your client provider, for example, the name of your AWS IoT 'Thing'.
MQTT port	The port MQTT should be initiated over.
Auth username	The username of the connection.
Auth password	The password of the connection.
Keepalive	Number of seconds that the connection should be kept alive.
MQTT protocol	Version of MQTT that should be used.
CA file	The Certificate Authority used to generate your Client Certificate file.
Client cert file	The client certificate file generated as part of your client's configuration.
Client key file	The client key file generated as part of your client's configuration.

1. Set the Enable toggle to **On** to enable the 'topic' that should be sent from the NTC-500 Series router.

Figure 9-13 MQTT – MQTT Client Configuration – MQTT topics

DEVICE ID DATA

Enable ☒ On ☐ Off

Publish topic string

Publish QoS ▼

Minimum publish interval seconds

NEIGHBOUR CELLS

Enable ☒ On ☐ Off

Publish topic string

Publish QoS ▼

Minimum publish interval seconds

SERVING CELLS

Enable ☒ On ☐ Off

Publish topic string

Publish QoS ▼

Minimum publish interval seconds

Drift interval dBm

2. Configure the following parameters as required:

Table 9-11 MQTT Client topic parameters

Parameter	Description
Publish topic string	Enter a string which will identify the topic on the MQTT client.
Publish QoS	Select the Publish QoS (Quality of Service) for the topic. Three options are available: • At most once • At least once • Exactly once At most once is the lowest level of QoS in MQTT, which offers a best-effort delivery mechanism where the sender does not expect an acknowledgment or guarantee of message delivery. At least once guarantees the message delivery but potentially exists duplicate messages. Exactly ensures that messages are delivered exactly once without duplication
Minimum publish interval	Set the minimum publish level in seconds. This is the amount of time the NTC-500 Series router will wait before attempting to publish a message.

3. Select the Save button to create the client. The client appears in the MQTT client list.

Figure 9-14 MQTT – MQTT Client Configuration – MQTT client list

CLIENT LIST		+ Add	
Name	Client ID		
IoT MQTT Demo Server	myclientid		

OMA-LWM2M

The OMA Lightweight M2M (OMA-LWM2M) protocol was designed by the Open Mobile Alliance to provide remote device management specifically for M2M devices. It is less taxing on the system and network than OMA-DM and TRS-069. OMA-LWM2M runs over UDP and supports asynchronous notifications when a resource changes.

It provides:

- Firmware upgrades
- Device monitoring and configuration
- Server provisioning

To configure the Lightweight M2M client, select the Enable LwM2M toggle key so that it is in the ON position.

Figure 9-15 OMA-LWM2M configuration

LWM2M CONFIGURATION

LWM2M CLIENT CONFIGURATION

Lwm2m endpoint

ntc_502:219943231100012

Enable Lwm2m

On

Off

Management wwan profile no.

Default route

Management port

1-65535

OVERRIDE SERVER SETTINGS

Override enable

On

Off

Override once

On

Off

Server URI

Registration lifetime

600

(60~86400) seconds

Bootstrap server

On

Off

Queue mode

On

Off

Security mode

Pre-Shared Key

Client identity

Test

PSK coding

hex

PSK key

abcd1234

Save

Table 9-12 OMA-LWM2M configuration items

Item	Description
LwM2M Endpoint Name	This is the unique ID the device will use to identify itself with LwM2M servers.
Enable LwM2M	Toggle key which enables or disables the LwM2M function.
Override Server Settings	The LwM2M client maintains the list of servers that it will connect to as part of its internal state. Enabling this setting will allow a user to specify new server details that will override whatever current settings the client has.
Override Once	When 'Override Settings' is enabled, this option allows you to specify whether the new server details they provide will be applied once when the client is restarted (normal flow for configuring/reconfiguring the client) or, when disabled, applied every time the client restarts (used for debugging/troubleshooting.)
Server URI	When 'Override Settings' is enabled, this allows you to specify the URI of the LwM2M server to connect to. Must be a fully specified CoAP or CoAPS URI, including port number, e.g. coap://server.com:5683 or coaps://server.com:5864.
Registration Lifetime	When 'Override Settings' is enabled, this allows you to specify the interval (in seconds) at which the LwM2M client will send registration updates (i.e. heartbeat messages) to the server.
Bootstrap Server	When 'Override Settings' is enabled, this allows you to specify whether the new server is a LwM2M bootstrap server.
Queue Mode	When 'Override Settings' is enabled, this allows you to specify whether to report the UDP binding mode to the server as queued ("UQ" binding mode) or not ("U" binding mode.)
Security Mode	When 'Override Settings' is enabled, this allows you to choose the security mode that will be used to connect to the LwM2M server. Currently supported options are 'No Security' and 'Pre-Shared Key' (PSK).
Client Identity	When PSK security mode is selected this field is where you must specify the identity string associated with your pre-shared key.
PSK coding	When PSK security mode is select this field is where you must specify the coding for the key. The coding can be either 'hex' or 'plain text'.
PSK Key	When PSK security mode is selected this field is where you must provide the pre-shared key. The key must be entered as a hexadecimal string or a plain text string, depending on the selected setting in the PSK coding field.

Table 9-13 - OMA-LWM2M configuration items

Supported LWM2M objects

The table below lists the supported object IDs on the NTC-500 Series router. For further information on the objects, refer to the [Open Mobile Alliance LWM2M registry](#).

Table 9-14 LWM2M supported objects

Object	Object ID	Note
LWM2M Server	1	
LWM2M Access Control	2	
Device	3	
Connectivity Monitoring	4	
Firmware Update	5	
Location	6	
APN Connection Profile	11	
System Log	10259	Custom object
Runtime Database Access	10260	Custom object
Phone Module Info	33040	Custom object

Timeouts

Most mobile networks use stateful firewalls or NAT where the timeout for UDP is approximately 1-2 minutes. If this applies to you, we suggest either configuring the LwM2M client with a registration lifetime that falls within this period (e.g. 60 seconds) or using the queued ("UQ") UDP binding mode.

Event Configuration

The NTC-500 Series router can be programmed to send notifications when certain events occur on the router. These notifications can be used for proactive monitoring of events such as unit reboots and Ethernet link changes.

Figure 9-16 Event Notification – Configuration

EVENT NOTIFICATION CONFIGURATION

Enable

On

Off

Maximum event buffer size

(100-10000)

Maximum retry count

(1-20)

Event notification log file

Unit ID

B38CC5

Event Notification Configuration

To use Event Notifications:

1. Enable event notifications by setting the **Enable** toggle to **On**.
2. In the **Maximum buffer event size** field, specify the buffer size for event notifications which failed to be delivered or are yet to be sent.
3. In the **Maximum retry count** field, enter the number of times the NTC-500 Series router should attempt to deliver the notification in the event of a delivery failure.
4. If required, adjust the output location of the **Event notification log file**.
5. For each of the **Event Notification Types** select the **Destination Profile** which should send the notification when the notification is triggered. For details on how to configure the Destination Profiles, view the [Destination Configuration](#) section.
6. Select the **Save** button to apply the configuration.

Figure 9-17 Event Configuration – Available notification types

EVENT NOTIFICATION TYPES AND DESTINATIONS MAPPING		
Event ID	Event notification type	Destination profile
1	Unit powered up	Default v
2	Unit rebooted	Default v
3	Link status change	Default v
4	WWAN IP address change	Default v
5	WWAN Registration change	Default v
6	WWAN Cell ID change	Default v
7	WWAN technology change	Default v
8	Number of connected Ethernet interfaces change	Default v
10	Login status	Default v
20	FOTA/DOTA status	Default v
23	USB connection change	Default v
24	GPS GEOFENCE status change	Default v

Destination configuration

The **Destination Configuration** page allows for the configuration of the Event Destination List, which specifies where notifications should be sent when they are triggered.

Figure 9-18 Log – Event destination list

Name	Email address	SMS number	TCP address	UDP address	Custom command
Default					

Configuring a destination

Multiple destinations can be configured and assigned to different event types, depending on what notifications need to be sent.

To configure or edit an event destination:

1. Select the **Add** button to add a destination or the  button to edit an existing destination. The **Event Destination Profile Settings** page opens.

Figure 9-19 Services – Event configuration – Destination Configuration – Event Destination Profile settings

2. In the **Destination name** field enter a name to identify the destination profile. This name will appear on the **Event Notification Configuration** page, in the **Destination Profile** column.

Note: The Email address, SMS number, TCP address, UDP address and Custom command fields listed



below are all optional. Complete the fields which should be included when a notification is sent. The TCP port and UDP port fields are required if using a TCP address or UDP address.

3. In the **Email address** field, enter an email address to receive the notification.
4. In the **SMS number** field, enter a phone number to receive the notification as an SMS.

5. In the **TCP address** and **TCP port** fields, enter a TCP address and TCP port to receive the notification over TCP.
6. In the **UDP address** and **UDP port** fields, enter a UDP address and UDP port to receive the notification over UDP.
7. In the **Custom command** field, enter a custom command to execute when the notification is triggered. The command should be a bash compatible command.
8. Select the **Save** button to save the destination profile.
9. Apply the destination profile by returning to the **Event Configuration > Event Notification Configuration** page.
10. Set the **Destination profile** dropdown on the appropriate Event Notification and Destination Mapping item to the new destination.

Figure 9-20 Services – Event Configuration – Destination profile mapping

Event ID	Event notification type	Destination profile
1	Unit powered up	MyCustoml V Default MyCustomDestination

11. Select the **Save** button at the bottom of the **Event Notification Configuration** page.

Event notification log

The **Event Notification Log** displays a log of Events which have been triggered. Select the **Update** button to refresh the content in the **Log Content** window. Select the **Download** button to download a log file for review in an external application. Select the **Clear** button to clear the log.

Figure 9-21 Services – Event Configuration – Event notification log




Figure 9-22 – Services – Event Configuration – Event notification log

Email Settings

The email settings page is used to configure the SMTP server to be used to deliver Event Notifications (configured in the Event notification configuration section).

Figure 9-23 Email Client Setting

EMAIL CLIENT SETTING

EMAIL SERVER SETTINGS

From:

CC:

Email server address (SMTP):

Email server port: (STARTTLS:587, SSL/TLS:465, Default:25)

Encryption: ▼

Enable authentication: ☒ On ☐ Off

Username:

Password:

Confirm password:

Email test recipient:

To configure the Email Server Settings, the following information is required:

Table 9-15 Email Client Setting Configuration

Parameter	Description
From	Email address that the email notification should appear to be from.
CC	Email address or addresses that the notification should be sent to.
Email server address (SMTP)	SMTP server that the email should be sent through.
Email server port	Port that the SMTP server is expecting email on. The port varies depending on the encryption type used, refer to your email provider's SMTP instructions on which port is correct. The available encryption types are STARTTLS (Port 587) , SSL/TLS (Port 465) , or Default (Port 25) .
Encryption	Select the encryption type from the drop-down. Available types are STARTTLS , SSL/TLS , None .
Enable authentication	If the SMTP server is expecting authentication, set the Enable Authentication toggle to On .
Username	Username to authenticate with the SMTP server.
Password	Password to authenticate with the SMTP server.

Parameter	Description
Confirm password	Re-enter the password to authenticate with the SMTP server.
Email test recipient	Enter an email address here after completing the previous details to test the SMTP configuration.
Send test email button	Select this button to send the test email to the address configured in the Email test recipient field.
Save button	Applies the email setting configuration.

Dynamic DNS

Dynamic DNS (DDNS) allows your NTC-500 Series router to associate an easy-to-remember domain name, such as **[yourdomainname].com** with the regularly changing IP address assigned by your carrier. This feature allows you to connect to the NTC-500 Series router and its internal network more easily for maintenance.

Figure 9-24 Services – Dynamic DNS

The screenshot shows the 'DYNAMIC DNS' configuration page. At the top, there's a header 'DYNAMIC DNS' and a sub-header 'DYNAMIC DNS CONFIGURATION'. Below this, there's an 'Enable' toggle switch set to 'On'. The 'Dynamic DNS' field is a dropdown menu with 'www.dhs.org' selected. The 'Hostname' field contains 'www.myhostname.com'. The 'Username' field contains 'demouser@example.com'. The 'Password' and 'Verify password' fields are masked with asterisks and have eye icons to toggle visibility. A blue 'Save' button is at the bottom.

To use DDNS, you will need to sign up for a DDNS provider which is supported by the NTC-500 Series router. The supported providers are DHS.org, No-IP, DynDNS, easyDNS, and ZoneEdit. To configure DDNS on the NTC-500 Series router you will require your unique hostname from the provider, as well as your username and password which you used to sign up to the provider.

To configure DDNS:

1. To enable DDNS, set the **Enable** toggle to **On**.
2. In the **Dynamic DNS** field select the provider you have signed up with.
3. In the **Hostname** field, enter the custom hostname which you added to your provider.
4. In the **Username** field, enter the username which you used to sign up to your provider.
5. In the **Password** field, enter the password which you used to sign up to your provider.
6. In the **Verify Password** field, re-enter the password which you used to sign up to your provider.
7. Select the **Save** button to apply the configuration.

10. System

Log

The Log pages are used to download the System log, Event notification logs and IPSec logs on the router.

System log

The System Log enables you to troubleshoot any issues you may be experiencing with your NTC-500 Series router. To access the System Log page, select on the System menu. The System Log page is displayed.

The display level dropdown allows for filtering of the logs that you wish to see.

Table 10-1 Log – System log levels

Item	Definition
Debug	Show extended system log messages with full debugging level details.
Info	Show informational messages only.
Notice	Show normal system logging information.
Warning	Show warning messages only.
Error	Show error condition messages only.

Use the Display level dropdown to select the level of log that you wish to view, then select Download.

The downloaded log file is in Linux text format with carriage return (CR) only at the end of a line, therefore to be displayed correctly with new lines shown, it is recommended to use a text file viewer which displays this format correctly (e.g. Notepad++).

System log settings

To access the System log settings page, select on the System menu item then select the Log menu on the left and then select System log settings from the drop-down menu.

Log data is stored in RAM and therefore when the unit loses power or is rebooted the RAM will lose any log information stored in the RAM. To ensure that log information is accessible between reboots of the router there are two options:

- Enable the Log to non-volatile memory option.
- Use a Remote syslog server.

Figure 10-1 Log – System log settings

SYSTEM LOG SETTINGS

LOG CAPTURE LEVEL

Log capture level Notice

VOLATILE LOG

Log buffer size (KB) 256 100-512

NON VOLATILE LOG

Log to non-volatile memory On Off

Log file size (KB) 5000 500-5000

REMOTE SYSLOG SERVER

IP / Hostname [:PORT] 192.168.2.1:514

Save

Log capture level

The log capture level defines the amount of detail that the system log stores. This setting also affects the Display level setting on the System log page, for example, if this is set to a low level, such as “Error”, the System log will not be able to display higher log levels.

Table 10-2 Log - System log detail levels

Item	Definition
Debug	Show extended system log messages with full debugging level details.
Info	Show informational messages only.
Notice	Show normal system logging information.
Warning	Show warning messages only.
Error	Show error condition messages only.

Volatile Log

The size of the volatile log buffer can be configured to store larger logs if required. The default is 256KB.

Non-volatile Log

When the router is configured to log to non-volatile memory, the log data is stored in flash memory, making it accessible after a reboot of the router. Up to 512kb of log data will be stored before it is overwritten by new log data. Flash memory has a finite number of program-erase operations that it may perform to the blocks of memory.

While this number of program-erase operations is quite large, we recommend that you do not enable this option for anything other than debugging to avoid excessive wear on the memory.

Remote syslog server

The router can be configured to output log data to a remote syslog server. This is an application running on a remote computer which accepts and displays the log data. Most syslog servers can also save the log data to a file on the computer on which it is running allowing you to ensure that no log data is lost between reboots.

To configure the NTC-500 Series router to output log data to a remote syslog server:

1. Select on the System menu from the top menu bar. The System log item is displayed.
2. Under the Remote syslog server section, enter the IP address or hostname of the syslog server in the IP / Hostname [PORT] field. You can also specify the port number after the IP or hostname by entering a semi-colon and then the port number e.g. 192.168.1.102:514. If you do not specify a port number, the router will use the default UDP port 514.

Figure 10-2 Log – System log settings – Remote syslog server

The screenshot shows a web-based configuration interface for a 'REMOTE SYSLOG SERVER'. At the top, the title 'REMOTE SYSLOG SERVER' is displayed in blue. Below the title, there is a text input field labeled 'IP / Hostname [:PORT]' containing the value '192.168.2.1:514'. Below the input field is a blue rectangular button with the text 'Save' in white.

3. Select the Save button to save the configuration.

Diagnostic log

The router may be configured to enable the collection of diagnostic logs for the purpose of troubleshooting problems. These log files are intended for use by Lantronix technicians. By default, this feature is disabled and should only be enabled if you are trying to find out the cause of a problem and are instructed to enable this by Lantronix technical support staff.

Figure 10-3 Log – Diagnostic log configuration and download

DIAGNOSTIC LOG

LOG CONFIGURATION

Diagnostic log collection ☐ On ☒ Off

Log capture interval Once only ▼

Maximum diagnostic log size 256 100-10000 (KB)

Maximum kernel panic data size 256 1-1000 (KB)

Save

LOG CAPTURE INFORMATION

Number of captured diagnostic logs 0

Captured kernel panic data 0 (KB)

Download Clear

Table 10-3 Diagnostic log descriptions

Item	Description
Diagnostic log configuration	
Periodic log collection	Turn on this toggle key to enable diagnostic log collection.
Log capture interval	Specifies the interval at which the router should collect diagnostic log data.
Maximum periodic log size (KB)	Specifies the maximum size of the log file in kilobytes.
Maximum kernel panic data size (KB)	Specifies the maximum size of the kernel panic data file in kilobytes.
Save button	Saves the Log Configuration.
Log capture information	
Number of captured periodic logs	Displays the number of captured periodic logs.

Item	Description
Captured kernel panic data (KB)	Displays the total size of captured kernel panic data in kilobytes.
Clear all captured periodic logs	Press the “Clear” button to clear all captured periodic logs.
Download all captured logs	Press the “Download” button to download all captured logs.

IPSec log

The IPSec Log enables you to identify and troubleshoot issues with the IPSec VPN connection. To access the IPSec Log page, select IPSec Log on the System menu. The IPSec Log page is displayed.

Figure 10-4 Log - IPSec Log

IPSEC LOG

common level

0 (auditing)

▼

the common level for all types

Please set the level for each type

app

0 (auditing)

▼

applications other than daemons

dmn

0 (auditing)

▼

Main daemon setup/cleanup/signal handling

mgr

0 (auditing)

▼

IKE_SA manager, handling synchronization for IKE_SA access

ike

0 (auditing)

▼

IKE_SA/ISAKMP SA

chd

0 (auditing)

▼

CHILD_SA/IPsec SA

job

0 (auditing)

▼

Jobs queuing/processing and thread pool management

cfg

0 (auditing)

▼

Configuration management and plugins

knl

0 (auditing)

▼

IPsec/Networking kernel interface

net

0 (auditing)

▼

IKE network communication

asn

0 (auditing)

▼

Low-level encoding/decoding (ASN.1, X.509 etc.)

enc

0 (auditing)

▼

Packet encoding/decoding encryption/decryption operations

lib

0 (auditing)

▼

libstrongswan library messages

esp

0 (auditing)

▼

libipsec library messages

tls

0 (auditing)

▼

libtls library messages

tnc

0 (auditing)

▼

Trusted Network Connect

imc

0 (auditing)

▼

Integrity Measurement Collector

imv

0 (auditing)

▼

Integrity Measurement Verifier

pts

0 (auditing)

▼

Platform Trust Service

Save

Download

Update

To use the IPSec log, first set the log level for each type of log that should be captured. The following log levels are available:

Table 10-4 IPsec log descriptions

Item	Definition
Off	No logs collected.
0 Auditing	Auditing is the lowest log level, providing minimal information. This level is typically used for logging only critical security events or administrative actions that have a significant impact on the VPN.
1 Control Flow	Control Flow logging provides information about the establishment and termination of IPsec VPN connections and security associations (SAs). Control Flow includes details about the negotiation of encryption and authentication parameters, as well as key exchange protocols like IKE (Internet Key Exchange).
2 Debug Control Flow	Debug Control Flow logging provides more detailed information than the standard Control Flow level. Debug Control Flow includes additional debugging information related to the establishment and management of IPsec SAs.
3 Raw Data Dumps	Raw Data Dumps logging is a very verbose level that includes detailed packet-level information. Raw Data Dumps logs raw data, such as the contents of IPsec packets and payloads.
5 Private Data Dumps	Private Data Dumps logging is the highest log level and provides the most detailed information. Private Data Dumps logs sensitive and private data, such as encryption keys and other security-related information. This level should only be used in a secure environment for advanced debugging or security analysis.

Once the log level has been set, select the **Save** button to apply the log configuration.

Viewing and downloading the IPsec log

As logs are collected, they are visible in the **Log Content** section at the bottom of the page. Select the **Update** button to refresh the Log Content window.

To view the logs in an external tool, select the **Download** button.

Watchdog

Periodic ping

The **Periodic ping** page is used to configure the behaviour of the Periodic Ping monitor function.

When configured, the Ping watchdog feature transmits controlled ping packets to 1 or 2 user specific IP addresses. Should the watchdog not receive responses to the pings, it will reboot the device in a last resort attempt to restore connectivity.

Caution should be exercised when using this feature in situations where the device is intentionally offline for a particular reason (e.g. user configured PDP session disconnect, or the Connect on demand feature enabled). The ping watchdog feature expects to be able to always access the internet and will always eventually reboot the router if access isn't restored by the time the various timers and retries expire.

The ping watchdog being a last resort standalone backup mechanism that it will continue to do its job and reboot the device even when the Connect on demand session is idle, or the PDP context is disabled by the user.

It is recommended to disable this feature if Connect on demand is configured, or if the PDP context will be intentionally disconnected on the occasion.

The feature operates as follows:

1. After every “Periodic Ping timer” configured interval, the router sends 3 consecutive pings to the “First destination address”.
2. If all 3 pings fail the router sends 3 consecutive pings to the “Second address”.
3. The router then sends 3 consecutive pings to the “Destination address” and 3 consecutive pings to the “Second address” every “Retry timer” configured interval.
4. If all retry pings in step C above fail the number of times configured in “Fail count”, the router reboots.
5. If any ping succeeds, the router returns to step A and does not reboot.

Figure 10-5 Watchdog – Periodic ping and reboot configuration

The screenshot shows the 'WATCHDOG' configuration page. It is divided into two main sections: 'PERIODIC PING' and 'PERIODIC REBOOT'.

PERIODIC PING Section:

- Enable:** A toggle switch set to 'On'.
- First destination address:** A field with four input boxes containing the values 192, 168, 2, and 1.
- Second destination address:** A field with four input boxes containing the values 192, 168, 2, and 6.
- Periodic Ping timer:** A text input field with the value 0, with a range of (300-65535) secs indicated.
- Retry timer:** A text input field with the value 0, with a range of (0=disable, 60-65535) secs indicated.
- Fail count:** A text input field with the value 0, with a range of (1-65535) times indicated.

PERIODIC REBOOT Section:

- Enable:** A toggle switch set to 'On'.
- Force reboot every:** A text input field with the value 5, with a range of (5-65535) mins indicated.
- Random delay before reboot:** A dropdown menu currently showing '1 minute'.

At the bottom of the form are two buttons: 'Save' and 'Cancel'.

Configuring Periodic Ping settings

The Periodic Ping settings configure the router to transmit controlled ping packets to 2 specified IP addresses. If the router does not receive responses to the pings, the router will reboot.

To configure the ping watchdog:

1. Enable the ping watchdog by setting the Periodic Ping Enable toggle to **On**.
2. In the **First destination address** field, enter a website address or IP address to which the router will send the first round of ping requests.
3. In the **Second destination address** field, enter a website address or IP address to which the router will send the second round of ping requests.
4. In the **Periodic Ping timer** field, enter a number between 300 and 65535 for the number of seconds the router should wait between ping attempts. Setting this to 0 disables the ping watchdog function.
5. In the **Retry timer** field, enter a number between 60 and 65535 for the number of seconds the router should wait between retry ping attempts, i.e. pings to the second destination address.

6. In the **Fail count** field, enter an integer between 1 and 65535 for the number of times an accelerated ping should fail before the router reboots. Setting this to 0 disables the ping watchdog function.
7. Select the **Save** button to save the configuration.

Disabling the ping watchdog

To disable the ping watchdog by setting the **Periodic Ping Enable** toggle to Off, then select the **Save** button.

Periodic reboot

The router can be configured to automatically reboot after a period of time specified in minutes. While this is not necessary, it does ensure that in the case of remote installations, the router will reboot if some anomaly occurs.

1. In the **Force reboot every** field, enter the time in minutes between forced reboots. The default value is 0 which disables the Periodic reboot function. The minimum period between reboots is 5 minutes while the maximum value is 65535 minutes.
2. If you have configured a forced reboot time, you can use the **Randomise reboot time** drop-down list to select a random reboot timer. Randomising the reboot time is useful for preventing a large number of devices from rebooting simultaneously and flooding the network with connection attempts. When configured, the router waits for the configured Force reboot every time and then randomly selects a time that is less than or equal to the Randomise reboot time setting. After that randomly selected time has elapsed, the router reboots.



Important: *The randomise reboot time is not persistent across reboots; each time the router is due to reboot, it randomly selects a time less than or equal to the Randomise reboot time.*

3. Select the **Save** button to save the settings.

System configuration

Restore factory defaults

Restoring factory defaults will reset the NTC-500 Series router to its factory default configuration. You may encounter a situation where you need to restore the factory defaults on your NTC-500 Series router. There are three levels of factory reset:

- Installer reset
- Carrier reset
- Full factory reset

The availability of the above levels depends on your [Runtime Configuration](#) settings.

Installer reset

The installer reset only resets settings that have changed after the NTC-500 Series router was installed. The settings that are included are those that were likely changed through the web interface. This reset level is generally the first one that should be attempted, as it will reset less important configurations.

Carrier reset

The carrier reset will reset the device with the carrier-defined default settings to operate on the network. This also resets the user-configured options to their default settings. This reset should be attempted after trying the installer reset.

Full factory reset


The full factory reset is generally used for refurbishment or to remove an erroneous configuration. This will remove all settings including the carrier settings that are required for the device to operate on the network. All configurations and settings are completely removed.



Important: The full factory reset will require the NTC-500 Series router to be completely reconfigured.

To complete a reset at any level

1. On the **Restore Factory Defaults** page, select the **Clear HTTPS certificate** checkbox if you want to clear the HTTPS certificate.
2. Select the appropriate reset level.
3. You will be prompted to confirm. Select the **Ok** button to proceed with the reset.



4. Wait for the router to reset and reboot, then access the device through the web interface at **https://192.168.1.1**

Web server setting

You can configure whether the NTC-500's web server uses HTTP or HTTPS and the server port. Additionally, you can generate a web server certificate by entering data in all the fields under the **Generate web server certificate** section.

Figure 10-6 Web server setting configuration

WEB SERVER SETTING

HTTPS

OnOff

HTTP

OnOff

Redirect HTTP to HTTPS

OnOff

Save

WEB SERVER CERTIFICATE

Certificate serial number06FF3B256DB90352FD7BE41A59002A9A651601E8

Not before

Apr 4 05:29:40 2023 GMT

Not after

Jul 7 05:29:40 2025 GMT

Server key size

2048

Country

AU

State

NSW

City

Lane Cove

Organization

Casa Systems

Generate server certificate

Generate

UPLOAD WEB SERVER CERTIFICATE

Alternatively, please provide a web server certificate in a .zip file that contains the certificate and key file.

Choose a file

Administration settings

The Administration settings page allows for updating administration credentials and Web UI login limits.

Web UI credentials

Use this section to configure the username and password used to access the NTC-500 Series router via the web interface. Enter the current password used to access the Web UI, then enter a new password. Select the **Save** button to confirm the changes.

Figure 10-7 Administration settings – Web UI credentials configuration

WEB UI CREDENTIALS

Username admin

Current password 

New password  

Confirm new password 

Web UI logon limits

The Web UI login limit section allows configuration of the timeout and lock of the web interface. It is designed to improve security by reducing the risk of brute force attacks on the web interface.

Figure 10-8 Administration settings – Web UI login limit configuration

WEB UI LOGIN LIMIT

Incorrect login attempt limit (3-5)

Login lock duration (1-10 minutes)

IP login attempt limit (5-8)

LAN IP address lock duration (5-10 minutes)

WAN IP address lock duration (10-20 minutes)

Session timeout (5-60 minutes)

Table 10-5 WebUI login limits

Item	Description
Incorrect login attempt limit	The number of times an incorrect password can be entered into the web interface before it locks out any further attempts
Login lock duration	The amount of time the login lock lasts
IP login attempt limit	The number of logins that can be attempted from one IP before any further attempts are locked out

Item	Description
LAN IP address lock duration	The amount of time an IP attempting to log in from the LAN is forbidden from trying to login
WAN IP address lock duration	The amount of time an IP attempting to log in from the WAN is forbidden from trying to login
Session timeout	The amount of time in minutes that a logged in session lasts on the web interface. The web interface will log the current user out after the configured time.

SSH credentials

Use this section to configure the username and password used to access the NTC-500 Series router via SSH.

Figure 10-9 Administration – Administrator credentials configuration

SSH CREDENTIALS

Username root

Current password 

New password  

Confirm new password 

Settings backup/restore

The settings backup and restore page is used to backup or restore the router's configuration or to reset it to factory defaults. In order to view the settings page, you must be logged into the web user interface as root using the password admin. The backup / restore functions can be used to easily configure a large number of NTC-500 Series routers by configuring one router with your desired settings, backing them up to a file and then restoring that file to multiple NTC-500 Series routers.

To access the Settings backup and restore page, select on the **System menu** item then select **the System configuration** menu on the left and finally select **Settings backup/restore** beneath it.

Figure 10-10 System configuration - Backup and restore

SETTINGS BACKUP AND RESTORE

SAVE A COPY OF CURRENT SETTINGS

Password  

confirm password 

Save

RESTORE SAVED SETTINGS

Select file to upload  Not uploaded

Password 

Restore

Creating a settings backup

To create a settings backup, under the **Save a copy of current settings** section select the **Save** button. The configuration will download. If you wish to protect the configuration with a password, enter a password into the **Password** and **Confirm password** fields, then press **Save**.

Restoring a settings backup

To restore a settings backup, under the **Restore saved settings** section, select **Choose a file**, then locate the saved configuration. If the file was saved with a password, enter the password, then select **Restore**. You will be prompted to confirm, select **OK** to proceed. The device will reboot with the saved settings.

Figure 10-11 Systems configuration – Restoring a settings backup confirmation

It may take a few minutes to restore settings and reboot your device. Are you sure you want to continue?

OK Cancel

Site and location settings

The Site settings feature allows you to add a name that appears on the Status page in the System information section. This can be useful for identifying the particular device you are using when you have a fleet of them in various locations.

Figure 10-12 System configuration – Site and location settings

Update the site name and location by entering the information in the fields, then pressing **Save**.

Runtime configuration

Runtime Configuration can be used to load a configuration file containing carrier-specific settings such as default settings, MBN changes which are not available via the web user interface. It is used for late binding of carrier configurations at the time of installation.

Figure 10-13 System configuration – Runtime configuration upload

To apply runtime configuration:

1. Select the **Choose a file** button and locate the configuration file.
2. Select the file. The word **Uploaded** appears next to the button.
3. Select the **Apply** button to install the configuration file.
4. The device automatically reboots after successful upload of the configuration file.

SSH key management

Secure Shell (SSH) is UNIX-based command interface and network protocol used to gain secure access to a remote computer, execute commands on a remote machine or to transfer files between machines.

SSH uses RSA public key cryptography for both connection and authentication. Two common ways of using SSH are:

- Use automatically generated public-private key pairs to encrypt the network connection and then use password authentication to log on.

- Use a manually generated public-private key pair to perform the authentication and allow users or programs to log in without using a password.

To access the SSH key management page, select the **System** menu then the **System configuration** menu on the left and then select on **SSH key management**.

Figure 10-14 System configuration – SSH server configuration

SSH SERVER CONFIGURATION

SSH SERVER SETTINGS

SSH Protocol

Protocol 2

Password Authentication enable

On

Off

Key Authentication enable

On

Off

Save

HOST KEY MANAGEMENT

Key type	Date
ssh_host_dsa_key	2024-02-12 17:50:01
ssh_host_rsa_key	2024-02-15 10:16:38
ssh_host_ecdsa_key	2024-02-15 10:16:38
ssh_host_ed25519_key	2024-02-15 10:16:38

Generate keys

Get keys

Get public keys

Upload keys

CLIENT KEY MANAGEMENT

Username	Hostname	Key type	Delete

Clear

Upload

SSH Server Configuration

To configure the SSH server settings:

1. Use the **SSH Protocol** drop-down list to select the protocol that you want to use. Protocol 2 is more recent and is considered more secure.
2. Select the type of authentication you want to use by turning the **Enable password** authentication and **Enable key authentication** toggle keys on or off. Note that you may have both authentication methods on, but you may not turn them both off.
3. Select the **Save** button to confirm your settings.

Host key management

The **host key management** section allows you to manage the SSH keys on the NTC-500 Series router.

Figure 10-15 System configuration – SSH server configuration – Host key management

HOST KEY MANAGEMENT	
Key type	Date
ssh_host_dsa_key	2024-02-27 10:17:16
ssh_host_rsa_key	2024-02-27 10:17:32
ssh_host_ecdsa_key	2024-02-27 10:17:32
ssh_host_ed25519_key	2024-02-27 10:17:32
Generate keys Get keys Get public keys Upload keys	

Select the **Generate Keys** button to generate new keys. Use caution when selecting the **Generate Keys** button, as this invalidates any previously generated keys.

Select the **Get Keys** button to download the generated private and public keys. You will be asked to enter a password for the keys file.

Figure 10-16 System configuration – SSH server configuration – Host key management – Password

Enter the password for the keys file

Password

confirm password

Enter an appropriate password and select the **OK** button to download the keys file.

Select the **Get Public Keys** button to download just the public keys.

Select the **Upload keys** button to upload a keys file. You will be prompted to enter the password created in the **Get Keys** step to upload the file. The keys will replace the previously generated keys.

Client key management

The Client key management page allows you to upload client keys to the NTC-500 Series router, allowing key based SSH access to the NTC-500 Series router. Select the **Upload** button to upload the public key of your SSH client. The key appears in **Client key management** window. Select the cross in the **Delete** column to remove the key.

Figure 10-17 System configuration – SSH server configuration – Host key management – Password

CLIENT KEY MANAGEMENT			
Username	Hostname	Key type	Delete
root		rsa2	

Clear
Upload

LED operation mode

Use the **LED operation mode** page to control the operation of the LED indicator lights on the NTC-500 Series router. There are two modes available, **Always on** and **Turn off after timeout**. Setting the mode to **Always on** sets the indicator LEDs to be lit when the device is on. Setting the mode to **Turn off after timeout** sets the indicator LEDs to turn off after the timer has expired.

Figure 10-18 LED operation mode

LED OPERATION MODE

LED OPERATION MODE SETTING

Mode Turn off after timeout

LED power off timer (1-65535 minutes)

Save

Setting the LED operation mode

To set the LED operation mode:

1. Use the **Mode** dropdown to set the mode to be configured.
2. If using the **Turn off after timeout** mode, set the LED power off timer to the number of **minutes** that the indicator LEDs should be lit after the device has started.
3. Select the **Save** button to apply the configuration.

A/B system configuration

The A/B system configuration page allows you to switch between an active and previous firmware. Switching between firmware allows you to restore a previous firmware for troubleshooting in the event of an issue with the current firmware. Restoring a previous firmware should only be used for troubleshooting.

Figure 10-19 A/B System configuration

A/B SYSTEM CONFIGURATION			
CURRENT STATUS			
Bank	Firmware version	Module firmware version	Status
A	1.2.12.0		Standby
B	1.2.15.0		Active
<button>Switch active bank</button>			

To switch the active bank, select the **Switch active bank** button. You will be prompted to accept the following message:

Figure 10-20 A/B System configuration - Confirmation

Switching active banks will cause the device to reboot, breaking communications temporarily while the device reboots. Switching to a bank with older firmware should only be done for the purposes of troubleshooting and can result in loss of remote access. Please use it with caution. Are you sure you want to switch to the standby bank?

OK Cancel

To proceed select the **OK** button. Once the reboot is complete, the previous firmware will be restored. To switch active banks again, return to this screen and select the **Switch active bank** button.

Firmware upgrade

To access the **Firmware upgrade** page, select the **System** menu, then **Firmware upgrade**.

The **Firmware upgrade** page allows you to upload firmware files to update the NTC-500 Series router. The firmware upgrade will be applied to the **Standby** bank, to ensure the current firmware can be restored in the event of an issue.

Figure 10-21 File uploads

The screenshot shows the 'FIRMWARE UPGRADE' page. It contains a table with the following data:

Bank	Firmware version	Module firmware version	Status
A	1.2.12.0		Standby
B	1.2.15.0		Active

Below the table, there is a section titled 'UPGRADE FIRMWARE'. It includes a 'Select firmware to upload' label, a 'Choose a file' button, and a 'Not uploaded' status. There is also a 'Reset to default config' toggle switch set to 'Off'. A message states: 'The system must be rebooted to complete the firmware upgrade. Please choose when you would like the reboot to occur.' Below this, there is a 'Reboot' dropdown menu set to 'Immediately' and an 'Upgrade' button.

Updating the router firmware

The firmware update process involves first uploading the recovery image firmware and then updating the main firmware image.

To update the NTC-500 Series router's firmware:

1. Power on the router as described in the Installing the router section.
2. Log in to the router with the root user account (See the Advanced configuration section for details)
3. Select the **System** item from the top menu bar, then select the **Firmware upgrade** menu item.
4. Under the **Select firmware to upload** section, select the **Choose a file** button. Locate the firmware image file on your computer and select **Open**.
5. If required set the **Reset to default config** toggle to **On** to reset the NTC-500 Series router to the default configuration.
6. Select the **Upgrade** button to upgrade the firmware.

Access control

The Access control pages are used to configure the remote and local access to the router.

 **Note:** All remote access to the router is disabled by default.

Figure 10-22 Access control configuration

ACCESS CONTROL

REMOTE ACCESS CONTROL

HTTP enable
On Off

HTTP port
8080
1-65535

HTTPS enable
On Off
[Update server certificate if necessary](#)

HTTPS port
443
1-65535

HTTPS source IP allow list

Comma-separated list of unicast IP addresses and/or network IP addresses (with /mask where mask is a plain number). If it is blank, all IP addresses are permitted.

SSH enable
On Off

SSH port
22
1-65535

Ping enable
On Off

LOCAL ACCESS CONTROL

HTTP enable
On Off

HTTPS enable
On Off

SSH enable
On Off

Save

Table 10-6 Access control configuration items

Option	Definition
Remote Access Control	
HTTP enable	Enable or disable remote HTTP access to the router.
HTTP port	When HTTP is enabled (see previous) you can set the HTTP management port. Enter a port number between 1 and 65534 to use when accessing the router remotely.
HTTPS enable	Enable or disable remote HTTPS access to the router using a secure connection.
HTTPS port	When HTTPS is enabled you can set the HTTPS remote access port. Enter a port number between 1 and 65534 to use when accessing the router remotely over a secure HTTPS connection.
HTTPS source IP allow list	When HTTPS is enabled (see Enable HTTPS above) you can enter a 'whitelist' of IP addresses that will be permitted to access the router. Enter a list of comma-separated unicast IP addresses. You may also enter IP addresses in CIDR notation; however, no spaces are permitted.

Option	Definition
	Note that if this field is left blank, all IP addresses will be permitted to access the router.
SSH enable	Enable or disable Secure Shell on the router.
SSH port	When SSH is enabled you can set the remote SSH access port. Enter the port number for remote SSH access. The port number must be between 1 and 65534.
Ping enable	Enable or disable remote ping responses on the WWAN connection.
Local Access Control	
HTTP enable	Enable or disable local HTTP access to the router. The default setting is disabled.
HTTPS enable	Enable or disable local secure HTTP access (https). The default setting is enabled.
SSH enable	Enable or disable local Secure Shell on the router. The default setting is enabled.
Save button	Select the Save button to save the configuration.


Reboot

The Reboot option in the System section performs a soft reboot of the device. This can be useful if you have made configuration changes you want to implement.

To reboot the NTC-500 Series router:

1. Select the System menu item from the top menu bar.

Figure 10-23 Reboot



2. Select the Reboot button from the menu on the left side of the screen.
3. The NTC-500 Series router displays a warning that you are about to perform a reboot.
4. If you wish to proceed, select the Reboot button.
5. A warning popup will advise that “It may take a few minutes to reboot your device. Are you sure you want to continue?”
6. Select OK to continue with the reboot process.

Field test

The Field test page contains LTE, LTE SCELL and NR5G cell information which may be useful when troubleshooting signal strength issues. This screen can be found by navigating to System > Field test.

Figure 10-24 Field Test

FIELD TEST

LTE PCELL INFORMATION

PCI	EARFCN	Band	Bandwidth
409	3148	7	20MHz

LTE SCELL INFORMATION

CC ID	PCI	EARFCN	Band	Bandwidth	UL configured	State
-------	-----	--------	------	-----------	---------------	-------

5G NR SERVING CELL INFORMATION

CC ID	Cell ID	DL ARFCN	UL ARFCN	Band	Band type	DL BW	UL BW	DL max MIMO	UL max MIMO
7	188	176500	167500	5	SUB6	5MHz	5MHz	2	1
8	188	640332	13107	78	SUB6	60MHz	5MHz	4	1

Table 10-7 LTE PCELL Information

LTE PCELL Information	
PCI	Physical Cell ID of the LTE Cell.
EARFCN	E-UTRA Absolute Radio Frequency Channel Number. Uniquely identifies the LTE Band and carrier frequency.
Band	The current LTE band.
Bandwidth	The current LTE bandwidth.

Table 10-8 LTE SCELL Information

LTE SCELL Information	
CC ID	Component Carrier ID.
PCI	Physical Cell ID of the LTE Cell.
EARFCN	E-UTRA Absolute Radio Frequency Channel Number. Uniquely identifies the LTE Band and carrier frequency.
Band	The current LTE band.
Bandwidth	The current LTE bandwidth.
UL Configured	If the Up Link is configured.

LTE SCELL Information	
State	The current state of the LTE SCELL.

Table 10-9 NR5G Serving cell information

5G NR Serving Cell Information	
CC ID	Component Carrier ID.
Cell ID	The physical cell identifier.
DL ARFCN	Downlink Absolute Radio Frequency Channel Number.
UL ARFCN	Uplink Absolute Radio Frequency Channel Number.
Band	The NR5G band.
Band Type	The type of the NR5G band, e.g. Sub6 or mmWave.
DL BW	Downlink bandwidth.
UL BW	Uplink bandwidth.
DL max MIMO	Downlink maximum Multiple Input Multiple Output.
UL max MIMO	Uplink maximum Multiple Input Multiple Output.

Encrypted debuginfo

The Encrypted Debug Information page contains NR5G cell information which may be useful when troubleshooting signal strength issues.

Select the **Generate** button to force the NTC-500 Series router to create a debug file. A success message will appear when the debug file generation is complete. Select the **Download** button to download the generated file.

Figure 10-25 Encrypted debuginfo download



Appendix A. Configuring Radio Access Technologies

This device supports the following modes of operations in various combinations.

- **LTE** (3GPP Core Network Option 1)
- **5G Non Standalone** (3GPP Core Network Option 3x)
- **5G Standalone** (3GPP Core Network Option 2)

Please refer to the following table to understand which modes of operation are possible and how to configure them.

Table A-1 RAT/Band Selection table

Mode	Allowed RAT			Supported	How to Configure	
	LTE	5G NSA	5G SA		RAT Selection Menu	Band Selection Menu
LTE Only	Yes	No	No	Yes	Select LTE only	Select LTE Frequency Bands
LTE + 5G NSA	Yes	Yes	No	Yes	Select LTE + 5G NR	Select LTE + NSA Frequency Bands
5G NSA Only	No	Yes	No	No	–	–
LTE + 5G NSA + 5G SA	Yes	Yes	Yes	Yes	Select LTE + 5G NR	Select LTE + NSA + SA Frequency Bands
LTE + 5G SA	Yes	No	Yes	No	–	–
5G NSA + 5G SA	No	Yes	Yes	No	–	–
5G SA Only	No	No	Yes	Yes	Select 5G NR	Select SA Frequency Bands

Use this table in conjunction with the settings described in sections **6.2.1.3 RAT selection** and **6.2.1.2 Band selection** of this guide.

 **Note:** 5G Standalone Mode is not supported when utilising mmWave frequency bands.

Appendix B. NetComm Document History

Table B-1 NetComm Document History

Ver.	Document description	Date
v1.00	Initial document release based on firmware version 1.1.74.0	12 October 2023
v1.01	Updated for firmware version 1.1.88.0. New features include OpenVPN, GRE Tunnelling, RIP, VRRP Redundancy, minor webUI updates. Updated naming of device. Updated document theme.	20 December 2023
v1.02	Updated for firmware version 1.2.2.1. MQTT added as a new feature.	15 February 2024
V2.00	Updated for firmware version 1.2.15.0. New WebUI with NetComm branding. Document images updated throughout to match WebUI changes. Updated sections on Network Slicing, A/B configuration, Administration Settings.	March 2024

Appendix C. Compliance Information

(According to ISO/IEC Guide and EN 45014)

Manufacturer's Name & Address:

Lantronix, Inc. 48 Discovery, Suite 250, Irvine, CA 92618 USA

Product Family:

NTC-500 Series

Conforms to the following standards or other normative documents:

Country	Specification
USA	Contains FCC ID: XMR2022RG520NNA
Canada	Contains IC: 10224A-2022RG520NA
EU	See EU Declaration of Conformity – pending completion
United Kingdom	See UK Declaration of Conformity – pending completion
Safety	EN IEC 62368-1 AS/NZS 62368-1