



NTC-140 Series User Guide

4G M2M Router

NTC-140-01

NTC-140-02

Part Number PMD-00324
Revision A September 2025

Trademark Notice

This product may reference NetComm. On December 26, 2024, Lantronix, Inc. acquired the Industrial Internet of Things (IIoT) product portfolio from NetComm Wireless Pty Ltd and is authorized to use the NetComm trademark in association with this product.

Intellectual Property

© 2025 Lantronix, Inc. All rights reserved. No part of the contents of this publication may be transmitted or reproduced in any form or by any means without the written permission of Lantronix.

Lantronix is a registered trademark of Lantronix, Inc. in the United States and other countries.

Patented: <https://www.lantronix.com/legal/patents/>. Additional patents pending.

Warranty

For details on the Lantronix warranty policy, please go to our web site at <https://www.lantronix.com/support/warranty/>.

Contacts

Lantronix, Inc.
48 Discovery, Suite 250
Irvine, CA 92618, USA
Toll Free: 800-526-8766
Phone: 949-453-3990
Fax: 949-453-3995

Technical Support

Online: www.lantronix.com/technical-support/

Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix website at <https://www.lantronix.com/about-us/contact/>.

Disclaimer

All information contained herein is provided “AS IS.” Lantronix undertakes no obligation to update the information in this publication. Lantronix does not make, and specifically disclaims, all warranties of any kind (express, implied or otherwise) regarding title, non-infringement, fitness, quality, accuracy, completeness, usefulness, suitability or performance of the information provided herein. Lantronix shall have no liability whatsoever to any user for any damages, losses and causes of action (whether in contract or in tort or otherwise) in connection with the user’s access or usage of any of the information or content contained herein. The information and specifications contained in this document are subject to change without notice.

Important Notice

This device, like any wireless device, operates using radio signals which cannot guarantee the transmission and reception of data in all conditions. While the delay or loss of signal is rare, you should not rely solely on any wireless device for emergency communications or otherwise use the device in situations where the interruption of data connectivity could lead to death, personal injury, property damage, data loss, or other loss. Lantronix accepts no responsibility for any loss or damage resulting from errors or delays in transmission or reception, or the failure of the Lantronix NTC-140 Series to transmit or receive such data.

Safety and Hazards



Warning: Do not connect or disconnect cables or devices to or from the USB port, SIM card tray, Ethernet port or the terminals of the Molex power connector in hazardous locations such as those in which flammable gases or vapours may be present, but normally are confined within closed systems; are prevented from accumulating by adequate ventilation; or the location is adjacent to a location from which ignitable concentrations might occasionally be communicated.

Save our Environment

When this equipment has reached the end of its useful life, it must be taken to a recycling centre and processed separately from domestic waste.

The cardboard box, the plastic contained in the packaging, and the parts that make up this device can be recycled in accordance with regionally established regulations. Never dispose of this electronic equipment along with domestic waste. You may be subject to penalties or sanctions under the law. Instead, ask for disposal instructions from your municipal government.

Please be responsible and protect our environment.

Revision History

Date	Rev.	Comments
September 2025	A	Reformatted to Lantronix For prior document history, see Appendix H. NetComm Revision History

For the latest revision of this product document, please check our online documentation at <https://www.lantronix.com/support/documentation/>.

Contents

1. Overview	11
Introduction	11
Target audience	11
Prerequisites	11
Notation	11
2. Product introduction	12
Product overview	12
Product features	12
Package contents	12
Ordering Information	12
3. Physical dimensions and indicators	13
Physical dimensions	13
LED indicators	14
Signal strength LEDs	15
LED update interval	16
Ethernet port LED indicators	16
Interfaces	17
4. Placement of the router	19
Mounting options	19
Mounted flat against the wall	19
DIN rail mounting bracket	19
Wall mounted via DIN rail bracket	20
DIN rail mount	20
Pole mount using DIN rail bracket	21
Desk mount	21
5. Installation and configuration of the NTC-140 Series router	22
Powering the router	22
Installing the router	22
6. Advanced configuration	23
7. Status	24
8. Networking	28
Wireless WAN	28
Data connection	28

SIM management	36
Band settings	36
Operator settings.....	37
SIM security settings.....	37
LAN	41
LAN configuration.....	41
DHCP	42
Ethernet LAN/WAN.....	45
Ethernet group	45
Ethernet WAN	46
PPPoE	47
WAN failover.....	48
Routing	51
Static.....	51
RIP.....	54
Redundancy (VRRP) configuration.....	54
Port forwarding	55
DMZ	56
Router firewall.....	57
MAC / IP / Port filtering.....	57
Creating a MAC / IP / Port filtering rule	58
VPN.....	60
IPSec	60
Configuring an IPSec VPN	60
OpenVPN	63
Configuring an Open VPN server.....	63
OpenVPN Server	64
Configuring an OpenVPN Client	67
Certificate Authentication	68
Configuring an OpenVPN P2P Connection	68
PPTP client	70
GRE tunnelling.....	71
9. Services	74
Dynamic DNS	74
Network time (NTP)	75

Configuring Timezone settings.....	75
Configuring NTP settings	75
Data stream manager	76
Endpoints.....	76
Streams.....	82
Data stream applications.....	84
PADD.....	86
Remote management	88
SNMP	88
TR-069.....	90
OMA Lightweight M2M configuration.....	91
GPS	94
NMEA support.....	94
GPS configuration.....	94
Odometer	95
IO configuration.....	96
Event notification	98
Notification configuration	99
Destination configuration	102
Email settings.....	103
SMS messaging.....	104
Setup.....	104
SMS forwarding configuration.....	106
Redirect to mobile	106
Redirect to TCP / UDP server address	106
New message.....	106
Inbox / Sent Items	107
Diagnostics.....	108
SMS diagnostics and command execution configuration.....	109
White List for diagnostic or execution SMS	111
Sending an SMS Diagnostic Command	112
Types of SMS diagnostic commands.....	112
SMS acknowledgment replies	112
SMS command format.....	112
List of basic commands.....	114

List of get/set commands	115
List of basic RDB variables	118
Network scan and manual network selection by SMS.....	120
SMS diagnostics examples.....	122
10. System	126
Log	126
System log.....	126
IPSec log.....	126
Event notification log	127
System log settings	127
System Configuration	129
Settings backup and restore	129
Upload	130
Updating the Firmware.....	131
Package manager.....	132
Administration	132
Administration settings	132
Server certificate.....	135
SSH key management	140
LED operation mode.....	142
Watchdogs.....	143
Configuring Periodic Ping settings.....	144
Disabling the Periodic Ping reset function	145
Configuring a Periodic reboot.....	145
Power management.....	145
Sleep settings.....	146
Wake settings	147
USB-OTG	148
Storage.....	148
Storage device list	148
Network Samba storage settings	149
Reboot	150
Logging out	151
11. Safety and product care.....	152
Electrical safety.....	152

Accessories	152
Connection to a car	152
Distraction	152
Driving	152
Product handling	152
Small children	153
Demagnetisation	153
Electrostatic discharge (ESD)	153
Air Bags	153
Emergency & other situations requiring continuous connectivity	153
Device heating	153
Faulty and Damaged Products	154
Interference	154
Pacemakers	154
Hearing aids	154
Medical devices	154
Hospitals	154
Aircraft	154
Interference in cars	154
Explosive environments	154
Petrol stations and explosive atmospheres	154
12. Compliance	156
RF Exposure	156
Déclaration d'exposition aux radiations:	156
External antenna	157
CE Approval	157
FCC Statement	158
FCC compliance	158
FCC regulations	158
IC regulations	158
CAN ICES-3(B)/NMB-3(B)	158
IMPORTANT NOTE:	159
Appendix A. Default Settings	160
Restoring factory default settings	160
Using the web-based user interface	161

Using the reset button on the interface panel of the router	161
Appendix B. Recovery mode.....	162
Accessing recovery mode.....	162
Status.....	162
Log	163
Application Installer	164
Settings	164
Reboot	164
Appendix C. HTTPS – Uploading a self-signed certificate	165
Appendix D. RJ-45 connectors	167
Appendix E. Input/Output.....	168
Overview.....	168
Hardware Interface	168
Wiring Examples	169
Open Collector Output driving a relay.....	169
Logic level Output	169
LED Output	169
NAMUR Sensor	170
Analogue Sensor with Voltage output.....	171
Analogue Sensor with 4 to 20mA output.....	171
Analogue Sensor with Thermistor	172
System Example –Solar powered Router with battery backup	172
Appendix F. Obtaining a list of RDB variables	173
Appendix G. Using USB devices and MicroSD™ cards	174
Accessing USB/SD card storage devices	174
Host and Device mode	174
Appendix H. NetComm Revision History	175

1. Overview

Introduction

This document provides you all the information you need to set up, configure and use the Lantronix NTC-140 Series router.

Target audience

This document is intended for system integrators or experienced hardware installers who understand telecommunications terminology and concepts.

Prerequisites

An electronic computing device with a working Ethernet network adapter and a web browser such as Internet Explorer®, Mozilla Firefox® or Google Chrome™.

Notation

The following symbols are used in this user guide:

	Note: <i>The following note provides useful information.</i>
	Important: <i>The following note requires attention.</i>
	Warning: <i>The following note provides a warning.</i>

2. Product introduction

Product overview

- Powerful and flexible industrial cellular router platform supporting LTE with fallback to 3G/UMTS and GSM/GPRS/EDGE (Fallback only applies to certain models)
- Ideal for providing primary and backup wireless connectivity over LTE networks
- Industrial Features – rugged enclosure, wide operating temperature range, wall mount option and a flexible range of power options
- Embedded Linux operating system allowing for the installation of custom applications. Software Development Kit (SDK) is available
- Web interface for easy centralized configuration and management from any PC
- Two 10/100/1000 Base T ports for Ethernet connection
- VPN support for establishing a secure connection over public cellular network using OpenVPN
- Supports SNMP with cellular specific MIB, PPPoE, RIP, VRRP. DDNS, MAC /NET address filtering, Open VPN, DHCP/DHCP relay
- System monitoring, remote diagnostics and configuration over the air, diagnostic log viewer via browser
- Integrated GPS support
- TR-069 device management (optional)
- Ignition Sense capability for graceful shutdown and startup in vehicle applications
- Configurable power save mode with minimum current draw when not operational
- Tested for vehicular applications IEC Class 5M2 and MIL-STD-810F Method 516.5

Product features

The robust and intelligent Lantronix NTC-140 Series 4G M2M Router is designed to provide real-time M2M data connectivity even in harsh environments. The NTC-140 Series router creates reliable point-to-point or point-to-multi-point wide area network (WAN) connections for a variety of mission critical applications such as primary broadband, video surveillance, retail payments and business continuity.

Package contents

The Lantronix NTC-140 Series router package consists of:

- 1 x Lantronix NTC-140 Series router
- 2 x Cellular antennas
- 1 x 1.5m Black Ethernet cable
- 1 x DIN rail mounting bracket
- 1 x Power supply cable (2 metres) with fitted Molex connector

If any of these items are missing or damaged, please contact Lantronix Support immediately at www.lantronix.com/technical-support/.

Ordering Information

Model	Lantronix Part Number	Description
NTC-140	NTC-140-02	4G M2M for EMEA, AU & Singapore

3. Physical dimensions and indicators

Physical dimensions

Below is a list of the physical dimensions of the NTC-140 Series router.

Figure 3-1 NTC-140 Series Router Dimensions



Table 3-1 Device Dimensions

NTC-140 Series ROUTER (WITHOUT EXTERNAL ANTENNAS ATTACHED)	
Length	143 mm
Depth	107 mm
Height	34 mm
Weight	~235g

LED indicators

The NTC-140 Series router uses LEDs to display the current system and connection status.

Figure 3-2 NTC-140 Series Router LED Indicators




Table 3-2 LED Indicators

LED ICON	NAME	COLOUR	STATE	DESCRIPTION
	Power		Off	Power off
			Double flash	Powering up
			On	Power on
			On	Power on in recovery mode
			Slow flashing	Hardware error, such as SIM not inserted
	GPS/Customizable LED		Off	GPS function disabled
			Slow flashing	GPS function is enabled but no satellite detected.
			On	Satellite detected, location acquired.
			Off	Radio Off
			On	Connected via WWAN
			Blinking ¹	Traffic via WWAN
			Slow flashing	Connecting PDP
			On	Registered network

LED ICON	NAME	COLOUR	STATE	DESCRIPTION
	Network		Slow flashing	Registering network
			Slow flashing	SIM PIN locked
			Fast flashing	SIM PUK locked
			On	Can't connect
	Signal strength		On	LTE signal
			On	WCDMA signal
			On	GSM signal

¹ The term “blinking” means that the LED may pulse, with the intervals that the LED is on and off not being equal. The term “flashing” means that the LED turns on and off at equal intervals.

Signal strength LEDs

The following tables list the signal strength range corresponding with the number of lit signal strength LEDs.

LTE signal mapping (green)

Table 3-3 LTE Signal Strength LED Descriptions

NUMBER OF LIT LEDs	SIGNAL STRENGTH
All LEDs unlit	No signal
1	-115 dBm to -119dBm
2	-105 dBm to -114 dBm
3	-100 dBm to -104 dBm
4	-90 dBm to -99 dBm
5	> -90 dBm

WCDMA signal mapping (amber)

Table 3-4 WCDMA Signal Strength LED Descriptions

NUMBER OF LIT LEDs	SIGNAL STRENGTH
All LEDs unlit	< -109 dBm
1	-109 dBm to -102dBm
2	-101 dBm to -92 dBm
3	-91 dBm to -86 dBm
4	-85 dBm to -78 dBm
5	≥ -77 dBm

GSM signal mapping (red)

Table 3-5 GSM Signal Strength LED Descriptions

NUMBER OF LIT LEDs	SIGNAL STRENGTH
All LEDs unlit	≤ -109 dBm
1	-102 dBm to -108dBm
2	-93 dBm to -101 dBm
3	-87 dBm to -92 dBm
4	-86 dBm to -78 dBm
5	-78 dBm


LED update interval

The signal strength LEDs update within a few seconds with a rolling average signal strength reading. When selecting a location for the router or connected or positioning an external antenna, please allow up to 20 seconds for the signal strength LEDs to update before repositioning.

Ethernet port LED indicators

Each of the Ethernet ports of the NTC-140 Series router have two LED indicators on them.

Figure 3-3 Ethernet port LED Indicators



The table below describes the statuses of each light and their meanings.

Table 3-6 Ethernet Port LED Indicators Description

LED	STATUS	DESCRIPTION
Green	On	There is a valid network link.
	Blinking	There is activity on the network link.
	Off	No valid network link detected.
Amber	On	The Ethernet port is at a speed of 1000 Mbps.
	Off	The Ethernet port is operating at a speed of 10/100 Mbps, or no Ethernet cable is connected.



Warning: Do not connect or disconnect cables or devices to or from the Ethernet ports in hazardous locations such as those in which flammable gases or vapours may be present but normally are confined within closed systems; are prevented from accumulating by adequate ventilation; or the location is adjacent to a location from which ignitable concentrations might occasionally be communicated.

Interfaces

Figure 3-4 Interfaces




Table 3-7 Interfaces

NO.	ITEM	DESCRIPTION
1	Cellular Main antenna connector	SMA connector for main cellular antenna.
2	GPS antenna connector	SMA connector for GPS antenna (not included in package).
3	Cellular AUX antenna connector	SMA connector for auxiliary cellular antenna.
4	microSD™ card slot	Insert a microSD™ card here to provide additional storage (Optional).
5	SIM card slot	Insert SIM card here.
6	SIM tray eject button	Press to eject the SIM tray
7	Micro USB 2.0 OTG port	Provides connectivity for optional external storage or a USB Ethernet dongle. Supplies up to 0.5A to connected device.
8	Reset button	Press and hold for less than 5 seconds to reboot to normal mode. The LEDs are green and extinguish in sequence to indicate that the router will reboot normally if the button is released during this period. Press and hold for 5 to 15 seconds to reboot to recovery mode. The LEDs are amber and extinguish in sequence to indicate that the router will reboot to recovery mode if the button is released during this period. Press and hold for 15 to 20 seconds to reset the router to factory default settings. The LEDs are red and extinguish in sequence to indicate that the router will reset to factory default settings if the button is released during this period.
9	Molex Mini-Fit™ Jr. 2 x 2 receptacle	Connect the provided power supply here. The Molex receptacle provides: Ground (-) Power (+) I/O terminal (i) ignition input detection terminal.
10	LAN port	LAN port for wired Ethernet clients.
11	LAN/WAN port	LAN or WAN port for wired Ethernet clients or to bridge another network connection.

4. Placement of the router

The four external high-performance antennas supplied with the router are designed to provide optimum signal strength in a wide range of environments. If you find the signal strength is weak, try adjusting the orientation of the antennas. If you are unable to get an acceptable signal, try moving the router to a different place or mounting it differently.



Note: When selecting a location for the router, allow at least 20 seconds for the signal strength LEDs to update before trying a different location.


Mounting options

The NTC-140 Series router can be quickly and easily mounted in a variety of locations.

Mounted flat against the wall

When mounted flat against the wall, the NTC-140 Series router has a slimline form factor. Use appropriately sized screws in the mounting holes provided on the base of the unit.


Figure 4-1 Wall Mount – Flat against the wall



DIN rail mounting bracket


V Bend allows you to snap the DIN bracket onto the middle of a DIN rail rather than sliding it onto the end.

Figure 4-2 DIN rail mounting bracket




Wall mounted via DIN rail bracket

Figure 4-3 Wall mounted DIN rail bracket




DIN rail mount

Figure 4-4 DIN rail mount




Pole mount using DIN rail bracket

Figure 4-5 Pole mount using DIN rail bracket



Desk mount

Figure 4-6 Desk Mount



5. Installation and configuration of the NTC-140 Series router

Powering the router

The NTC-140 Series router may be powered using the included power supply cable with 8-40 V to the Molex connector. A suitable power supply (PSU-0039) is available as an accessory. The diagram below shows the layout of the pins on the Molex connector.

Figure 5-1 Molex Connector




Table 5-1 Locking power block pin outs

TERMINAL	DESCRIPTION
-	Ground wire.
+	Positive wire for power.
i	Dedicated terminal for ignition detection.
I/O	Input/output detection.

Installing the router

Follow these steps to complete the installation process. For a more detailed description, please refer to the Quick Start Guide included in the package contents.

1. Using a paper clip, press the SIM Eject button to eject the SIM card tray. Place the SIM card in the tray and then insert the loaded tray into the SIM slot with the gold side facing up.
2. Attach the cellular antennas to their respective connectors.
3. Connect equipment that requires network access to the LAN port of your router. This may be your computer for advanced configuration purposes, or your end equipment which requires data access via the NTC-140 Series router. You can connect one device directly, or several devices using a network switch.
4. Connect the power source to the router. Wait approximately 2 minutes for your NTC-140 Series router to start up. To check the status of your router, compare the LED indicators on the device with those listed in the [LED indicators](#) section of this guide.



Warning: Do not connect or disconnect cables or devices to or from the USB port, SIM card tray, Ethernet port or the terminals of the Molex power connector in hazardous locations such as those in which flammable gases or vapours may be present, but normally are confined within closed systems; are prevented from accumulating by adequate ventilation; or the location is adjacent to a location from which ignitable concentrations might occasionally be communicated


6. Advanced configuration

The NTC-140 Series router comes with pre-configured settings that should suit most customers. For advanced configuration, log in to the web-based user interface of the router.

To log in to the web-based user interface:

1. Open a web browser (e.g. Internet Explorer®, Mozilla Firefox® or Google Chrome™.™.), type <http://192.168.1.1> into the address bar and press Enter. The web-based user interface log in screen is displayed.

Figure 6-1 Log in prompt for the web-based user interface



2. Enter the login username and password. If this is the first time you are logging in or you have not previously configured the password for the “root” or “admin” accounts, you can use one of the default account details to log in.

Table 6-1 Management account login details – Root manager

ROOT MANAGER ACCOUNT	
Username:	root
Password:	admin

Table 6-2 Management account login details – Admin manager

ADMIN MANAGER ACCOUNT	
Username:	admin
Password:	admin

Note:




- The admin manager account allows you to manage all settings of the router except functions such as firmware upgrade, device configuration backup and restore and reset to factory default settings, which are privileged only to the root manager account.
- For security reasons, we highly recommend that you change the passwords for the root and admin accounts upon initial installation. You can do so by navigating to the System and then Administration page.

The Status page is displayed when you have successfully logged in.

7. Status

The status page of the web interface provides system related information and is displayed when you log in to the NTC-140 Series router management console. The status page shows System information, LAN details, Cellular connection status, Packet data connection status and Advanced status details. You can toggle the sections from view by clicking the  or  buttons to show or hide them. Extra status boxes will appear as additional software features are enabled (e.g. VPN connectivity).

Figure 7-1 NTC-140 Series Status page



The screenshot displays the NTC-140 Series Status page. The top navigation bar includes links for NetCommWireless, Status, Networking, Services, System, and Help. The main content area is divided into several sections:

- System information:**
 - System up time:** 01:44:55 (with a clock icon).
 - Device version:** Hardware version 1.1, Serial number XXXXXXXXXXXXXXX, Firmware version Vx.X.XX.X.
 - Cellular module:** Model MC7304, Module firmware 05.05.26.02, IMEI XXXXXXXXXXXXXXX.
- Cellular connection status:**
 - SIM status:** SIM OK (with a checkmark icon).
 - Signal strength (dBm):** -115 dBm (Low) (with a signal strength icon).
 - Network registration status:** Registered, home network.
 - Operator selection:** Automatic.
 - Current operator:** XXXXXXXX.
 - Roaming status:** Not roaming.
 - Allowed bands:** All Bands.
 - Current band:** LTE Band 3 - 1800Mhz.
 - Coverage:** LTE.
- WWAN connection status:**
 - Profile name:** Profile1 (with a 'Show data usage' button).
 - Status:** Connected.
 - Default profile:** Yes.
 - WWAN IP:** 10.101.42.167.
 - DNS server:** 10.4.81.103, 10.4.182.20.
 - APN:** XXXXXXXX.
 - Connection uptime:** 01:43:50.
- Advanced status:**
 - Mobile country code:** 505.
 - Mobile network code:** XX.
 - DC input voltage:** 12.26V.
 - HSUPA category:** 6.
 - HSDPA category:** 24.
 - SIM ICCID:** XXXXXXXXXXXXXXXXXX.
 - Power input mode:** DCJack.
 - Tracking Area Code (TAC):** 20D7 (8407).
 - IMSI:** XXXXXXXXXXXXXXX.
 - Cell ID:** 133256195.
 - Channel number (UARFCN):** 1275.
 - Module PRIID Revision:** 05.01.
 - Module PRIID PRI part number:** 9903749.
 - PRI carrier:** XXXXXXXX.
 - PRI config:** XXXXXXXX.
 - Reference Signal Received Quality (RSRQ):** -11 dB.
 - Reference Signal Received Power (RSRP):** -115 dBm.
 - Packet service status:** Attached.
- LAN:**
 - IP:** 192.168.1.1 / 255.255.255.0.
 - MAC address:** 18:F1:45:21:0C:4D.
 - Ethernet port status #1:** Down (with a down arrow icon).
 - Ethernet port status #2:** Up / 1000 Mbps / FDX (with an up arrow icon).
- WAN:**
 - Priority:** 1. wwan.0 [Link] (with a checkmark icon).
- External storage:** No media found.
- USB-OTG:**
 - Current status:** Device mode.
- SMS status:**
 - Received message count:** 0.
- Event notification:**
 - Event count:** 0.

Table 7-1 Status page item details

ITEM	DEFINITION
System information	
System up time	The current uptime of the router.
Board version	The hardware version of the router.
Serial Number	The serial number of the router.
Firmware version	The firmware version of the router
Model	The type of phone module and the firmware version of the module.
Module firmware	The firmware revision of the phone module.
IMEI	The International Mobile Station Equipment Identity number used to uniquely identify a mobile device.
LAN	
IP	The IP address and subnet mask of the router.
MAC Address	The MAC address of the router.
Ethernet Port Status	Displays the current status of the Ethernet port and its operating speed.
WAN	
Priority	Displays the priority of the available WAN connections.
External storage	
External storage	Lists the type and size of external storage (onboard/USB), if connected.
USB-OTG	
Current status	Displays the current status of the USB-OTG port (Device or host mode)
SMS status	
Received message count	Displays the number of SMS messages received by the router.
Event notification	
Event count	Displays the number of notifications sent using the Event notification feature.
Cellular connection status	
SIM Status	Displays the activation status of the SIM in the router.
Signal strength (dBm)	The current signal strength measured in dBm

ITEM	DEFINITION
Network registration status	The status of the router's registration for the current network.
Operator selection	The mode used to select an operator network.
Current operator	The current operator network in use.
Roaming status	The roaming status of the router.
Allowed bands	The bands to which the router may connect.
Current band	The current band being used by the router.
Coverage	The type of mobile coverage being received by the router.
WWAN Connection Status	
Profile name	The name of the active profile.
Status	The connection status of the active profile.
Default profile	Indicates whether the current profile in use is the default profile.
WWAN IP	The IP address assigned by the mobile broadband carrier network.
DNS server	The primary and secondary DNS servers for the WWAN connection.
APN	The Access Point Name currently in use.
Connection uptime	The length of time of the current mobile connection session.
Advanced status	
Mobile country code	The Mobile Country Code (MCC) of the router.
Mobile network code	The Mobile Network Code (MNC) of the router.
DC input voltage	Displays the current voltage of the power input source provided via the DC Input jack
HSUPA category	Displays the HSUPA category (1-9) for the current uplink
HSDPA category	Displays the HSDPA category (1-8) for the current downlink.
SIM ICCID	The Integrated Circuit Card Identifier of the SIM card used with the router, a unique number up to 19 digits in length.
Power input mode	Displays the power source being used.
Tracking Area Code (TAC)	Identifies a tracking area within a particular network.
IMSI	The International mobile subscriber identity is a unique identifier of the user of a cellular network.

ITEM	DEFINITION
Cell ID	A unique code that identifies the base station from within the location area of the current mobile network signal.
Channel number (UARFCN)	The channel number of the current cellular connection.
CID	Cellular configuration ID
Module PRIID Revision	Module version used for customization.
Module PRIID PRI part number	The part number of the Module PRIID.
PRI carrier	The carrier network.
PRI config	Configuration file for the current carrier network.
Reference Signal Received Quality (RSRQ)	RSRQ calculates signal quality taking into consideration the RSSI. It is calculated by $N \times \text{RSRP} / \text{RSSI}$ where N is the number of Physical Resources Blocks (PRBs) over which the RSSI is measured.
Reference Signal Received Power (RSRP)	A cell-specific reference signal used to determine RSRP.
Packet service status	Displays whether the packet service is attached or detached. When APN or username/password is changed, the device detaches and reattaches to the network.

8. Networking

The Networking section provides configuration options for Wireless WAN, LAN, Routing and VPN connectivity.

Wireless WAN

Data connection

The data connection page allows you to configure and enable/disable the connection profile. To access this page, click on the Networking menu, and under the Wireless WAN menu, select the Data connection item.

Figure 8-1 Data connection settings

Profile name

	Default	Status	APN	Username
Profile1	☒	☒ ON ☐ OFF	Automatic	
Profile2	☐	☐ ON ☒ OFF	Blank	
Profile3	☐	☐ ON ☒ OFF	Blank	
Profile4	☐	☐ ON ☒ OFF	Blank	
Profile5	☐	☐ ON ☒ OFF	Blank	
Profile6	☐	☐ ON ☒ OFF	Blank	

Roaming settings

Allow data roaming ☐ ON ☒ OFF

Table 8-1 Data connection item details

ITEM	DEFINITION
Profile name	
Default	Sets the corresponding profile to be the default gateway for all outbound traffic except traffic for which there are configured static route rules or profile routing settings.
Status	Toggles the corresponding profile on and off. Only one profile may be turned on at any time.
APN	The APN configured for the corresponding profile.
Username	The username used to log on to the corresponding APN.
Roaming settings	
Allow data roaming	When set to ON, the router will allow local devices to access the Wireless WAN network when it is roaming onto a foreign network. When set to OFF, the router will deny network access to data services when roaming onto a foreign network. This setting is OFF by default. Note that additional costs may apply when using roaming data services.

Connecting to the mobile broadband network


The router supports the configuration of up to six APN profiles; these profiles allow you to configure the settings that the router will use to connect to the broadband network and switch easily between different connection settings.

Manually configuring a connection profile

To manually configure a connection profile:

1. Click the Edit button corresponding to the Profile that you wish to modify. The data connection profile settings page is displayed.

Figure 8-2 Data connection profile setting



2. Click the Profile toggle key to turn the profile on. Additional settings appear.

Figure 8-3 Data connection settings - Profile turned on

Data connection profile settings

Profile ☒ ON ☐ OFF

Profile name

Automatic APN selection ☐ ON ☒ OFF

APN

Username

Password

Authentication type ☒ CHAP ☐ PAP

Metric (0-65535)

MTU (1358-1460)

NAT masquerading ☒ ON ☐ OFF

Profile routing settings

You may route only particular traffic via this connection profile by specifying the network address and mask below of the destination network. Blank values will route all traffic via this profile. Please leave these settings blank if you are unsure.

Network address · · ·

Network mask · · ·

3. In the Profile name field, enter a name for the profile. This name is only used to identify the profile on the router.
4. Ensure that the Automatic APN selection toggle key is set to off. If it is not, click it to toggle it to the off position.
5. In the APN field, enter the APN Name (Access Point Name) and if required, use the Username and Password fields to enter your login credentials. Note that the APN and username fields have a limit of 81 characters.
6. Next to Authentication type, select either CHAP or PAP depending on the type of authentication used by your provider.
7. The Metric value is used by router to prioritize routes (if multiple are available) and is set to 20 by default. This value is sufficient in most cases but you may modify it if you are aware of the effect your changes will have on the service.
8. The MTU field allows you to modify the Maximum Transmission Unit used on the connection. Do not change this unless instructed to by your carrier.
9. Use the NAT Masquerading toggle key to turn NAT Masquerading on or off. NAT masquerading, also known simply as NAT is a common routing feature which allows multiple LAN devices to appear as a single WAN IP via network address translation. In this mode, the router modifies network traffic sent and


received to inform remote computers on the internet that packets originating from a machine behind the router actually originated from the WAN IP address of the router's internal NAT IP address. This may be disabled if a framed route configuration is required and local devices require WAN IP addresses.

10. Click the Save button when you have finished entering the profile details.

Confirming a successful connection

After configuring the packet data session, and ensuring that it is enabled, click on the Status menu item at the top of the page to return to the Status page. When there is a mobile broadband connection, the WWAN section is expanded showing the details of the connection and the Status field displays Connected. To see details on the connected session, you can click the Show data usage button.

Figure 8-4 WWAN connection status section



Connect on demand

The Connect on demand feature keeps the Packet Data Protocol (PDP) context deactivated by default while making it appear to locally connected devices that the router has a permanent connection to the mobile broadband network. When a packet of interest arrives or an SMS wake-up command is received, the router attempts to establish a mobile broadband data connection. When the data connection is established, the router monitors traffic and terminates the link when it is idle.



Note: When interesting packets arrive, the recovery time for the wireless WAN connection is approximately 20-30 seconds.

Configuring Connect on demand

To configure Connect on demand:

1. Click the Networking menu item from the top menu bar.
2. On the Connect on demand page, click the Connect on demand toggle key so that it is ON. Extra options appear. See the following sub-sections for further instructions.

Figure 8-5 Connect on demand configuration options

Connect on demand

The connect on demand feature keeps the PDP context deactivated by default while making it appear that the router has permanent connection to WWAN and locally connected devices. When interesting packets arrive or an SMS wake-up command is received, the router will attempt to establish a WWAN data connection. The router will monitor traffic once the data connection is established and will terminate it when the link is idle.

Connect on demand ☒ ON ☐ OFF

Selected profile

Data activity triggered connection

Connect only when traffic appears to these UDP/TCP destination ports. You can specify multiple ports by separating them with a comma (eg 21, 23, 53).

Enable dial port filter ☒ ON ☐ OFF

Connect on data activity except when activity matches these IP protocols

Ignore ICMP ☒ ON ☐ OFF

Ignore TCP ☒ ON ☐ OFF

Ignore UDP ☒ ON ☐ OFF

on data activity except when activity matches these applications

Ignore DNS ☒ ON ☐ OFF

Ignore NTP ☒ ON ☐ OFF

Ignore Microsoft network awareness (NCSI) traffic ☒ ON ☐ OFF

Connect and disconnect timers Periodic connect schedule

On data activity, stay online for at least

After connecting, stay online for at least

After hanging up, don't redial for

Disconnect regardless of traffic after

Connect regularly, every

Randomize connect frequency by up to

Verbose logging configuration

Log all matched activity to the system log ☒ ON ☐ OFF

Online / Offline control

Connection status Disabled

Setting the router to dial a connection when traffic is detected on specific ports

In some situations, you may wish to have the internet connection disabled except at times when outbound traffic to a particular external host's port or group of ports is sent to the router. To use this feature, click Enable dial port filter and enter the port number or list of port numbers separated by commas. When you select this option, all outbound ICMP/TCP/UDP packets to any remote host on the specified port(s) will trigger the connection to dial. Note that when this feature is enabled, the options to ignore specific packet types are not available.

Figure 8-6 Connect on demand - Data activity triggered connection

Data activity triggered connection

Connect only when traffic appears to these UDP/TCP destination ports. You can specify multiple ports by separating them with a comma (eg 21, 23, 53).

Enable dial port filter ☒ ON ☐ OFF

You can allow Microsoft network awareness (NCSI) traffic through but if you prefer that they do not trigger the connection, click the Ignore Microsoft network awareness (NCSI) traffic toggle key to set it to ON.

Figure 8-7 Connect on demand - Ignore NCSI traffic

Connect on data activity except when activity matches these applications

Ignore Microsoft network awareness (NCSI) traffic ☐ ON ☒ OFF

Excluding certain packet types from triggering the connection to dial

Depending on your environment, you might prefer to exclude certain types of traffic passing through the router from triggering the data connection. You can tell the router to ignore outbound TCP, UDP or ICMP packets. When any of these options are checked the router will not dial a connection when that type of outbound destined data packet reaches the router from a locally connected device.

Figure 8-8 Connect on demand - Excluding IP protocols

Connect on data activity except when activity matches these IP protocols

Ignore ICMP ☐ ON ☒ OFF

Ignore TCP ☐ ON ☒ OFF

Ignore UDP ☐ ON ☒ OFF

Excluding certain application types from triggering the connection to dial

Some devices may generate general traffic as a part of normal operation which you may not want to trigger the data connection. You can set the router to ignore Domain Name System (DNS), Network Time Protocol (NTP) or Microsoft network awareness (NCSI) traffic from devices behind the router. When you check the box for these options, it tells the router to ignore the request from that application type and will not dial a connection when this data type is received.

Figure 8-9 Connect on demand - Excluding application types

on data activity except when activity matches these applications

Ignore DNS ☐ ON ☒ OFF

Ignore NTP ☐ ON ☒ OFF

Ignore Microsoft network awareness (NCSI) traffic ☐ ON ☒ OFF

Setting timers for connection and disconnection

The router has a number of timer settings which let you determine when a connection is dialled and when it is disconnected.

Figure 8-10 Connect on demand - Connect and disconnect timers

Connect and disconnect timers **Periodic connect schedule**

On data activity, stay online for at least

After connecting, stay online for at least

After hanging up, don't redial for

Disconnect regardless of traffic after

Connect regularly, every

Randomise connect frequency by up to

Table 8-2 Connect on demand - Connect and disconnect timers descriptions

OPTION	DESCRIPTION
On data activity, stay online for at least	When traffic as per the configured settings above appear, the router will either continue to stay online, or dial a connection and will not disconnect it for the specified time period (min. 1 minute, max. 1 hour). This timer is continuously reset throughout the duration of a dial-up session, whenever data activity is detected matching the rules above.
After connecting, stay online for at least	This timer configures the router to not hang-up the connection for the specified time period after initially dialling the connection. This setting cannot be less than the keep online period above. This timer affects the connection only once per dial up session, at the beginning of the session.
After hanging up, don't redial for	After a connection has been disconnected, you can tell the router to rest for a period of time before re-dialling.
Disconnect regardless of traffic after	Forces the router to disconnect the connection regardless of the traffic passing through it. The default setting is never.
	If you want to have the router dial a connection at regular intervals, use Connect regularly, every to specify the interval between dials. Setting this to never effectively disables this option. The router also features the ability to randomise the time at which the first dial action is performed. This is useful in situations such as where you have numerous routers in an area where a power outage has occurred. Setting a random dial time helps to reduce network

OPTION	DESCRIPTION
Connect regularly, every / Randomise connect frequency by up to	congestion when all the routers are powered on so they do not all try to connect simultaneously. When Connect regularly, every is set to at least 2 minutes, you are able to configure the router to randomise the time it begins to dial. The randomised dial timer only affects the initial dial after the unit powers on or after the settings are saved. For example, if you configure the router to dial every 2 minutes with a randomised dial starting time of 1 minute, the router waits for the Connect regularly, every time (2 minutes) and then randomly selects a time less than or equal to the Randomise connect frequency by up to time (1 minute). After the randomly selected time has elapsed, the router dials the connection. After the first dial, the router dials the connection every 2 minutes, ignoring the Randomise connect frequency by up to time.

Verbose mode

The router provides the option of logging all the data activity which matches the settings for the Connect on demand feature for advanced troubleshooting purposes. To enable the logging of the Connect on demand feature, click the Enable verbose mode toggle key to switch it ON. See the System log section for more information.


Figure 8-11 Connect on demand - Verbose logging configuration



Manually connecting/disconnecting

There may be times when you need to either force a connection to be made or force a disconnection manually. You can use the Manual connect and Manual disconnect buttons to do this whenever necessary. The online status of the connection is displayed above the buttons.

Figure 8-12 Connect on demand - Online/Offline control



When you have finished configuring the options for the Connect on demand feature, click the Save button at the bottom to save your changes.

SMS Wake up

The router can also be woken up by means of an SMS message using the SMS diagnostics feature by sending an executable wakeup command via SMS. See the [Diagnostics](#) section for details on using the SMS Wake up function.

SIM management

The SIM management page displays the status of the SIM card.

Figure 8-13 SIM Management

Option	Status	Preference
SIM1	External	SIM OK

[Data connection](#)

Band settings

The Band Settings page enables you to select which frequency band you will use for your connection and enables you to scan for available network operators in your area.

Figure 8-14 Band settings



Note: In order to change the operator's band settings, the data connection must be disabled. When you access this page, you are prompted to disable the data connection if it is already active.

You may want to do this if you're using the router in a country with multiple frequency networks that may not all support High Speed Packet Access (HSPA). You can select the router to only connect on the network frequencies that suit your requirements.

Use the Change band drop down list to select the band you wish to use. The following band settings options are available:

It is not necessary to change the default setting of All bands in most cases. In fact, locking to a particular band can cause connection difficulties if the device is moved to a location where the forced band selection is no longer available.

When All bands is selected, the router attempts to find the most suitable band based on the available networks for the inserted SIM card.

The “WCDMA / GSM” and “WCDMA Only” options allow you to force the device to lock to those particular networks only. Click the Save button to save and apply your selection.

Operator settings

The operator settings feature allows you perform a scan of available networks, and to optionally lock to a particular network returned by the network scan. To scan for available networks, set the Select operator mode from automatic to Manual then click the scan button. This operation can take a few minutes and requires that the packet data session be disconnected prior to scanning.

Figure 8-15 Operator settings

Operator settings

Select operator mode ☒ Automatic ☐ Manual

Current operator registration XXXXXXXX

Scan Apply

A list of the detected cellular service carriers in your area is displayed.

Figure 8-16 Detected operator list

Operator name list	MCC	MNC	Operator status	Network type
☐ Telstra	505	01	Available	UMTS (3G)
☐ Telstra	505	01	Available	GSM (2G)
☒ Telstra	505	01	Current	LTE (4G)
☐ vodafone AU	505	03	Forbidden	UMTS (3G)
☐ YES OPTUS	505	02	Forbidden	GSM (2G)
☐ YES OPTUS	505	02	Forbidden	LTE (4G)
☐ vodafone AU	505	03	Forbidden	GSM (2G)
☐ YES OPTUS	505	02	Forbidden	UMTS (3G)

Apply Cancel



Note: Certain module firmware versions may not allow forbidden operators to be selected. Select the most appropriate service from the list shown and click Apply.

When Select operator mode is set to Automatic, the router selects the most appropriate operator based on the inserted SIM card. This is the default option and is sufficient for most users.

SIM security settings


The SIM security settings page can be used for authenticating SIM cards that have been configured with a security PIN.

Unlocking a PIN locked SIM

If the SIM card is locked, you will receive a notice when you access the Status page after which you will be directed to the PIN settings page to enter the PIN. The PIN settings page lists the status of the SIM at the top of the page. If you are not redirected to the PIN settings page, to unlock the SIM:

1. Click on the Networking menu from the top menu bar, and then click SIM security settings.

Figure 8-17 SIM security settings - SIM PIN locked



PIN settings

! SIM is PIN locked - remaining attempt(s) 3

Current PIN

Confirm current PIN

Remember PIN ☐

Save

2. Enter the PIN in the Current PIN field and then enter it again in the Confirm current PIN field to confirm the PIN.
3. If you are placing the router in a remote, unattended location, you may wish to check the Remember PIN option. This feature allows the router to automatically send the PIN to the SIM each time the SIM asks for it (usually at power up). This enables the SIM to be PIN locked (to prevent unauthorised re-use of the SIM elsewhere), while still allowing the router to connect to the cellular service.

When this feature is enabled, the PIN you enter when setting the Remember PIN feature is encrypted and stored locally on the router. The next time the SIM asks the router for the PIN, the router decrypts the PIN and automatically sends it to the SIM without user intervention.

When this feature is disabled and the SIM is PIN locked and the PIN must be manually entered via the router's configuration interface. In situations where the router will be unattended, this is not desirable.



Note: Select Remember PIN if you do not want to enter the PIN code each time the SIM is inserted.

4. Click the Save button. If successful, the router displays the following screen:

Figure 8-18 SIM security settings - SIM unlock successful

Success!

The SIM unlock was successful

PIN settings

SIM OK ✓

Retries remaining: 0

PIN protection ☒ ON ☐ OFF

Change PIN

Current PIN

Confirm current PIN

Remember PIN ☐

Save

Enabling/Disabling SIM PIN protection

The security PIN protection can be turned on or off using the PIN protection toggle key.

Figure 8-19 PIN Settings

PIN settings

SIM OK ✓

PIN remembered

PIN protection ☒ ON ☐ OFF

Change PIN

Current PIN

Confirm current PIN

Remember PIN ☒

Save

Changing the SIM PIN code

If you would like to change the PIN, click the Change PIN button and enter the current PIN into the Current PIN and Confirm current PIN fields, then enter the desired PIN into the New PIN and Confirm new PIN fields and click the Save button.

Figure 8-20 PIN settings - Change PIN

PIN settings

SIM OK ☒

PIN remembered

PIN protection ☒ ON ☐ OFF

[Change PIN](#)

Current PIN

Confirm current PIN

New PIN

Confirm new PIN

Remember PIN ☒

[Save](#)

When the PIN has been changed successfully, the following screen is displayed:

Figure 8-21 SIM security settings – PIN unlock successful

Success!

Your settings have been changed successfully

PIN settings

SIM OK ☒

PIN remembered

PIN protection ☒ ON ☐ OFF

[Change PIN](#)

Current PIN

Confirm current PIN

Remember PIN ☒

[Save](#)

Unlocking a PUK locked SIM

After three incorrect attempts at entering the PIN, the SIM card becomes PUK (Personal Unblocking Key) locked and you are requested to enter a PUK code to unlock it.



Note: To obtain the PUK unlock code, you must contact your service provider.

You will be issued a PUK to enable you to unlock the SIM and enter a new PIN. Enter the new PIN and PUK codes. Click the Save button when you have finished entering the new PIN and PUK codes.

Figure 8-22 SIM security - SIM PUK locked

Oops, something went wrong...

Your SIM is PUK locked now. Please enter the PUK code to unlock. You have 10 remaining attempt(s).

PIN settings

! SIM is PUK locked

Change PIN

Current PIN

Confirm current PIN

PUK

Confirm PUK

Remember PIN ☐

Save

LAN

LAN configuration

The LAN configuration page is used to configure the LAN settings of the router and to enable or disable DNS Masquerading. To access the LAN configuration page, click on the Networking menu at the top of the screen, then click on the LAN menu on the left.

Figure 8-23 LAN configuration settings

LAN configuration

IP address · · ·

Subnet mask · · · ?

Hostname

DNS masquerading ☒ ON ☐ OFF

Save

The default IP of the LAN port is 192.168.1.1 with subnet mask 255.255.255.0. To change the IP address or Subnet mask, enter the new IP Address and/or Subnet mask and click the Save button.



Note: If you change the IP address, remember to reboot the router and enter the new IP address into your browser address bar.

DNS masquerading

DNS masquerading allows the router to proxy DNS requests from LAN clients to dynamically assigned DNS servers. When enabled, clients on the router's LAN can then use the router as a DNS server without needing to know the dynamically assigned cellular network DNS servers.

With DNS masquerading ON, the DHCP server embedded in the NTC-140 Series router hands out its own IP address (e.g. 192.168.1.1) as the DNS server address to LAN clients. The downstream clients then send DNS requests to the NTC-140 Series router which proxies them to the upstream DNS servers.

With DNS masquerading OFF, the DHCP server hands out the upstream DNS server IP addresses to downstream clients directly, so that downstream clients send DNS requests directly to the upstream DNS servers without being proxied by the NTC-140-02 router.

You may also override the DNS Masquerading option by specifying custom DNS Server IP addresses in the DHCP Server configuration mentioned in the next section of this guide. In this case the DHCP server assigns downstream devices the manually configured addresses and the DNS Masquerading option is ignored.

In most cases, it is not necessary to disable DNS masquerading but if you need to, click the DNS masquerading toggle key to turn it OFF and then click the Save button.

DHCP


The DHCP page is used to adjust the settings used by the router's built in DHCP Server which assigns IP addresses to locally connected devices. To access the LAN configuration page, click on the Networking menu at the top of the screen, click on the LAN menu on the left then select the DHCP menu item.

DHCP relay configuration

In advanced networks configurations where the NTC-140 Series router should not be responsible for DHCP assignment, but instead an existing DHCP server is located on the Wireless WAN or LAN connections, the clients behind the NTC-140 Series router are able to communicate with the DHCP server when DHCP relay is enabled. This enables the NTC-140 Series router to accept client broadcast messages and to forward them onto another subnet.

To configure the router to act as a DHCP relay agent click the DHCP relay toggle key to turn it ON and enter the DHCP server address into the DHCP server address field. DHCP relay is disabled by default.

Figure 8-24 DHCP relay configuration



DHCP relay configuration

DHCP relay ☒ ON ☐ OFF

DHCP server address . . .

Save

DHCP configuration

You can manually set the start and end address range to be used to automatically assign addresses within, the lease time of the assigned address, the default domain name suffix, primary and secondary DNS server, the primary and secondary WINS server, as well as the advanced DHCP settings such as NTP, TFTP and Option 150/Option 160 (VoIP options).

Figure 8-25 DHCP configuration

DHCP configuration

DHCP ☒ ON ☐ OFF

DHCP start range · · ·

DHCP end range · · ·

DHCP lease time(seconds)

Default domain name suffix

DNS server 1 IP address · · ·

DNS server 2 IP address · · ·

WINS server 1 IP address · · ·

WINS server 2 IP address · · ·

NTP server (Option 42) · · ·

TFTP Server (Option 66)

DHCP option 150

DHCP option 160

Table 8-3 DHCP Configuration Settings

OPTION	DESCRIPTION
DHCP start range	Sets the first IP address of the DHCP range
DHCP end range	Sets the last IP address of the DHCP range
DHCP lease time (seconds)	The length of time in seconds that DHCP allocated IP addresses are valid
Default domain name suffix	Specifies the default domain name suffix for the DHCP clients. A domain name suffix enables users to access a local server, for example, server1, without typing the full domain name server1.domain.com
DNS server 1 IP address	Specifies the primary DNS (Domain Name System) server's IP address.
DNS server 2 IP address	Specifies the secondary DNS (Domain Name System) server's IP address.
WINS server 1 IP address	Specifies the primary WINS (Windows Internet Name Service) server IP address

OPTION	DESCRIPTION
WINS server 2 IP address	Specifies the secondary WINS (Windows Internet Name Service) server IP address
NTP server (Option 42)	Specifies the IP address of the NTP (Network Time Protocol) server
TFTP Server (Option 66)	Specifies the TFTP (Trivial File Transfer Protocol) server
DHCP option 150	This is used to configure Cisco IP phones. When a Cisco IP phone starts, if it is not pre-configured with the IP address and TFTP address, it sends a request to the DHCP server to obtain this information. Specify the string which will be sent as a reply to the option 150 request.
DHCP option 160	This is used to configure Polycom IP phones. When a Polycom IP phone starts, if it is not pre- configured with the IP address and TFTP address, it sends a request to the DHCP server to obtain this information. Specify the string which will be sent as a reply to the option 160 request.

Enter the desired DHCP options and click the Save button.

Address reservation list

DHCP clients are dynamically assigned an IP address as they connect, but you can reserve an address for a particular device using the address reservation list.

Figure 8-26 DHCP – Address reservation list

The screenshot shows a web interface for configuring the DHCP address reservation list. At the top, there's a title 'Address reservation list' and a '+ Add' button. Below this is a table with four columns: 'Computer name', 'MAC address', 'IP address', and 'Enable'. The 'IP address' column contains a text input field with '0.0.0.0'. To the right of the IP field is an 'Enable' toggle switch, which is currently in the 'ON' position. There is also a close button (X) next to the toggle. At the bottom of the form is a blue 'Save' button.

To add a device to the address reservation list:

1. Click the +Add button.
2. In the Computer Name field enter a name for the device.
3. In the MAC Address field, enter the device's MAC address.
4. In the IP Address fields, enter the IP address that you wish to reserve for the device.
5. If the Enable toggle key is not set to ON, click it to switch it to the ON position.
6. Click the Save button to save the settings.

Dynamic DHCP client list

The Dynamic DHCP client list displays a list of the DHCP clients. If you want to reserve the current IP address for future use, click the Clone button and the details will be copied to the address reservation list fields. Remember to click the Save button under the Address reservation list section to confirm the configuration.

Figure 8-27 Dynamic DHCP client list

Dynamic DHCP client list				
Computer name	MAC address	IP address	Expiry time	
xxxxxx	00:21:9b:1a:89:ee	192.168.1.146	Thursday, 5 September 2013 12:02:59 PM	 Clone

Ethernet LAN/WAN

The Ethernet LAN/WAN pages provide configuration options for the two built-in Ethernet ports and any USB-to-Ethernet ports you may connect.

Ethernet group

The Ethernet group page displays the Ethernet interfaces and allows you to configure whether they operate in LAN or WAN mode.

To access the Ethernet group page, click on the Networking menu at the top of the screen, click on the Ethernet LAN/WAN menu on the left then select the Ethernet group menu item.

Figure 8-28 Ethernet group configuration

Ethernet group configuration						
#	Description	Name	Link status	MAC	Port	Configuration
0	LAN/WAN	eth.0	Down	00:60:64:D9:48:11	platform	LAN
1	LAN	eth.1	Up	00:60:64:D9:48:11	platform	LAN
2	USB Tethering	eth.2	Down	B6:BC:E9:1F:FB:EA	gadget	LAN

Save Refresh

Table 8-4 Ethernet group configuration items

OPTION	DEFINITION
#	A number identifying the interface on the router.
Description	A description of the type of interface.
Name	The name used to identify the interface on the router.
Link status	Displays whether the interface is inserted

OPTION	DEFINITION
MAC	The MAC address of the interface.
Port	The type of port.
Configuration	Select whether the port operates as a LAN or WAN port.

Ethernet WAN

The Ethernet WAN page allows you to configure the connection type and metric of the available WAN connections. To access the Ethernet WAN page, click on the Networking menu at the top of the screen, click on the Ethernet LAN/WAN menu on the left then select the Ethernet WAN menu item.

Figure 8-29 Ethernet WAN configuration

The screenshot shows the 'WAN configuration' page. At the top, there's a title 'WAN configuration' in orange. Below it, the 'WAN Ethernet' field is set to 'eth.0'. The 'Connection Type' is set to 'Static'. The 'IP address' field is set to '0.0.0.0'. The 'Subnet mask' field is set to '255.255.255.255'. The 'Gateway' field is set to '0.0.0.0'. The 'DNS server 1 IP address' field is set to '0.0.0.0'. The 'DNS server 2 IP address' field is set to '0.0.0.0'. The 'Metric' field is set to '10'. A blue 'Save' button is at the bottom.

Table 8-5 Ethernet WAN configuration options

OPTION	DEFINITION
WAN Ethernet	Use this field to select the WAN interface to configure.
Connection Type	Selects whether the WAN interface has static IP settings or DHCP.
IP address	The IP address to assign to the selected WAN interface.
Subnet mask	The Subnet mask of the IP address above.
Gateway	The gateway to assign this WAN interface.

OPTION	DEFINITION
DNS server 1 IP address	The first DNS server for the WAN interface.
DNS server 2 IP address	The second DNS server for the WAN interface.
Metric	The metric value is used to define the priority of the interface. Lower metric values indicate higher priority.

PPPoE

If desired, you can have a client device connected to the Ethernet port initiate the mobile broadband connection using a PPPoE session. This is particularly useful in situations where you wish to provide Wireless WAN data access to an existing router which you want to have full public WAN IP access and have control over routing functionality. The PPPoE connection is established over the highest priority interface.

To configure PPPoE:

1. Select the Networking menu item from the top menu bar, then select the PPPoE menu on the left side of the screen. The PPPoE configuration screen is displayed.

Figure 8-30 PPPoE Configuration

PPPoE configuration

Enable PPPoE ☒ ON ☐ OFF

Service name


Debug logging ☒ ON ☐ OFF

Forward WAN IP ☐ ON ☒ OFF

Save

2. Click the Enable PPPoE toggle key so that it is ON.
3. (Optional) In the Service name field, enter a name to use for the connection. This name is displayed on the Status page to identify the PPPoE connection. Any name you enter here must also be entered in the PPPoE connection profile in order for it to work.
4. If you require additional logging to be made available, click the Debug logging toggle key so that it is in the ON position. This displays PPPoE negotiation details in the System log.
5. The Forward WAN IP option determines whether the router passes the WAN IP address on to the PPPoE client. When this option is set to ON the first PPPoE client to connect will receive the WAN IP address and no further clients will be able to make a connection. In this mode, the router transparently bridges the connection and many of the router's features are disabled. When this option is set to OFF, the router retains the WAN IP address and performs Network Address Translation (NAT) for connected clients. In this mode, you are able to connect multiple PPPoE clients and all of the router's features are available.
6. Click the Save button to confirm the settings.
7. Click the Status menu item from the top menu bar. When Forward WAN IP is enabled, the status page shows a Transparent bridge mode section and displays the WAN IP.

Figure 8-31 Transparent bridge mode status




8. Configure the properties of the interface that the PPPoE connection will use (determined by WAN priority) in order to provide authentication credentials. Each interface uses the authentication credentials configured on the router for that particular interface, not those entered in the PPPoE client. For example, when using WWAN as the PPPoE interface, enter the username and password on the Data connection profile settings before connecting. See the [Manually configuring a connection profile](#) section for more detail.
9. Use your downstream device to initiate a network connection using a PPPoE client.

WAN failover

The WAN failover page displays a summary of the configured WAN interfaces and their priorities (Metric). Lower metric values determine higher priority. The priority of the interfaces can be adjusted using the up and down arrows in the Priority column. When the interface with the highest priority goes down, the router fails over to the next highest priority interface. The method used to determine whether an interface is “up” or “down” is defined by the Monitor setting. By default, an interface is monitored by its link status.

To access the WAN failover page, click on the Networking menu at the top of the screen then click on the WAN failover menu item on the left.

Figure 8-32 WAN summary



To edit an interface, select the edit icon for the interface you wish to edit. The Failover configuration page is displayed. When Monitoring method is set to Hardware link the failover is controlled by the physical detection of the link.

Figure 8-33 Failover configuration – hardware link

Failover configuration - wwan (Profile1)

Metric (0-65535)

Monitoring method

Verbose logging ☒ ON ☐ OFF

Table 8-6 Failover configuration - Hardware link monitoring

OPTION	DESCRIPTION
Priority	The priority (metric) is a numeric value which determines which interface has priority. Lower priority values mean higher priority.
Monitoring method	Specifies the means used to determine whether the link is up or down.
Verbose logging	When enabled, this logs verbose comments in the system log related to the failover monitoring.

When Monitoring method is set to Ping, the router sends periodic ping requests to the specified addresses to verify the connection is working. This works in a similar manner to the Watchdogs feature but with different ranges on the timers. Please refer to the [Watchdogs](#) section of this user guide for a more detailed description of this function.

Figure 8-34 Failover Configuration - ping

Failover configuration - wwan (Profile1)

Metric (0-65535)

Monitoring method

Verbose logging ☒ ON ☐ OFF

First destination address

Second destination address

Periodic Ping timer (3-65535) secs

Retry timer (2-65535) secs

Consecutive error monitor

Fail/Success count (0=disable, 3-65535) times

Periodic ratio monitor

Monitor total count (0=disable, 3-65535) times

Failover fail count (3-65535) times

Failback success count (3-65535) times

Table 8-7 Failover configuration - Ping monitoring

OPTION	DESCRIPTION
Priority	The priority (metric) is a numeric value which determines which interface has priority. Lower priority values mean higher priority.
Monitoring method	Specifies the means used to determine whether the link is up or down.
Verbose logging	When enabled, this logs verbose comments in the system log related to the failover monitoring.
First destination address	The first address the router that the router should ping in order to confirm the connection is up. This may be an IP address or a domain name.
Second destination address	The second address the router that the router should ping in order to confirm the connection is up. This may be an IP address or a domain name.
Periodic Ping timer	The time in seconds between ping attempts.

Retry timer	The time in seconds between attempts when a ping failure occurs.
Consecutive error monitor	
Fail count	The number of failed pings that must occur before the monitor moves to the second destination address or fails the connection over to the next interface.
Periodic ratio monitor	
Monitor total count	This field specifies the number of previous pings to consider when calculating whether to fail over or fail back.
Failover total count	This field specifies the number of failed ping attempts with respect to the Monitor total count before the router fails over to the next highest priority interface. For example, at the default setting of 5, the router fails over to the next interface when 5 out of the last 10 ping attempts have failed. The failures need not be consecutive to meet the fail over criteria. If any 5 of the last 10 pings have failed, the router deems the interface connection to be of poor quality and fails over.
Failback success count	Like the Failover fail count field, this field specifies the number of ping successes that must be registered on a higher priority interface with respect to the Monitor total count before the router fails back to that interface.

Routing

Static

Static routing is the alternative to dynamic routing used in more complex network scenarios and is used to facilitate communication between devices on different networks. Static routing involves configuring the routers in your network with all the information necessary to allow the packets to be forwarded to the correct destination. If you change the IP address of one of the devices in the static route, the route will be broken.

To access the Static routing page, click on the Networking menu at the top of the screen, click on the Routing menu on the left, then click on the Static menu item.

Figure 8-35 Static routing list

Static routing list						+ Add	
Route name	Destination network address	Subnet mask	Gateway IP address	Network interface	Metric		
MyRoute	192.168.20.0	255.255.255.0	192.168.1.101	Auto	0		

Active routing list							
Destination	Gateway	Netmask	Flags	Metric	Ref	Use	Interface
0.0.0.0	120.157.26.49	0.0.0.0	UG	20	0	0	rmnet1
120.157.26.48	0.0.0.0	255.255.255.240	U	0	0	0	rmnet1
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0	br0
192.168.20.0	192.168.1.101	255.255.255.0	UG	0	0	0	br0

Some routes are added by default by the router on initialization such as the Ethernet subnet route for routing to a device on the Ethernet subnet.

Adding Static Routes

To add a new route to the static routing list, click the +Add button. The Static routes page appears.

1. In the Route name field, type a name for the route so that it can be identified in the static routing list.
2. From the Network interface drop down list, select the interface for which you would like to create a static route.
3. In the Destination IP address field, enter the IP address of the destination of the route.
4. In the IP subnet mask field, enter the subnet mask of the route.
5. In the Gateway IP address field, enter the IP address of the gateway that will facilitate the route.
6. In the Metric field enter the metric for the route. The metric value is used by the router to prioritise routes. The lower the value, the higher the priority. To give the route the highest priority, set it to 0.
7. Click the Save button to save your settings.

Figure 8-36 Adding a static route

Static routes

Route name

MyRoute

Network interface

Auto

Destination network address

192

168

20

0

Destination subnet mask

255

255

255

0

Gateway IP address

192

168

1

101

Metric

0

(0-65535)

Save

Refresh

Cancel

Active routing list

Static routes are displayed in the Active routing list.

Figure 8-37 Active routing list

Active routing list

Destination	Gateway	Netmask	Flags	Metric	Ref	Use	Interface
0.0.0.0	120.157.26.49	0.0.0.0	UG	20	0	0	rmnet1
120.157.26.48	0.0.0.0	255.255.255.240	U	0	0	0	rmnet1
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0	br0
192.168.20.0	192.168.1.101	255.255.255.0	UG	0	0	0	br0

Deleting static routes

From the static routing list, click the  icon to the right of the entry you wish to delete.

Figure 8-38 Active routing list

Static routing list

+ Add

Route name	Destination network address	Subnet mask	Gateway IP address	Network interface	Metric	
MyRoute	192.168.20.0	255.255.255.0	192.168.1.101	Auto	0	 

RIP

RIP (Routing Information Protocol) is used for advertising routes to other routers. Thus all the routes in the router's routing table will be advertised to other nearby routers. For example, the route for the router's Ethernet subnet could be advertised to a router on the PPP interface side so that a router on this network will know how to route to a device on the router's Ethernet subnet. Static routes must be added manually according to your requirements. See [Adding Static Routes](#).

To access the RIP configuration page, click on the Networking menu at the top of the screen, click on the Routing failover menu on the left, then click on the RIP menu item.



Note: Some routers will ignore RIP.

Figure 8-39 RIP configuration

The screenshot shows the 'RIP configuration' page. At the top, the title 'RIP configuration' is in orange. Below it, there is a toggle switch for 'RIP' set to 'ON'. Underneath, there is a 'Version' dropdown menu currently showing '2'. Below that is an 'Interface' dropdown menu currently showing 'LAN'. At the bottom of the form is a blue 'Save' button.

To enable Routing Information Protocol (RIP):

1. Click the RIP toggle key to switch it to the ON position.
2. Using the Version drop down list, select the version of RIP that you would like to use.
3. Select the interface for which you want RIP to apply. You can choose the LAN interface, the WWAN interface or BOTH.
4. Click the Save button to confirm your settings.

Redundancy (VRRP) configuration

Virtual Router Redundancy Protocol (VRRP) is a non-proprietary redundancy protocol designed to increase the availability of the default gateway servicing hosts on the same subnet. This increased reliability is achieved by advertising a “virtual router” (an abstract representation of master and backup routers acting as a group) as a default gateway to the host(s) instead of one physical router. Two or more physical routers are then configured to stand for the virtual router, with only one doing the actual routing at any given time. If the current physical router that is routing the data on behalf of the virtual router fails, an arrangement is made for another physical router to automatically replace it. The physical router that is currently forwarding data on behalf of the virtual router is called the master router. Master routers have a priority of 255 and backup router(s) can have a priority between 1 and 254.

A virtual router must use 00-00-5E-00-01-XX as its (MAC) address. The last byte of the address (XX) is the Virtual Router Identifier (VRID), which is different for each virtual router in the network. This address is used by only one physical router at a time, and is the only way that other physical routers can identify the master router within a virtual router.

To access the Redundancy (VRRP) page, click on the Networking menu at the top of the screen, click on the Routing failover menu on the left, then click on the Redundancy (VRRP) menu item.

Figure 8-40 VRRP configuration

To configure VRRP, configure multiple devices as follows and connect them all via an Ethernet network switch to downstream devices.

5. Click the Redundancy (VRRP) toggle key to activate VRRP.
6. In the Virtual ID field, enter an ID between 1 and 255. This is the VRRP ID which is different for each virtual router on the network.
7. In the Router priority field, enter a value for the priority – a higher value is a higher priority.
8. The Virtual IP address field is used to specify the VRRP IP address – this is the virtual IP address that both virtual routers share.
9. Click the Save button to save the new settings.



Note: Configuring VRRP changes the MAC address of the Ethernet port and therefore if you want to resume with the web configuration you must use the new IP address (VRRP IP) or on a command prompt type:

`arp -d <ip address>` (i.e. `arp -d 192.168.1.1`) to clear the arp cache.(old MAC address).

Port forwarding

The Port forwarding list is used to configure the Network Address Translation (NAT) rules currently in effect on the router. To access the Port forwarding page, click on the Networking menu at the top of the screen, click on the Routing failover menu on the left, then click on the Port forwarding menu item.

Figure 8-41 Port forwarding list

Protocol	Original IP address	Original port range	Destination IP address	Destination port range
TCP	192.168.1.1	3389 - 3389	192.168.1.150	3389 - 3389

The purpose of the port forwarding feature is to allow mapping of inbound requests to a specific port on the WAN IP address to a device connected on the Ethernet interface.

Adding a port forwarding rule

To create a new port forwarding rule:

1. Click the +Add button. The port forwarding settings screen is displayed.
2. Use the Protocol drop down list to select the type of protocol you want to use for the rule. The protocols selections available are TCP, UDP and All.
3. In the Source IP Address field, enter a “friendly” address that is allowed to access the router or a wildcard IP address
4. (0.0.0.0) that allows all IP addresses to access the router.
5. The Source Port Range (From) and (To) fields are used to specify the port(s) on the source side that are to be forwarded. This allows you to send a range of consecutive port numbers by entering the first in the range in the (From) field and the last in the range in the (To) field. To forward a single port, enter the port in the (From) field and repeat it in the (To) field.
6. In the Destination network address field, enter the IP address of the client to which the traffic should be forwarded.
7. The Destination Port Range (From) and (To) fields are used to specify the port(s) on the destination side that are to be forwarded. If the Source port range specifies a single port then the destination port may be configured to any port. If the Source port range specifies a range of port numbers then the Destination port range must be the same as the Source port range.
8. Click the Save button to confirm your settings.

Figure 8-42 Port forwarding settings

Port forwarding settings

Protocol TCP

Source IP address 192 168 1 1

Source port range (From) 3389 (1-65535) (To) 3389 (1-65535)

Destination network address 192 168 1 150

Destination port range (From) 3389 (1-65535) (To) 3389 (1-65535)

Save Reset Cancel

To delete a port forwarding rule, click the  button on the Port forwarding list for the corresponding rule that you would like to delete.

DMZ

The Demilitarized Zone (DMZ) allows you to configure all incoming traffic on all protocols to be forwarded to a selected device behind the router. This feature can be used to avoid complex port forwarding rules, but it exposes the device to untrusted networks as there is no filtering of what traffic is allowed and what is denied. The DMZ configuration page is used to specify the IP Address of the device to use as the DMZ host.

To access the DMZ page, click on the Networking menu at the top of the screen, click on the Routing failover menu on the left, then click on the DMZ menu item.

Figure 8-43 DMZ configuration

DMZ configuration

DMZ ☒ ON ☐ OFF

DMZ IP address 192 . 168 . 1 . 101

Save

1. Click the DMZ toggle key to turn the DMZ function ON.
2. Enter the IP Address of the device to be the DMZ host into the DMZ IP Address field.
3. Click the Save button to save your settings.

Router firewall

The Router firewall page is used to enable or disable the in-built firewall on the router. When enabled, the firewall performs stateful packet inspection on inbound traffic from the wireless WAN and blocks all unknown services, that is, all services not listed on the Services configuration page of the router.

With respect to the other Routing options on the Networking page, the firewall takes a low priority. The priority of the firewall can be described as:

DMZ > MAC/IP/Port filtering rules > MAC/IP/Port filtering default rule > Router firewall rules

In other words, the firewall is of the lowest priority when compared to other manual routing configurations. Therefore, a MAC/IP/Port filtering rule takes priority in the event that there is a conflict of rules. When DMZ is enabled, MAC/IP/Port filtering rules and the router firewall are ignored but the router will still honour the configuration of the Remote router access control settings listed under Administration Settings.

To access the DMZ page, click on the Networking menu at the top of the screen, click on the Routing failover menu on the left, then click on the Router firewall menu item.

Figure 8-44 Router firewall toggle key

Router firewall

Enable router firewall ☒ ON ☐ OFF

Save

MAC / IP / Port filtering

The MAC/IP/Port filter feature allows you apply a policy to the traffic that passes through the router, both inbound and outbound, so that network access can be controlled. When the filter is enabled with a default rule of “Accepted”, all connections will be allowed except those listed in the “Current MAC / IP / Port filtering rules in effect” list. Conversely, when the default rule is set to “Dropped”, all connections are denied except for those listed in the filtering rules list.

To access the MAC / IP / Port filtering page, click on the Networking menu at the top of the screen, click on the Routing failover menu on the left, then click on the MAC / IP / Port filtering menu item.

Figure 8-45 MAC / IP / Port filtering

MAC / IP / Port filtering

MAC / IP / Port filtering **ON** OFF

Default rule (inbound/forward) Accepted

Save

Current MAC / IP / Port filtering rules in effect

Up Down + Add

Index	Bound	Action	Comment
1	Forward	Drop	DemonstrationRule



Note: When enabling MAC / IP / Port filtering and setting the default rule to “Dropped”, you should ensure that you have first added a filtering rule which allows at least one known MAC/IP to access the router, otherwise you will not be able to access the user interface of the router without resetting the router to factory default settings.

Creating a MAC / IP / Port filtering rule

To create a filtering rule:

1. Click the MAC / IP / Port filtering toggle key to switch it to the ON position.
2. Using the Default rule (inbound/forward) drop down list, select the default action for the router to take when traffic reaches it. By default, this is configured to Accepted. If you change this to Dropped, you should first configure a filter rule that allows at least one device access to the router, otherwise you will effectively be locked out of the router.
3. Click the Save button to confirm the default rule.
4. In the Current MAC / IP / Port filtering rules in system section, click the +Add button.

Figure 8-46 Current MAC / IP / Port filtering rules in effect

Current MAC / IP / Port filtering rules in effect

Up Down + Add

Index	Bound	Action	Comment
MAC / IP / Port filtering rule is empty			

Save Reset

5. Enter the details of the rule in the section that is displayed and click the Save button.

Figure 8-47 MAC / IP / Port filtering settings

MAC / IP / Port filter settings

Bound

Protocol

Source MAC address

Source IP address /

Destination IP address /

Action

Comment

Table 8-8 Current MAC / IP / Port filtering rules in effect

OPTION	DESCRIPTION
Bound	Use the drop down list to select the direction of the traffic for which you want to apply to the rule. Inbound refers to all traffic that is entering the router including data entering from the WAN and the LAN. Outbound refers to all traffic exiting the router including traffic leaving in the direction of the WAN and traffic leaving in the direction of the LAN. Forward specifies traffic that enters on the LAN or WAN side and is forwarded to the opposite end.
Protocol	Use the drop down list to select the protocol for the rule. You can have the rule apply to All protocols, TCP, UDP, UDP/TCP or ICMP.
Source MAC Address	Enter the MAC address in six groups of two hexadecimal digits separated by colons (:). e.g. 00:40:F4:CE:FA:1E
Source IP Address	Enter the IPv4 address that the traffic originates from and the subnet mask using CIDR notation.
Destination IP Address	Enter the IPv4 address that the traffic is destined for and the subnet mask using CIDR notation.
Action	Select the action to take for traffic which meets the above criteria. You can choose to Accept or Drop packets. When the default rule is set to Accept, you cannot create a rule with an Accept action since the rule is redundant. Likewise, if the default rule is set to Dropped you cannot create a rule with a Drop action.
Comment	[Optional] Use this field to enter a comment as a meaningful description of the rule.

6. The new rule is displayed in the filtering rules list. You can edit the rule by clicking the  Edit button or delete the rule by clicking the  button.

Figure 8-48 Completed filtering rule

Current MAC / IP / Port filtering rules in effect

Up Down + Add

	Index	Bound	Action	Comment		
	1	Forward	Drop	DemonstrationRule		

VPN

A Virtual Private Network (VPN) is a tunnel providing a private link between two networks or devices over a public network. Data to be sent via a VPN needs to be encapsulated and as such is generally not visible to the public network.

The advantages of a VPN connection include:

- Data Protection
- Access Control
- Data Origin Authentication
- Data Integrity

Each VPN connection has different configuration requirements. The following pages detail the configuration options available for the different VPN connection types.



Note: The following descriptions are an overview of the various VPN options available. More detailed instructions are available in separate whitepapers on the Lantronix website.

IPSec

IPSec operates on Layer 3 of the OSI model and as such can protect higher layered protocols. IPSec is used for both site to site VPN and Remote Access VPN. The NTC-140 Series router supports IPSec end points and can be configured with Site to Site VPN tunnels with third party VPN routers.

Configuring an IPSec VPN

From the menu at the top of the screen, click Networking and under the VPN section, click IPSec. A list of configured IPSec VPN connections is displayed.

Figure 8-49 IPSec VPN List



Click the +Add button to begin configuring an IPSec VPN connection.

Figure 8-50 IPSec profile edit

IPSec profile edit

IPSec profile ☒ ON ☐ OFF

Profile name

Phase 1 parameters

Remote IPSec address

Key mode

Pre-shared key

Remote ID (xy.sample.com or blank)

Local ID (xy.sample.com or blank)

IKE mode

PFS

IKE encryption

IKE hash

DH group

IKE re-key time (0-78400, 0=Unlimited) secs

DPD action

DPD keep alive time secs

DPD timeout secs

SA life time (0-78400, 0=Unlimited) secs

Phase 2 parameters

Remote LAN address · · ·

Remote LAN subnet mask · · ·

Local LAN address · · ·

Local LAN subnet mask · · ·

Encapsulation type

IPSec encryption

IPSec hash

The following table describes each of the fields of the IPsec VPN Connection Settings page.

Table 8-9 IPsec Configuration Items

ITEM	DEFINITION
IPsec profile	Enables or disables the VPN profile.
Profile name	A name used to identify the VPN connection profile.
Remote IPsec address	The IP address or domain name of the IPsec server.
Key mode	Select the type of key mode in use for the VPN connection. You can select from: Pre Shared Key RSA keys Certificates
Pre-shared key	The pre-shared key is the key that peers used to authenticate each other for Internet Key Exchange.
Update Time	Displays the last time the key was updated.
Local RSA Key Upload	Select the RSA key file for the local router here by clicking the Browse button.
Remote RSA Key Upload	Select the RSA key file for the remote router here by clicking the Browse button.
Private key Passphrase	The Private key passphrase of the router is the passphrase used when generating the router's private key using OpenSSL CA.
Key / Certificate	Select the type of key or certificate to use for authentication. You can select Local private key, Local public certificate, Remote public certificate, CA certificate, CRL certificate.
IPsec Certificate Upload	Select the IPsec certificate to upload by clicking the Browse button.
Remote ID	Specifies the domain name of the remote network.
Local ID	Specifies the domain name of the local network.
IKE mode	Select the IKE mode to use with the VPN connection. You can choose Main, Aggressive or Any.
PFS	Choose whether Perfect Forward Secrecy is ON or OFF for the VPN connection.
IKE encryption	Select the cipher type to use for the Internet Key Exchange.
IKE hash	Select the IKE Hash type to use for the VPN connection. The hash is used for authentication of packets for the key exchange.

ITEM	DEFINITION
DH group	Select the desired Diffie-Hellman group to use. Higher groups are more secure but also require longer to generate a key.
IKE re-key time	Enter the time in seconds between changes of the encryption key. To disable changing the key, set this to 0.
DPD action	Select the desired Dead Peer Detection action. This is the action to take when a dead Internet Key Exchange Peer is detected.
DPD keep alive time	Enter the time in seconds for the interval between Dead Peer Detection keep alive messages.
DPD timeout	Enter the time in seconds of no response from a peer before Dead Peer Detection times out.
SA life time	Enter the time in seconds for the security association lifetime.
Remote LAN address	Enter the IP address of the remote network for use on the VPN connection.
Remote LAN subnet mask	Enter the subnet mask in use on the remote network.
Local LAN address	Enter the IP address of the local network for use on the VPN connection.
Local LAN subnet mask	Enter the subnet mask in use on the local network.
Encapsulation type	Select the encapsulation protocol to use with the VPN connection. You can choose ESP, AH or Any.
IPSec encryption	Select the IPSec encryption type to use with the VPN connection.
IPSec hash	Select the IPSec hash type to use for the VPN connection. The hash is used for authentication of packets for the VPN connection.

OpenVPN

OpenVPN is an open source virtual private network (VPN) program for creating point-to-point or server-to-multi-client encrypted tunnels between host computers. It can traverse network address translation (NAT) and firewalls and allows authentication by certificate, pre-shared key or username and password. OpenVPN works well through proxy servers and can run over TCP and UDP transports. Support for OpenVPN is available on several operating systems, including Windows, Linux, Mac OS, Solaris, OpenBSD, FreeBSD, NetBSD and QNX.

Configuring an Open VPN server

From the menu at the top of the screen, click Networking and from the VPN section on the left, click OpenVPN. A list of configured OpenVPN VPN connections is displayed.

Figure 8-51 OpenVPN VPN List


The screenshot shows a web interface for OpenVPN configuration. It contains three sections, each with a title and a '+ Add' button:

- OpenVPN server list**: The OpenVPN server list is empty.
- OpenVPN client list**: The OpenVPN client list is empty.
- OpenVPN P2P list**: The OpenVPN P2P list is empty.

Click the +Add button for the type of OpenVPN server/client you would like to configure.

OpenVPN Server

When you select the +Add button to add an OpenVPN server, the router checks whether there are existing server certificates. If no server certificate is found, you are informed that you must generate a certificate before configuring the OpenVPN server.



Click on the OK button to be taken to the Server certificate page. For more information on generating server certificates, refer to the Server certificate section of this guide. When you have created the certificate, return to the OpenVPN server configuration page and continue with the steps below.

To configure an OpenVPN Server:

1. Click the OpenVPN profile toggle key to switch it to the ON position.
2. Type a name for the OpenVPN server profile you are creating.
3. In the Type drop down list, select the OpenVPN connection type (TUN/TAP). Default is TUN.
4. Use the Server port field to select a port number and then use the drop down list to select a packet type to use for your OpenVPN Server. The default OpenVPN port is 1194 and default packet type is UDP.
5. In the VPN network address and VPN network subnet mask fields, enter the IP address and network subnet mask to assign to your VPN. This is ideally an internal IP address which differs from your existing address scheme.
6. The Server certificates section displays the details of the certificate. If you wish to change the certificate, click the Change button.
7. HMAC or Hash-based Message Authentication Code is a means of calculating a message authentication code through the use of a cryptographic hash function and a cryptographic key. If you wish to use the HMAC signature as an additional key and level of security, under the SSL/TLS handshake section, click the Use HMAC Signature toggle key so that it is in the ON position, then click the Generate button so that the

router can randomly generate the key. The Server key timestamp field is updated with the time that the key was generated. Click the Download button to download the key file so that it can be uploaded on the client.

8. Select an Authentication type. Authentication may be done using a Certificate or Username / Password.

Certificate Authentication

In the Certificate Management section, enter the required details to create a client certificate. All fields are required. When you have finished entering the details, click the Generate button.

Figure 8-52 OpenVPN server configuration – Certificate management

Certificate management

Certificate

Name

Country

State

City

Organisation

Email

Remote network address

Remote network subnetmask

When it is done, you can click the Download P12 button or the Download TGZ button to save the certificate file depending on which format you would like. If for some reason the integrity of your network has been compromised, you can return to this screen and use the Certificate drop down list to select the certificate and then press the Revoke button to disable it.

Optional: To inform the OpenVPN server of the network address scheme of the currently selected certificate, enter the network address and network subnet mask in the respective fields and click the Set network information button. If you do not enter the remote subnet here, any packet requests from the server to the client will not be received by the client network because it is not aware of the remote client's subnet.

Figure 8-53 OpenVPN server profile settings

OpenVPN server edit

OpenVPN profile ☒ ON ☐ OFF

Profile name

Type

Server port

VPN network address

VPN network subnet mask

Server certificates

Not before Mar 13 04:21:03 2015 GMT

Not after Mar 10 04:21:03 2025 GMT

Country AU

State NSW

City Sydney

Organisation NetComm Wireless

Email techsupport@netcommwireless.com

SSL/TLS handshake

Use HMAC Signature ☒ ON ☐ OFF

Server key timestamp 2015-03-13 16:49:48

Authentication type

☒ Certificate ☐ Username / Password

Certificate management

Certificate

Name

Country

State

City

Organisation

Email

Remote network address

Remote network subnetmask

Username / Password Authentication

In the Username/Password section, enter the username and password you would like to use for authentication on the OpenVPN Server. Click the Download CA certificate or Download CA TGZ depending on file format button to save the ca.crt file. This file will need to be provided to the client.



Note: If you wish to have more than one client connect to this OpenVPN server, you must use Certificate authentication mode as Username/Password only allows for a single client connection.

Figure 8-54 OpenVPN Server – Username / Password section

The screenshot shows a web interface titled "Username / Password". It contains the following elements:

- Username** and **Password** text input fields.
- Download CA TGZ** and **Download CA certificate** buttons.
- Remote network address** and **Remote network subnetmask** fields, each consisting of four small input boxes (all containing "0").
- Set network information** button.
- Save** (blue) and **Exit** (grey) buttons at the bottom.

Optional: To inform the OpenVPN server of the network address scheme of the currently selected certificate, enter the network address and network subnet mask in the respective fields and click the Set Network Information button. If you do not enter the remote subnet here, any packet requests from the server to the client will not be received by the client network because it is not aware of the remote client's subnet.

When you have finished entering all the required information, click Save to finish configuring the OpenVPN server.


Configuring an OpenVPN Client

1. Click the OpenVPN profile toggle key to switch it to the ON position.
2. In the Profile name field, type a name for the OpenVPN client profile you are creating.
3. In the Server IP address field, type the WAN IP address /host domain name of the OpenVPN server.
4. Select OpenVPN connection type (TUN/TAP). Default is TUN.
5. Use the Server port field to select a port number and then use the drop down list to select a packet type to use for the OpenVPN server. The default OpenVPN port is 1194 and default packet type is UDP.
6. If the Default gateway option is applied on the OpenVPN client page, the OpenVPN server will enable connections to be made to other client networks connected to it. If it is not selected, the OpenVPN connection allows for secure communication links between this router and the remote OpenVPN server only.
7. Use the Authentication type options to select the Authentication type that you would like to use for the OpenVPN client.

Certificate Authentication

In the Certificate upload section at the bottom of the screen, click the Browse button and locate the certificate file you downloaded when you configured the OpenVPN server. When it has been selected, click the Upload button to send it to the router.

Figure 8-55 OpenVPN client - Certificate upload




The screenshot shows a section titled "Certificate upload". It contains two buttons: "Choose a file" and "Upload".

Username / Password Authentication

Enter the username and password to authenticate with the OpenVPN server.

Figure 8-56 OpenVPN Client - Username/Password section



The screenshot shows the "Username / Password" section. It includes fields for "Username" and "Password". Below these is the "Select certificate" section, which has a "Certificate" dropdown menu and a "Delete" button. Further down are "Not before" and "Not after" fields, both showing "N/A". At the bottom is the "CA upload" section, which includes a "Choose file" button and an "Upload" button.

Use the Browse button to locate the CA certificate file you saved from the OpenVPN Server and then press the Upload button to send it to the router.

Click the Save button to complete the OpenVPN Client configuration.

Configuring an OpenVPN P2P Connection

To configure an OpenVPN peer-to-peer connection:

1. Set the OpenVPN profile toggle key to switch it to the ON position.
2. In the Profile name field, type a name for the OpenVPN P2P profile you are creating.
3. On the router designated as the server, leave the Server IP address field empty. On the router designated as the client, enter the WAN IP address/host domain name of the server.

Figure 8-57 OpenVPN P2P mode settings

OpenVPN peer edit

OpenVPN profile ☒ ON ☐ OFF

Profile name

Server IP address
(leave empty if it's a peer-to-peer server)

Server port

Local IP address

Remote IP address

Remote network

Address

Subnet mask

Server secret key

Update time N/A

Client secret key

Update time N/A

Client secret key upload

4. Use the Server port field to select a port number and then use the drop down list to select a packet type to use for the OpenVPN server. The default OpenVPN port is 1194 and default packet type is UDP.
5. In the Local IP Address and Remote IP Address fields, enter the respective local and remote IP addresses to use for the OpenVPN tunnel. The slave should have the reverse settings of the master.
6. Under the Remote network section, enter the network Address and network Subnet mask. The Network Address and Network Mask fields inform the Master node of the LAN address scheme of the slave.
7. Press the Generate button to create a secret key to be shared with the slave. When the timestamp appears, you can click the Download button to save the file to exchange with the other router.
8. When you have saved the secret key file on each router, use the Browse button to locate the secret key file for the master and then press the Upload button to send it to the slave. Perform the same for the other router, uploading the slave's secret key file to master.
9. When they are uploaded click the Save button to complete the peer-to-peer OpenVPN configuration.

PPTP client


The Point-to-Point Tunneling Protocol (PPTP) is a method for implementing virtual private networks using a TCP and GRE tunnel to encapsulate PPP packets. PPTP operates on Layer 2 of the OSI model and is included on Windows computers.

Configuring the PPTP client

To configure the PPTP client:

1. From the menu bar at the top of the screen, click Networking and then from the VPN section on the left side of the screen, click PPTP client. The PPTP client list is displayed.

Figure 8-58 PPTP client list



2. Click the +Add button to begin configuring a new PPTP client profile. The PPTP client edit screen is displayed.

Figure 8-59 VPN PPTP client edit

VPN PPTP client edit

Enable PPTP client ☒ ON ☐ OFF

Profile name

Username

Password

PPTP server

Authentication type

Metric (0-65535)

Use peer DNS ☐ ON ☒ OFF

NAT masquerading ☐ ON ☒ OFF

Set PPTP server as default gateway ☐ ON ☒ OFF

MPPE ☒ ON ☐ OFF

Extra PPP option

Verbose logging ☐ ON ☒ OFF

Reconnect delay (30-65535) seconds

Reconnect retries (0-65535, 0=Unlimited)

3. Click the Enable PPTP client toggle key to switch it to the ON position.

4. In the Profile name list, enter a profile name for the tunnel. This may be anything you like and is used to identify the tunnel on the router.
5. Use the Username and Password fields to enter the username and password for the PPTP account.
6. In the PPTP server address field, enter the IP address /host domain name of the PPTP server.
7. From the Authentication type drop down list, select the Authentication type used on the server. If you do not know the authentication method used, select any and the router will attempt to determine the correct authentication type for you. There are 5 authentication types you can choose from:
 - CHAP – uses a three way handshake to authenticate the identity of a client.
 - MS-CHAP v1 – This is the Microsoft implementation of the Challenge Handshake Authentication Protocol for which support was dropped in Windows® Vista.
 - MS-CHAP v2 - This is the Microsoft implementation of the Challenge Handshake Authentication Protocol which was introduced in Windows® NT 4.0 and is still supported today.
 - PAP – The Password Authentication Protocol uses a password as a means of authentication and as such, is commonly supported. PAP is not recommended because it transmits passwords unencrypted and is not secure.
 - EAP – Extensible Authentication Protocol. An Authentication protocol commonly used in wireless networks.
8. The metric value helps the router to prioritize routes and must be a number between 0 and 65535. The default value is 30 and should not be modified unless you are aware of the effect your changes will have.
9. The Use peer DNS option allows you to select whether the remote clients will use the Domain Name Server of the PPTP server. Click the toggle key to set this to ON or OFF as required.
10. NAT masquerading allows the router to modify the packets sent and received to inform remote computers on the internet that packets originating from a machine behind the router actually originated from the WAN IP address of the router's internal NAT IP address. Click the toggle key to switch this to the ON position if you want to use this feature.
11. Set default route to PPTP sets all outbound data packets to go out through the PPTP tunnel. Click the toggle key to switch this to the ON position if you want to use this feature.
12. The Verbose logging option sets the router to output detailed logs regarding the PPTP connection in the System Log section of the router interface.
13. The Reconnect delay is the time in seconds that the router will wait before attempting to connect to the PPTP server in the event that the connection is broken. The minimum time to wait is 30 seconds so as to not flood the PPTP server with connection requests, while the maximum time to wait is 65335 seconds.
14. The Reconnect retries is the number of connection attempts that the router will make in the event that the PPTP connection goes down. If set to 0, the router will retry the connection indefinitely, otherwise the maximum number of times to retry cannot be greater than 65335.
15. Click the Save button to save the changes. The VPN will attempt to connect after your click Save. Click the Status button at the top left of the interface to return to the status window and monitor the VPN's connection state.

GRE tunnelling

The Generic Route Encapsulation (GRE) protocol is used in addition to Point-to-Point Tunnelling Protocol (PPTP) to create VPNs (virtual private networks) between clients and servers or between clients only. Once a PPTP control session establishes the VPN tunnel GRE is used to securely encapsulate the data or payload.

Configuring GRE tunnelling

To configure GRE tunnelling:

1. From the menu bar at the top of the screen, click Networking and then from the VPN section on the left side of the screen, click GRE. The GRE client list is displayed.

Figure 8-60 GRE client list



2. Click the +Add button to begin configuring a new GRE tunnelling client profile. The GRE Client Edit screen is displayed.

Figure 8-61 GRE client edit

3. Click the Enable GRE Tunnel toggle key to switch it to the ON position.
4. In the Profile name, enter a profile name for the tunnel. This may be anything you like and is used to identify the tunnel on the router.
5. In the GRE server address field, enter the IP address or domain name of the GRE server.
6. In the Local tunnel address field, enter the IP address you want to assign the tunnel locally.
7. In the Remote tunnel address field, enter the IP address you want to assign to the remote tunnel.
8. In the Remote network address field, enter the IP address scheme of the remote network.
9. In the Remote network subnetmask field, enter the subnet mask of the remote network.


10. The TTL (Time To Live) field is an 8-bit field used to remove an undeliverable data packet from a network to avoid unnecessary network traffic across the internet. The default value of 255 is the upper limit on the time that an IP datagram can exist. The value is reduced by at least one for each hop the data packet takes to the next router on the route to the datagram's destination. If the TTL field reaches zero before the datagram arrives at its destination the data packet is discarded and an error message is sent back to the sender.
11. The Verbose logging option sets the router to output detailed logs regarding the GRE tunnel in the System Log section of the router interface.
12. The Reconnect delay is the time in seconds that the router will wait before attempting to connect to the GRE server in the event that the connection is broken. The minimum time to wait is 30 seconds so as to not flood the GRE server with connection requests, while the maximum time to wait is 65335 seconds.
13. The Reconnect retries is the number of connection attempts that the router will make in the event that the GRE connection goes down. If set to 0, the router will retry the connection indefinitely, otherwise the maximum number of times to retry cannot be greater than 65335.
14. Click the Save button to save the changes. The VPN will attempt to connect after your click Save. Click the Status button at the top left of the interface to return to the status window and monitor the VPN's connection state.

9. Services

Dynamic DNS

The DDNS page is used to configure the Dynamic DNS feature of the router. A number of Dynamic DNS hosts are available from which to select. To access the Dynamic DNS page, click on the Services menu at the top of the screen then click on the Dynamic DNS menu item on the left.

Figure 9-1 Dynamic DNS settings



DDNS configuration

DDNS configuration ☒ ON ☐ OFF

Dynamic DNS

Host name

Username

Password

Verify password

Save

Dynamic DNS provides a method for the router to update an external name server with the current WAN IP address.

To configure dynamic DNS:

1. Click the DDNS configuration toggle key to switch it to the ON position.
2. From the Dynamic DNS drop down list, select the Dynamic DNS service that you wish to use. The available DDNS services available are:
 - www.dhs.org
 - www.dyndns.org
 - www.dyns.cx
 - www.easydns.com
 - www.justlinux.com
 - www.no-ip.com
 - www.ods.org
 - www.tzo.com
 - www.zoneedit.com
3. Enter your hostname in 'Host name' field.
4. In the Username and Password fields, enter the logon credentials for your DDNS account. Enter the password for the account again in the Verify password field.
5. Click the Save button to save the DDNS configuration settings.

Network time (NTP)

The NTP (Network Time Protocol) settings page allows you to configure the NTC-140 Series router to synchronize its internal clock with a global Internet Time server and specify the time zone for the location of the router. This provides an accurate timekeeping function for features such as System Log entries and Firewall settings where the current system time is displayed and recorded. Any NTP server available publicly on the internet may be used. The default NTP server is 0.netcomm.pool.ntp.org.

To access the Network time (NTP) page, click on the Services menu at the top of the screen then click on the Network time (NTP) menu item on the left.

Figure 9-2 NTP settings

The screenshot displays the 'Timezone settings' and 'NTP settings' sections of a router's configuration interface. Under 'Timezone settings', the 'Current time' is 'Wed Nov 5 16:03:25 EST 2014'. The 'Timezone' is set to '(GMT+10:00) Australia/Sydney' via a dropdown menu. A link for 'Daylight savings time schedule' is visible below the dropdown. The 'NTP settings' section includes a 'Network time (NTP)' toggle set to 'ON', an 'NTP service' text field containing '0.netcomm.pool.ntp.org', a 'Synchronisation on WWAN connection' toggle set to 'ON', and a 'Daily synchronisation' toggle set to 'ON'. A 'Save' button is located at the bottom of the settings area.

Configuring Timezone settings

To configure time zone settings:

1. The Current time field shows the time and date configured on the router. If this is not accurate, use the Time zone drop down list to select the correct time zone for the router. If the selected zone observes daylight savings time, a [Daylight savings time schedule](#) link appears below the drop down list. Click the link to see the start and end times for daylight savings.
2. When you have selected the correct time zone, click the Save button to save the settings.

Configuring NTP settings

1. To configure NTP settings:
2. Click the Network time (NTP) toggle key to switch it to the ON position.
3. In the NTP service field, enter the address of the NTP server you wish to use.
4. The Synchronization on WWAN connection toggle key enables or disables the router from performing a synchronization of the time each time a mobile broadband connection is established.
5. The Daily synchronisation toggle key enables or disables the router from performing a synchronization of the time each day.

- When you have finished configuring NTP settings, click the Save button to save the settings.

Data stream manager

The data stream manager provides you with the ability to create mappings between two endpoints on the router. These endpoints may be physical or virtual, for example, a serial port connected to the router's USB port could be configured as an endpoint or you could configure a TCP Server as an endpoint. You can then configure a virtual data tunnel or "stream" between the endpoints.

The data stream manager provides a wide range of possibilities and expands upon simple PAD functionality to include the forwarding and translation of data between any of the endpoints. For example, you could send the GPS data from the built-in module to a TCP server running on the router. In each case, the logical flow of the stream is from Endpoint A to Endpoint B.

Customers interested in developing their own applications to create custom endpoints and streams can contact Lantronix about our Software Development Kit.

Endpoints

The first thing to be done in order to create a data stream is to define the endpoints. There are 7 types of endpoint that may be configured:

- Serial port (generic)
- TCP Server
- TCP Client
- UDP Server
- UDP Client
- GPS Data
- User defined executable

Figure 9-3 Endpoints list

The screenshot shows a web interface titled "Endpoints list" with a "+ Add" button in the top right corner. Below the title is a table with three columns: "Name", "Type", and "Summary".


Name	Type	Summary
Serialport	Serial port (generic)	bit_rate: 115200 data_bits: 8 dev_name: sys.hw.class.serial.3.name parity: none stop_bits: 1
TCPserver	TCP server	keep_alive: 0 keepcnt: keepidle: keepintvl: max_children: 5 port_number: 5000

Each row in the table has two icons on the right: a pencil icon for editing and an 'x' icon for deleting. At the bottom of the interface are two buttons: "Save" and "Cancel".

Serial port (generic)

This creates a generic serial port as an endpoint defaulting to the commonly used settings as shown below.

Figure 9-4 Serial port (generic) endpoint configuration (Custom)



Serial port (generic) endpoint (Serialport)

Host port: Custom

Custom host port name:

Baud rate: 115200

Data bits: 8 bits

Stop bits: 1

Parity: None

Save Cancel

When the Host port is set to Custom, you can use the Custom host port name field to manually specify a device path to use, for example, if using a USB-to-Serial adapter you could telnet to the router and issue the command `ls /dev/ttyUSB*` to list the paths of the connected USB devices. To determine the path of the desired USB adapter, issue the command when the adapter is not connected then run the command again when the adapter is connected and compare the output.




Note: Using a custom host port name is not recommended for normal use as the device path can change between power cycles of the router.

TCP server

This creates a TCP server endpoint with the following options available.

Figure 9-5 TCP server endpoint configuration



TCP server endpoint (TCPserver)

Port number: 1-65535

Keepalive: ON OFF

Keepalive count: 1-50

Keepalive idle: 1-10000 seconds

Keepalive interval: 1-1000 seconds


Max clients: 1-20

Save Cancel

TCP client

This creates a TCP client endpoint with the following options available. The retry timeout period specifies the number of seconds to wait between attempts to re-establish a connection in the event that it is lost. The client will attempt re-connection indefinitely every Retry timeout interval.

Figure 9-6 TCP client endpoint configuration




The form is titled "TCP client endpoint (TCPclient)" in orange. It contains the following fields and controls:

- IP address**: A text input field.
- Port number**: A text input field with a range indicator "1-65535" to its right.
- Keepalive**: A toggle switch with "ON" (selected) and "OFF" options.
- Keepalive count**: A text input field with a range indicator "1-50" to its right.
- Keepalive idle**: A text input field with a range indicator "1-10000 seconds" to its right.
- Keepalive interval**: A text input field with a range indicator "1-1000 seconds" to its right.
- Retry timeout**: A text input field with a range indicator "0-1000 seconds (0 = No retry)" to its right.
- At the bottom, there are two buttons: "Save" (blue) and "Cancel" (gray).

UDP server

This creates a UDP server endpoint with the following options available.

Figure 9-7 UDP server endpoint configuration



The form is titled "UDP server endpoint (UDPserver)" in orange. It contains the following fields and controls:

- Port number**: A text input field with a range indicator "1-65535" to its right.
- Max clients**: A text input field with a range indicator "1-20" to its right.
- At the bottom, there are two buttons: "Save" (blue) and "Cancel" (gray).

UDP client

This creates a UDP client endpoint with the following options available. The retry timeout period specifies the number of seconds to wait between attempts to re-establish a connection in the event that it is lost. The client will attempt re-connection indefinitely every Retry timeout interval.

Figure 9-8 UDP client endpoint configuration

UDP client endpoint (UDPclient)

IP address

Port number 1-65535

Retry timeout 0-1000 seconds (0 = No retry)

GPS data

This creates a GPS data endpoint.



Note: You must have GPS enabled before you can create this endpoint.

Figure 9-9 GPS data endpoint configuration

GPS data endpoint (GPSData)

User defined executable

Allows you to specify an executable and parameters to be used as an endpoint. For example, the following executable reads the phone module temperature every second.

```
while true; do rdb_get wwan.0.radio.temperature; sleep 1; done
```

The temperature can then be sent to another endpoint.

Figure 9-10 User defined executable endpoint configuration

User defined executable endpoint ()

Command

Table 9-1 Modem emulator endpoint options

ITEM	DESCRIPTION
Host port	Use the drop down list to select the serial port to use. If no USB-to-Ethernet adapter is connected, the only available selection is the Built-in serial port.
Baud rate	The serial (V.24) port baud rate. By default the serial line format is 8 data bits, No parity, 1 Stop bit.

ITEM	DESCRIPTION
	Refer to the AT (V.250) AT Command Manual if you need to change the serial line format.
Data bits	The default serial line data bits setting used is 8. Options include 5 – 8 bits.
Stop bits	The default stop bit setting is set to 1. However the stop bit setting can be set to 2 bits if required.
Parity	Parity is the means to detect transmission errors. An extra data bit is transmitted with each data character, and is arranged in a fashion such that the number of 1 bits in each character, including the parity bit, is always odd or always even. If a byte is received with the wrong number of 1s, then this shows the data must be corrupt. Options include none, odd or even. The default setting is none for no parity checks.
Hardware flow control	- Off - Serial port flow control off - Hardware - Serial port uses RTS/CTS flow control
Software flow control	Enables or disables software flow control.
DSR action	Sets the Data Set Ready action. This is an output from the modem and this configuration determines the pin's behavior. - Always: DSR is always on. - Registered: When connected to a CSD endpoint, sets pin to "on" when modem is in data mode. - Session established: When connected to PPP endpoint, sets pin on when PDP is connected, when connected to IP modem endpoint, sets pin to on when modem is in online state (e.g. data connection is established). - Never: DSR is always off. - Mimic DTR: mimics the DTR pin.
DCD action	Determines how the router controls the state of the serial port Data Carrier Detect (DCD) line. - Always On: DCD is always on. - Connect: DCD is on when a connection is established in response to an ATD command or DTR dial. - Session established: Pin is on when PPP session is in progress or modem is in an online state (e.g. data connection is established). - Always Off: DCD is always off.
DTR action	Determines how the router responds to change of state of the serial port DTR line - Ignore - Take no action - Enter Command State – when connected to PPP endpoint, this is equivalent to disconnect. When connected to IP modem or CSD endpoint, this enters online command state (e.g. process AT commands without dropping the connection).

ITEM	DESCRIPTION
	• Disconnect – terminates connection.
RI action	Determines how the router controls the state of the serial port RI (Ring Indicator) line. • Always On: RI is always on. • Incoming Ring: RI is on when an incoming connection request is received. • Always Off: RI is always off
RI action	Determines how the router controls the state of the serial port RI (Ring Indicator) line. • Always On: RI is always on. • Incoming Ring: RI is on when an incoming connection request is received. • Always Off: RI is always off
Enable auto answer	When enabled, the router accepts incoming connections.
Circuit auto answer rings	Sets the number of incoming rings after which the router will answer incoming circuit switched data calls. The default value is Off. The other available options are from 1 to 12.
Advanced status	
Echo enable	Enables echo on the serial side. All commands are echoes. This can be turned on/off via ATE1 and ATE0 commands. Recommended setting for this option is ON.
Quiet mode	When on, there is no output from the modem on the serial side, i.e. you do not see OK, Connect etc. Recommended setting for this option is OFF.
Send OK on carriage return	If enabled, will print OK every time CR is received on the serial side. Recommended setting for this option is ON.
Suppress line feeds	If enabled, line termination is using CR (13). If disabled, line termination is CR LF (13 10). Recommended setting for this option is OFF.
Send OK on unknown command	Will send OK when an unknown/invalid AT command is received. Recommended setting for this option is ON.
Verbose mode	The modem returns messages to the computer to indicate the return status of commands and interrupts such as incoming call and call progress. Recommended setting for this option is ON.

To create an endpoint:

1. Click the +Add button on the right side of the page. A pop-up window appears.

Figure 9-11 Creating an endpoint

2. In the Endpoint name field, type a name for this endpoint. The name can contain alphanumeric characters only i.e. A-Z, a- z, 0-9.
3. Use the Endpoint types drop down list to select the type of endpoint to configure.
4. Click the OK button. The router displays a screen with configuration options for your chosen endpoint type. Enter the options for your endpoint as required.
5. Click the Save button. The Endpoints list is displayed with the newly created endpoint listed and a summary of the settings your configured.

Figure 9-12 Endpoints list

Name	Type	Summary
serial	Serial port (generic)	bit_rate:115200 data_bits:8 parity:none stop_bits:1

Streams

When you have created the required endpoints, you can then proceed to set up a data stream. A data stream sends data from one endpoint to another, performing any transformation of the data as required. When a stream is added, an underlying process on the router checks the validity of the stream, checking for conflicts and illogical configurations. To access the Streams page, click on the Services menu at the top of the screen, click on the Data stream manager menu then click on the Streams menu item on the left.

Note:



- When any changes to the Data stream manager configuration are detected, all data streams are stopped and restarted as per the new configuration.
- Multiple Modbus clients cannot connect simultaneously to Modbus serial slaves connected to the router.

Every stream requires two endpoints, Endpoint A and Endpoint B. In all cases, the flow of data is from Endpoint A to Endpoint B. To create a new stream:

1. Click the +Add button on the right side of the page.

Figure 9-13 Data stream list



The Edit data stream page is displayed.

2. In the Data stream name field, enter a name for the Data stream.
3. Under Endpoint A, use the Endpoint name drop down list to select one of the endpoints you created previously. This endpoint should be the starting point of the stream. Use the Mode drop down list to select the mode of operation of the endpoint. The mode can be thought of as a transformation of the data as it leaves this endpoint. For example, if Endpoint A type is Serial port (generic), the Mode can be set to various Modbus server and client types. This means that upon arrival at Endpoint A, the data will be transformed into the chosen Modbus format, ready to be sent to Endpoint B.
4. Under Endpoint B, use the Endpoint name drop down list to select one of the endpoints you created previously. This endpoint should be the destination of the stream. The screenshot below shows a configuration sending data received on an attached serial port to a TCP server running on the router. Use the Mode drop down list to select the mode of operation of the endpoint. The mode can be thought of as a transformation of the data as it arrives at this endpoint.

Figure 9-14 Edit data stream

5. Click the Save button. The new stream appears in the Data stream list.

Figure 9-15 Data Stream List

Data stream list + Add

Name	Endpoint A	Mode	Endpoint B	Mode	Enabled	Status		
SerialtoTCP	Serial	Raw	TCPserver	Raw	Enabled	Running		

Save Cancel

Data stream applications

Table 9-2 Data stream applications

ENDPOINT A	ENDPOINT B	ENDPOINT A MODE / ENDPOINT B MODE	ENDPOINTS CAN BE REVERSED	UNDERLYING PROCESS	APPLICATION
1 (Serial), 8 (RS232), 9 (RS485), 10 (RS422)	1 (Serial), 8 (RS232), 9 (RS485), 10 (RS422)	Raw/Raw	N/A	socat	Serial to serial raw data stream
1 (Serial), 8 (RS232), 9 (RS485), 10 (RS422)	2 (TCP Server), 3 (TCP Client), 4 (UDP Server), 5 (UDP Client)	Raw/Raw	Yes	socat	Serial to IP data stream
2 (TCP Server), 4 (UDP Server)	3 (TCP Client), 5 (UDP Client)	Raw/Raw	Yes	socat	Client to server data stream
1 (Serial), 8 (RS232), 9 (RS485), 10 (RS422)	3 (TCP Client)	Modbus Client Agent ASCII, Modbus Client Agent RTU/raw	No	dsm_data_mover	Modbus Client Agent functionality
1 (Serial), 8 (RS232), 9 (RS485), 10 (RS422)	2 (TCP Server)	Modbus Server Gateway ASCII, Modbus Server Gateway RTU/raw	No	dsm_data_mover	Modbus Server Gateway functionality

ENDPOINT A	ENDPOINT B	ENDPOINT A MODE / ENDPOINT B MODE	ENDPOINTS CAN BE REVERSED	UNDERLYING PROCESS	APPLICATION
1 (Serial), 8 (RS232), 9 (RS485), 10 (RS422)	6 (GPS)	Raw/Raw	Yes	socat	Send GPS data to serial port
1 (Serial), 8 (RS232), 9 (RS485), 10 (RS422)	7 (User Executable)	Raw/Raw	Yes	socat	Send standard output of user- executable program to serial port
2 (TCP Server), 3 (TCP Client), 4 (UDP Server), 5 (UDP Client)	6 (GPS)	Raw/Raw	Yes	socat	Send GPS data to TCP or UDP client or server
2 (TCP Server), 3 (TCP Client), 4 (UDP Server), 5 (UDP Client)	7 (User Executable)	Raw/Raw	Yes	socat	Send standard output of user- executable program to TCP or UDP client or server
11 (Modem Emulator)	12 (PPP Server)	Raw/Raw	Yes	modem_emul_ ep	Router terminated PPP Server functionality for dial-up PPP clients
11 (Modem Emulator)	13 (IP Modem)	Raw/Raw	Yes	modem_emul_ ep	Modem emulation and tunneling via TCP/UDP (replacement for PAD Mode of the

ENDPOINT A	ENDPOINT B	ENDPOINT A MODE / ENDPOINT B MODE	ENDPOINTS CAN BE REVERSED	UNDERLYING PROCESS	APPLICATION
					old Modem Emulator)
11 (Modem Emulator)	14 (CSD)	Raw/Raw	Yes	modem_emul_ep	Circuit Switched Data calls via 3G/4G module and mobile networks
1 (Serial), 8 (RS232), 9 (RS485), 10 (RS422)	15 (TCP Client Connect on Demand)	Raw/Raw	Yes	dsm_data_mover	Serial to TCP server connection, which is initiated ONLY when data is seen on serial port

PADD

PAD Daemon is a tool used to encapsulate raw serial data into a TCP packet to be transported over IP to another end point. The server receiving the TCP packets unpacks the data and the original raw serial data is passed out of its serial port to the attached device, thereby creating an invisible IP network to the two serial devices.

The PAD Daemon runs as a background process which can be accessed via the web configuration interface. The PADD configuration page is located under “Services > PADD”. The PADD is used usually with multiple connections or when redundant connections are needed. The PADD has two modes: the PADD TCP/IP Server mode and PADD TCP/IP Client Mode. When PADD is enabled, both the PADD server mode and PADD client mode can be run at the same time.

To access the PADD configuration page, click on the Services menu at the top of the screen then click on the PADD menu item on the left.

Figure 9-16 PADD

PADD

Activate ☒ ON ☐ OFF

Serial port status No conflicts

Debug level (0-2)

Serial port settings

Host port

Baud rate

Data bits

Stop bits

Parity

Flow control

Inter character timeout (x100ms)

End-of-line character ASCII code

Start of line timestamps ☒ Off ☐ YYYYMMDDHHMMSS

TCP/IP Server

Listening port 1-65535

Incoming connection is ☒ Exclusive ☐ Shared

TCP/IP Client

Connect to ☐ First available ☒ All available

Remote Host 1 Server:Port

Remote Host 2 Server:Port

Remote Host 3 Server:Port

Remote Host 4 Server:Port

Network

Remote server retry period 1-65535 seconds

TCP Keepalive Probes 0-65535 seconds (0=disabled)

Number of probe failures before disconnect 1 - 20

Remote management

SNMP

SNMP configuration

The SNMP page is used to configure the SNMP features of the router.

Figure 9-17 SNMP configuration

SNMP configuration

SNMP ☒ ON ☐ OFF

Read-only community name

Read-write community name

Download MIB File (This is a brief version of the MIB file only)

SNMP traps

Trap destination (IP address)

Heartbeat interval (seconds)

Trap persistence Time (seconds)

Trap retransmission Time (seconds)

SNMP (Simple Network Management Protocol) is used to remotely monitor the router for conditions that may warrant administrative attention. It can be used to retrieve information from the router such as the signal strength, the system time and the interface status.

To configure SNMP:

1. Click the SNMP toggle key to switch it to the ON position.
2. Enter Read-only community name and Read-write community name which are used for client authentication.



Warning: Community names are used as a type of security to prevent access to reading and/or writing to the routers configuration. It is recommended that you change the Community names to something other than the default settings when using this feature.

3. Click the Save button to save any changes to the settings.

The Download button displays the Management Information Base (MIB) of the router. The MIB displays all the objects of the router that can have their values set or report their status. The MIB is formatted in the SNMP-related standard RFC1155.

SNMP traps


SNMP traps are messages from the router to the Network Management System sent as UDP packets. They are often used to notify the management system of any significant events such as whether the link is up or down.

Configuring SNMP traps

To configure SNMP traps:

1. In the Trap destination field, enter the IP address to which SNMP data is to be sent.
2. In the Heartbeat interval field, enter the number of seconds between SNMP heartbeats.
3. Use the Trap persistence field to specify the time in seconds that an SNMP trap persists.
4. Use the Trap retransmission time to specify the length of time in seconds between SNMP trap retransmissions.

Figure 9-18 SNMP traps

The image shows a web-based configuration interface for SNMP traps. It has a title "SNMP traps" in orange. Below the title are four configuration fields, each with a label, a text input box, and a unit in parentheses. The fields are: "Trap destination" with the value "192.168.1.101" and unit "(IP address)"; "Heartbeat interval" with the value "43200" and unit "(seconds)"; "Trap persistence time" with the value "500" and unit "(seconds)"; and "Trap retransmission time" with the value "21600" and unit "(seconds)". Below these fields are two buttons: a light gray "Send heartbeat" button and a blue "Save" button.

To send a manual SNMP Heartbeat, click the Send heartbeat button. When you have finished configuring the SNMP traps, click the Save button to save the settings.



Note: When a factory reset is performed via SNMP, the SNMP settings are preserved.

TR-069

To access the TR-069 configuration page, click the Services menu item, then select the TR-069 menu item on the left.

Figure 9-19 TR-069 configuration

TR-069 configuration

Enable TR-069 ☒ ON ☐ OFF

ACS URL

ACS username

ACS password

Verify ACS password

Connection request username

Connection request password

Verify connection request password

Enable periodic ACS informs ☒ ON ☐ OFF

Inform period (30-2592000) secs

Last inform status

Start at

End at

TR-069 DeviceInfo

Manufacturer NetComm Wireless Limited

ManufacturerOUI 006064

ModelName ntc_6908

Description NetComm NTC-6000 Series Cellular Router

ProductClass 6900 Series

SerialNumber 4456B7

The TR-069 (Technical Report 069) protocol is a technical specification also known as CPE WAN Management Protocol (CWMP). It is a framework for remote management and auto-configuration of end-user devices such as customer-premises equipment (CPE) and Auto Configuration Servers (ACS). It is particularly efficient in applying configuration updates across networks to multiple CPEs.

TR-069 uses a bi-directional SOAP/HTTP-based protocol based on the application layer protocol and provides several benefits for the maintenance of a field of CPEs:

- Simplifies the initial configuration of a device during installation
- Enables easy restoration of service after a factory reset or replacement of a faulty device
- Firmware and software version management
- Diagnostics and monitoring



Note: You must have your own compatible ACS infrastructure to use TR-069. In order to access and configure the TR-069 settings you must be logged into the router as the root user.



Note: When a factory reset of the router is performed via TR-069, the TR-069 settings are preserved.

TR-069 configuration

To configure TR-069:

1. Click the Enable TR-069 toggle key to switch it to the ON position.
2. In the ACS URL field, enter the Auto Configuration Server's full domain name or IP address.
3. Use the ACS username field to specify the username for the Auto Configuration Server.
4. In the ACS password and Verify ACS password fields, enter the Auto Configuration Server password.
5. In the Connection Request Username field, enter the username to use for the connection requests.
6. In the Connection Request Password and Verify password fields, enter the connection request password.
7. The inform message acts as a beacon to inform the ACS of the existence of the router. Click the Enable periodic ACS informs toggle key to turn on the periodic ACS inform messages.
8. In the Inform Period field, enter the number of seconds between the inform messages.
9. Click the Save button to save the settings.

OMA Lightweight M2M configuration



Note: The OMA Lightweight M2M specification has not yet been finalised. As such, the current implementation of OMA-LWM2M is experimental and should not be deployed for regular use. We also do not recommend using OMA-LWM2M while the router is connected to an APN providing a publicly routable IP address.

The OMA Lightweight M2M (OMA-LWM2M) protocol was designed by the Open Mobile Alliance to provide remote device management specifically for M2M devices. It is less taxing on the system and network than OMA-DM and TR-069. OMA-LWM2M runs over UDP and supports asynchronous notifications when a resource changes.

It provides:

- Firmware upgrades
- Device monitoring and configuration
- Server provisioning

Figure 9-20 OMA Lightweight M2M configuration

OMA Lightweight M2M configuration

Enable LWM2M ☒ ON ☐ OFF

Server URL

Bootstrap ☐ ON ☒ OFF

Security type ▼

Client id

Client key

Advanced Settings

Listen port (normal)

Listen port (secure)

Respond to any IP ☐ ON ☒ OFF

Read only ☐ ON ☒ OFF

Table 9-3 OMA Lightweight M2M configuration options

ITEM	DESCRIPTION
Enable LWM2M	Toggles the OMA-LWM2M function on and off.
Server URL	The URL of the LWM2M server. This must begin with coap:// or coaps:// and include the server port number. The correct syntax for this field is coap://<server IP or domain name>:<port number>. The Server URL field performs validation on the entered address so the field must contain an address in the correct format.
Listen port (normal)	The port that the router listens on for LWM2M.
Listen port (secure)	When using DTLS (coaps), enter the port that the router listens on for secure connections.
Security type (only used when Server	NoSec – When selected, this uses DTLS with the NULL cipher, therefore, it provides no security.

ITEM	DESCRIPTION
URL starts with coaps://)	PSK – Pre-shared key mode. Keys are typically a string of text saved into a text file. We recommend creating a key at least 32 bytes in size to enhance your security.
	RPK – Raw Public Key. The key is an EC key in DER format. It must contain both public and private keys. When RPK is selected, the Client ID field is not used. You can generate a raw public key using commands such as: <pre>openssl ecparam -out 256.key -name secp256r1 -genkey openssl ec -in 256.key -outform der -out 256.der</pre>
Client id (only used when Server URL starts with coaps:// and Security type is PSK)	When server is a coaps:// address and security type is set to PSK, the Client id acts as a means of identifying the client, similar to a username.
Client key (only used when Server URL starts with coaps:// and Security type is PSK or RPK)	This field is used to upload the key file used when security type is set to PSK, delete the uploaded key file or show the currently stored key.
Respond to any IP	When turned on, this feature adds a firewall rule that allows the router to respond to any IP address on the designated port. This eases the restrictions that requests must come from servers the client is currently registered with. We recommend that this feature is turned off for normal use.
Bootstrap	When set to the ON position, this specifies that the Server URL field points to a bootstrap server.
Read only	When set to the ON position, this allows read only access to all LWM2M settings. Writing new values and executing commands are not permitted. When set to OFF, values may be read, written and executed.

Supported objects

The objects and instances used by Lantronix routers are all part of the Open Mobile Alliance and IPSO Alliance approved list. At this time, there are no NetComm-specific objects or instances. For more information on the Lightweight M2M specifications, please visit the Open Mobile Alliance Specifications for Public Comment website: <http://technical.openmobilealliance.org/Technical/technical-information/specifications-for-public-comment>

Timeouts

Most mobile networks use stateful firewalls or NAT where the timeout for UDP is approximately 1-2 minutes. If this applies to you, configure your server to change the 'lifetime' (resource 1/0/1) to be shorter than the default 86400. We suggest setting it to 60.

Supported ciphers

- TLS_PSK_WITH_AES_128_CBC_SHA256
- TLS_ECDHE_ECDSA_WITH_AES_128_CBC_SHA256
- NULL (only if "NoSec" explicitly selected)
- Others may be negotiated by OpenSSL during connection

GPS

On models with a built-in GPS, you are able to use location-based services, monitor field deployed hardware or find your current location. The GPS Status window provides up to date information about the current location and the current GPS signal conditions (position dilution of precision (PDOP), horizontal dilution of precision (HDOP) and vertical dilution of precision (VDOP)) of the router.

NMEA support

The router supports the National Marine Electronics Association NMEA-0183 compatible (V2.3) standard of sending GPS data. The standard includes “sentences” used to identify the type of data being sent and therefore defines the way the data is interpreted. The supported GPS related sentences are listed below:

- GPGLGA – Global Positioning System Fix Data, Time, Position and fix related data for a GNSS receiver
- GPRMC – Recommended minimum data for GPS
- GPGSV – Detailed satellite data
- GPGSA – Overall satellite data
- GPVTG – Vector track and speed over the Ground

GPS configuration

To access the GPS configuration screen, select the Services item from the top menu bar then the GPS item on the left. Finally, select the GPS configuration menu item.

To use the GPS function, set the GPS operation toggle key to ON and click the Save button.

Figure 9-21 GPS configuration

GPS configuration

GPS operation ☒ ON ☐ OFF

Save

GPS applications

Google maps

GPS status

Positioning data source Stand-alone GPS

Date & Time Friday, 13 December 2013, 3:48:02 PM

Latitude & Longitude 33 48' 42.901" S , 151 08' 94.124" E

Altitude & GEOID height 82.3 m , 24.0 m

Ground speed 0.0 km/h , 0.0 knots

PDOP & HDOP & VDOP 2.1 , 1.9 , 0.9

Standalone GPS device status Normal

Number of satellites 11

Satellites status

Index	In Use	PRN	SNR	Elevation	Azimuth
1	✓	01	30	17	129
2	✓	04	26	25	016
3	✓	07	25	05	042
4	✓	08	25	35	049
5	✓	09	33	42	040
6	✗	15	19	26	257
7	✓	17	20	83	170
8	✓	28	35	41	122
9	✗	11	N/A	02	139
10	✗	24	N/A	14	222
11	✗	26	N/A	37	302
12	✗	N/A	N/A	N/A	N/A

The Google maps button provides a quick short cut to show your router's current position on a map.

Odometer

To access the Odometer screen, select the Services item from the top menu bar then the GPS item on the left. Finally, select the Odometer menu item.

The GPS may be used to record the distance that the router has travelled. To do this, set the Odometer toggle key to the ON position as in the screenshot below. You can toggle the unit of measurement by clicking the Display imperial / Display metric button. The threshold setting adjusts the router's sensitivity to movement so that movement within the specified radius from the starting point does not register as distance travelled. When you

have finished configuring the Odometer settings, click the Save button to ensure the settings are stored on the router.

Figure 9-22 Odometer options

Table 9-4 Odometer configuration options

ITEM	DESCRIPTION
Odometer reading	The number of metres/kilometres that the device has travelled since the time listed in the Odometer start time field.
Display imperial / Display metric	Toggles the Odometer reading between metric and imperial measurements.
Odometer start time	The time that recording of distance travelled began.
Reset odometer	Resets the odometer reading to 0 and the Odometer start time to the current time.
Odometer	Toggles the Odometer function on and off.
Threshold	Specifies the minimum distance that the router must travel from its current position before the Odometer reading increases.

IO configuration

The NTC-140 Series Router is equipped with a 2 x 2 Molex connector providing Power (+), Ground (–), a multipurpose input and output pin and an ignition detection input. The multipurpose input/output pin may be independently configured for various functions, including:

- Analogue 0V to 30V input
- Digital input (the I/O voltage measured by the Analogue input and the software making decision about the input state) with the threshold levels configurable in software
- Open collector output.

Use the pull up voltage options to select the desired output voltage of the I/O pins. The pull up voltage you select will be the same for each pin when pull up is enabled for that pin. Each pin is capable of outputting either 3.3V or 8.2V.

To access the IO configuration page, click the Services menu item, then select the IO configuration menu item on the left.

Figure 9-23 IO configuration options

IO configuration

IO Functionality ☒ ON ☐ OFF

Pull up voltage ☒ 3V ☐ 8.2V

IO Manager Debug level Min Max Error (Default=Error)

Pin configuration

Pin	Mode	Pull up	Threshold	Value
1	Digital input	☐ ON ☒ OFF	0.000000 V	High

Save Cancel

Table 9-5 IO configuration options

ITEM	DESCRIPTION
IO configuration	
IO Functionality	Enables the configuration of the input and output pins on the 2x2 Molex connector.
Pull up voltage	Specifies the output voltage of the I/O pins.
IO Manager Debug level	Use the slide bar to adjust the level of detail you would like to see in the log for IO messages. A higher debug level displays more detailed messages in the log file.
Per pin configuration	
Pin	The I/O pin number corresponding to the pin on the Molex connector that you wish to configure.
Mode	The mode of operation for the corresponding pin. Available options are Digital input, Digital output, and Analogue input.

ITEM	DESCRIPTION
Pull up	Use the pull up toggle keys to turn the pull up on or off for the corresponding pin. When turned on, the pull up voltage output is the value specified in the “Pull up voltage” option.
Threshold	Displays the current voltage threshold configured for the I/O pin.
Value	The value column displays whether the voltage detected on the line is low or high or allows you to configure the output value in the case that the pin is set to digital output. This can be useful for applications where monitoring of the transition between low and high is used to trigger an action.

The table below describes the different modes available on the physical I/O pins of the router.

Table 9-6 IO pin modes

MODE	DESCRIPTION
Digital input	The corresponding pin accepts digital input. Pull up may be on or off and both 3.3V and 8.2V are available as pull up voltages. The value column displays whether the signal received on the pin is High or Low.
Digital output	The corresponding pin outputs a digital signal. Pull up may be on or off and both 3.3V and 8.2V are available as pull up voltages. The value column contains a toggle key allowing you to set whether the output signal is High or Low.
Analogue input	The corresponding pin accepts an analogue signal. Pull up may be on or off and both 3.3V and 8.2V are available as pull up voltages. The value column displays the current voltage detected on the pin.



Note: Please refer to the SDK Developer Guide for hardware information about the Input/Output pins, wiring examples and configuration of the pins via the command line interface. There are also wiring examples in Appendix G of this User Guide. Contact Lantronix Technical Support for access to the Software Development Kit.

Event notification

The event notification feature is an advanced remote monitoring tool providing you with the ability to send alerts via SMS, e-mail, TCP or UDP when pre-defined system events occur.

Notification configuration

The Notification configuration screen is used to select the event types, methods of notification and the destinations for the notifications. Up to four types of alerts for a particular event may be sent to a single destination profile containing the contact details.

To access the Event notification configuration page, click the Services menu item, select the Event configuration menu item on the left, then select the Notification configuration menu item.

Figure 9-24 Event notification configuration

Event notification configuration

Enable event notification ☒ ON ☐ OFF

Maximum event buffer size (100-10000)

Maximum retry count (1-20)

Event notification log file

Unit ID

Event description	Event ID	Email	TCP	UDP	SMS	Destination profile	Filter
Unit powered up	1	☐	☐	☐	☐	Default	v
Unit rebooted	2	☐	☐	☐	☐	Default	v
Link status change	3	☐	☐	☐	☐	Default	v
WWAN IP address change	4	☐	☐	☐	☐	Default	v
WWAN Registration change	5	☐	☐	☐	☐	Default	v
WWAN Cell ID change	6	☐	☐	☐	☐	Default	v
WWAN technology change	7	☐	☐	☐	☐	Default	v
Number of connected Ethernet interfaces change	8	☐	☐	☐	☐	Default	v
Web UI login failure	10	☐	☐	☐	☐	Default	v
SD card status change	11	☐	☐	☐	☐	Default	v
WAN failover instance occurred	12	☐	☐	☐	☐	Default	v

Table 9-7 Event notification configuration options

ITEM	DESCRIPTION
Enable event notification	Toggles the event notification feature on and off.
Maximum event buffer size	Specifies the buffer size for event notifications which failed to be delivered or are yet to be sent. The minimum size is 100 and the maximum is 10000.
Maximum retry count	Specifies the maximum number of attempts that the router will make to deliver an event notification. The range is between 1 and 20.
Event notification log file	Specifies to the location and name of the file used to log the event notification activity.
Event notification prefix	The Unit ID field is used to specify an identifier for the router which are sent in the event notifications so that you know which router has an event.

Event types

There are ten events for which you can configure alerts. Hovering the mouse over the event description provides more details of event notification type.

Table 9-8 Event notification – event types

EVENT	EVENT ID	DESCRIPTION	EXAMPLE MESSAGE
Unit powered up	1	Notification is sent when the unit is powered up through connection of a power source or after a soft-reset.	Power is up
Unit rebooted	2	Notification is sent when the unit is rebooted via Web UI, SMS diagnostics or via command line/telnet session.	Rebooting triggered by internal application
Link status change	3	Notification is sent if the status of the data connection profile or any IPSec/OpenVPN/PPTP/GRE tunnel endpoint changes i.e. the link goes up or down.	Profile 1 WWAN status changed : down --> up
WWAN IP address change	4	Notification is sent if an active data connection profile's WWAN IP address changes.	WWAN IP address changed : N/A --> 10.103.4.149
WWAN Registration change	5	Notification is sent if the network registration status changed between "registered", "unregistered" or "roaming".	WWAN registration status changed : Not registered --> Registered to home network

EVENT	EVENT ID	DESCRIPTION	EXAMPLE MESSAGE
WWAN Cell ID change	6	Notification is sent if the router connects to a different cell, marked by a changed in the Cell ID.	Cell ID changed : --> 15224145 Cell ID changed : 15224148 --> 15224145
WWAN technology change	7	Notification is sent if the router connects to a different network technology, e.g. 3G/2G.	WWAN network changed : N/A() --> 3G(UMTS) WWAN network changed : 3G(UMTS) --> 2G(GSM)
Number of connected Ethernet interfaces change	8	Notification is sent if there is a change to the number of directly connected Ethernet interfaces.	Ethernet device number changed : 0 --> 1
Web UI login failure	10	Notification is sent if there was a failure to log in to the router via the Web UI.	WEBUI login failed, username root, password
SD card status changed	11	Notification is sent if the status of the SD card changes, i.e. a card is removed or inserted.	SD card status changed: removed --> inserted
WAN failover instance occurred	12	Notification is sent if a failover between WAN interfaces occurs.	Failover instance occurred: N/A --> wwan.0 Failover instance occurred: eth.0 --> wwan.0

Destinations

A “destination” is a profile on the router containing the contact details of a recipient of event notification alerts i.e. the e-mail address, SMS number, TCP or UDP server addresses of the recipient. The destination profile must contain the details of at least one destination type in order to be used.

Configuring Event notification

To configure the event notification feature:

1. Click the Services menu item at the top of the screen. From the Event notification menu on the left of the screen, select the Destination configuration menu item.
2. Click the +Add button at the top right corner of the window. The Event destination edit screen is displayed.
3. In the Destination name field enter a name for the destination profile then enter the contact details for the each type of destination i.e. Email address, TCP address and port, UDP address and port and/or SMS number.
4. Click the Save button when you have entered the required details.
5. From the Event notification menu on the left of the screen, select the Notification configuration menu item.
6. Select the Enable event notification toggle key to turn it to the ON position.

7. If desired, set the Maximum event buffer size, Maximum retry count, Event notification log file and Event notification prefix fields. See table 23 for descriptions of these options.
8. From the Destination column, use the drop down menus to select the desired destination profiles to use for the corresponding events, then select the checkboxes for the types of notifications to send to the chosen destination profile. If the Destination profile does not contain the required contact details, a pop-up warns you to enter the required details in the Destination profile.
9. Click the Save button.



Note: If you have selected the Email notification type for any of the events, you must also configure Email client settings to allow the router to send e-mail messages.

Destination configuration

The Destination configuration screen displays a list of the destination “profiles” that have been configured on the device as well as providing the option to add new profiles.

Figure 9-25 Event destination list

Destination name	Email address	TCP address	UDP address	SMS number
Default				
Email	user@domain.com			

To add a new destination profile:

1. Click the +Add button at the top right corner of the window. The Event destination edit screen is displayed.
2. In the Destination name field enter a name for the destination profile then enter the contact details for the each type of destination i.e. Email address, TCP address and port, UDP address and port and/or SMS number.
3. Click the Save button when you have entered the required details.

To edit a destination profile:

1. From the Event destination list, click the edit button for the corresponding destination profile. The Event destination edit page is displayed. Make the required changes.
2. Click the Save button.

To delete a destination profile:

1. From the Event destination list, select the delete button for the corresponding destination profile that you would like to delete. If the destination profile is linked to an event notification type, the i button is displayed instead of the delete button. In this case, you must go to the Notification configuration screen and remove the check marks from all the notification types for each event for which the destination

profile is configured. When you have done that, return to the Event destination list and select the delete button.

2. Click the Save button.

Email settings

The Email settings screen allows the configuration of the email account that is used to send emails in features such as Event notification.

To access the Email settings page, click the Services menu item then select the Email settings menu item on the left.

Figure 9-26 Email client settings

Table 9-9 Email client settings

ITEM	DESCRIPTION
From	Enter the email address of the account you will be using to send emails.
CC	(Optional) Enter an email address which will be copied on all messages sent.
Email server address (SMTP)	Enter the SMTP server address of the email server. This may be an IP address or a hostname.

ITEM	DESCRIPTION
Email server port	Enter the Email server's SMTP port.
Encryption	Use this drop down list to select the type of encryption to apply to the mail server connection.
Enable Authentication	If your mail server requires account authentication before it allows mail to be sent, enable this option and enter the account details in the Username and Password fields below.
Username	Enter the username of the account to be used for sending emails.
Password	Enter the password of the account to be used for sending emails.
Confirm password	Enter the password of the account to be used for sending emails once more for confirmation.
Email test recipient	Enter an email address to send a test message to, then click the Send test email button.

SMS messaging

The NTC-140 Series router offers an advanced SMS feature set, including sending messages, receiving messages, redirecting incoming messages to another destination, as well as supporting remote commands and diagnostics messages.

Some of the functions supported include:

- Ability to send a text message via a cellular network and store it in permanent storage.
- Ability to receive a text message via a cellular network and store it in permanent storage.
- Ability to forward incoming text messages via a cellular network to another remote destination which may be a TCP/UDP server or other mobile devices.
- Ability to receive run-time variables from the device (e.g. uptime) on request via SMS
- Ability to change live configuration on the device (e.g. network username) via SMS.
- Ability to execute supported commands (e.g. reboot) via SMS
- Ability to trigger the NTC-140 Series router to download and install a firmware upgrade
- Ability to trigger the NTC-140 Series router to download and apply a configuration file

To access the SMS messaging functions of the NTC-140 Series router, click on the Services menu item from the top menu bar, and then select one of the options under the SMS messaging section on the left hand menu.

Setup

The Setup page provides the options to enable or disable the SMS messaging functionality and SMS forwarding functionalities of the router. SMS messaging is enabled by default.

Figure 9-27 General SMS Configuration

General SMS configuration

SMS messaging ☒ ON ☐ OFF

Messages per page (10-50)

Encoding scheme ☒ GSM 7-bit ☐ UCS-2

SMSC address

SMS forwarding configuration

Forwarding ☒ ON ☐ OFF

Redirect to mobile

TCP server address

TCP port (1-65535)

UDP server address

UDP port (1-65535)

Table 9-10 SMS Setup Settings

OPTION	DEFINITION
General SMS configuration	
SMS messaging	Toggles the SMS functionality of the router on and off.
Messages per page (10-50)	The number of SMS messages to display per page. Must be a value between 10 and 50.
Encoding scheme	The encoding method used for outbound SMS messages. GSM 7-bit mode permits up to 160 characters per message but drops to 50 characters if the message includes special characters. UCS-2 mode allows the sending of Unicode characters and permits a message to be up to 50 characters in length.
SMS forwarding configuration	
Forwarding	Toggles the SMS forwarding function of the router on and off.

OPTION	DEFINITION
Redirect to mobile	Enter a mobile number as the destination for forwarded SMS messages.
TCP server address	Enter an IP address or domain name as the destination for forwarded SMS messages using TCP.
TCP port	The TCP port on which to connect to the remote destination.
UDP server address	Enter an IP address or domain name as the destination for forwarded SMS messages using UDP.
UDP port	The UDP port on which to connect to the remote destination.

SMS forwarding configuration

Incoming text messages can be redirected to another mobile device and/or a TCP/UDP message server.

Redirect to mobile

You can forward incoming text messages to a different destination number. This destination number can be another mobile phone or a router phone number.

For Example:

If someone sends a text message and Redirect to mobile is set to “+61412345678”, the text message is stored on the router and forwarded to “+61412345678” at the same time.

To disable redirection to a mobile, clear the Redirect to mobile field and click the Save button.

Redirect to TCP / UDP server address

You can also forward incoming text messages to a TCP/UDP based destination. The TCP or UDP server can be any kind of public or private server if the server accepts incoming text-based messages.

The TCP/UDP address can be an IP address or domain name. The port number range is from 1 to 65535. Please refer to your TCP/UDP based SMS server configuration for which port to use.

For Example:

If someone sends a text message and TCP server address is set to “192.168.20.3” and TCP port is set to “2002”, this text

message is stored in the router and forwarded to “192.168.20.3” on port “2002” at the same time.


To disable redirection to a TCP or UDP address, clear the TCP server address and UDP server address fields and click the Save button.

New message

The New message page can be used to send SMS text messages to a single or multiple recipients. To access the New message page, click on the Services menu item from the top menu bar, select the SMS messaging menu on the left then select the New message menu item.

A new SMS message can be sent to a maximum of 9 recipients at the same time. After sending the message, the result is displayed next to the destination number as “Success” or “Failure” if the message failed to send. By default, only one destination number field is displayed. Additional destination numbers may be added one at a time after entering a valid number for the current destination number field. To add a destination number, click the  button and to remove the last destination in the list, click the  button.

Figure 9-28 SMS - New Message



New message

Please prefix a '+' to all international numbers or the message may be incorrectly processed and/or discarded by the network.

Destination number  

New message

Destination numbers should begin with the “+” symbol followed by the country calling code. To send a message to a destination number, enter the “+” symbol followed by the country calling code and then the destination number.

For example:


To send a message to the mobile destination number 0412345678 in Australia (country calling code 61), enter “+61412345678”.

After entering the required recipient numbers, type your SMS message in the New message field. As you type your message, a counter shows how many characters you have entered out of the total number available for your chosen encoding scheme. When you have finished typing your message and you are ready to send it, click the Send button.

Inbox / Sent Items

The Inbox displays all received messages that are stored on the router while Sent Items displays all sent messages. To access the Inbox page, click on the Services menu item from the top menu bar, select the SMS messaging menu on the left then select the Inbox menu item.

Figure 9-29 SMS Inbox



To access the Sent items page, click on the Services menu item from the top menu bar, select the SMS messaging menu on the left then select the Sent items menu item.

Figure 9-30 SMS Outbox




Table 9-11 Inbox/Outbox icons

ICON	DESCRIPTION
	Forward button. Click this button to open a new message window where you can forward the corresponding message to another recipient.
	Reply button. Click this button to open a new message window where you can reply to the sender.
	Add to White list. Click this button to add the sender's mobile number to the white list on the router.
	Delete button. Click this button to delete the corresponding message.
	Refresh button. Click this button to refresh the inbox or outbox to see new messages.

Diagnostics

The Diagnostics page is used to configure the SMS diagnostics and command execution configuration. This allows you to change the configuration, perform functions remotely and check on the status of the router via SMS commands.

To access the Diagnostics page, click on the Services menu item then select the SMS menu on the left and finally select Diagnostics beneath it.

Figure 9-31 SMS diagnostics and command execution configuration

SMS diagnostics and command execution configuration

Enable remote diagnostics and command execution ☒ ON ☐ OFF

Only accept authenticated SMS messages ☒ ON ☐ OFF

Send Set command acknowledgement replies ☐ ON ☒ OFF

Access advanced RDB variables ☐ ON ☒ OFF

Allow execution of advanced commands ☐ ON ☒ OFF

Send acknowledgement replies to ☐ a fixed number ☒ the sender's number

Send command error replies ☒ ON ☐ OFF

Send error replies to ☐ a fixed number ☒ the sender's number

Send a maximum number of replies per
0 / 100 messages sent

Limit the number of diagnostic text messages that can be sent in a designated time period. Currently, the 'messages sent' count automatically resets at the end of the designated time period. For example, it will reset to zero at 01:00, 02:00, 03:00 etc for 'hour', 00:00 for 'day', 00:00 on Monday for 'week' and the first day of the month for 'month', or at anytime the unit reboots.

White list for diagnostic or execution SMS

All incoming diagnostic or execution text messages are checked against this white list. If the message sender and password don't match any destination numbers and passwords in this white list, the message is ignored and an error message reply is sent to the sender or to a predefined destination. You can add up to 20 destination numbers via the SMS inbox/sent items pages by clicking on 'Add white list'. Alternatively, click on 'Add' below to add a number now.

The white list is empty

SMS diagnostics and command execution configuration

The options on this page are described below.

Enable remote diagnostics and command execution

Enables or disables the remote diagnostics feature. If this setting is enabled all incoming text messages are parsed and tested for remote diagnostics commands.

If remote diagnostics commands are found, the router executes those commands. This feature is enabled by default. All remote diagnostic commands that are received are stored in the Inbox.



Note: It is possible to adjust settings and prevent your router from functioning correctly using remote diagnostics. If this occurs, you will need to perform a factory reset in order to restore normal operation.



Warning: We highly recommended that you use the white list and a password when utilising this feature to prevent unauthorised access. See the [white list](#) description for more information.

Only accept authenticated SMS messages

Enables or disables checking the sender's phone number against the allowed sender white list for incoming diagnostics and command execution SMS messages.

If authentication is enabled, the router will check if the sender's number exists in the white list. If it exists, the router then checks the password (if configured) in the incoming message against the password in the white list for the corresponding sending number. If they match, the diagnostic or command is executed.

If the number does not exist in the white list or the password does not match, the router does not execute the incoming diagnostic or command in the SMS message.

This is enabled by default and it is strongly advised that you leave this feature enabled to maintain security.

Send Set command acknowledgement replies

The NTC-140 Series router will automatically reply to certain types of commands received, such as *get* commands, or *execute* commands. However acknowledgement replies from the NTC-140 Series router are optional with *set* commands and the *Wakeup* command. This option Enables or disables sending an acknowledgment message after execution of a *set* command or SMS Wakeup command. If disabled, the router does not send any acknowledgement after execution of a *set* command or SMS Wakeup command. All acknowledgment replies are stored in the Outbox after they have been sent. This can be useful to determine if a command was received and executed by the router. This option is disabled by default.

Access advanced RDB variables

By default, this option is turned off and only allows access to the [basic RDB variables](#) listed later in this guide. If this option is enabled, you are able to access the full list of RDB variables via SMS.

Allow execution of advanced commands

By default, this option is turned off and only allows execution of the [basic commands](#) listed later in this guide. If this option is enabled, you are able to execute advanced commands such as those which are common to the Linux command line. For example: "execute ls /usr/bin/sms*" to list the contents of the /etc folder on the router.

Send acknowledgement replies to

This option allows you to specify where to send acknowledgment messages after the execution of a *set*, *get*, or *exec* command.

If a fixed number is selected, the acknowledgement message will be sent to the number defined in the Fixed number to send replies to field. If the sender's number is selected, the acknowledgement message will be sent to the number that the SMS diagnostic or command message originated from. The default setting is to use the sender's number.

Fixed number to send replies to

This field defines the destination number to which error messages are sent after the execution of a *get*, *set*, or *exec* command. This field is only displayed when Send Error SMS to is set to Fixed Number.

Send command error replies

Enables or disables the sending of an error message resulting from the execution of a *get*, *set*, or *exec* command. All error replies are stored in the Outbox after they have been sent.

Send error replies to

When Send Error SMS for Get/Set/Exec Command is set to ON, this option is used to specify where the error SMS is sent. Use the radio buttons to select either Fixed Number or SMS Sender Number. When set to SMS Sender Number the router will reply to the originating number of the SMS diagnostic or command. When set to Fixed Number the router will send the error messages to the number specified in the following field.

Send a maximum number of

You can set the maximum number of acknowledgement and error messages sent when an SMS diagnostic or command is executed. The maximum limit can be set per hour, day, week or month. The router will send a maximum of 100 replies by default.

The number of messages sent is shown below the options. The total transmitted message count resets after a reboot or at the beginning of the time frame specified.

White List for diagnostic or execution SMS

The white list is a list of mobile numbers that you can create which are considered “friendly” to the router. If Only accept authenticated SMS messages is enabled in the diagnostics section, the router will compare the mobile number of all incoming diagnostic and command messages against this white list to determine whether the diagnostic or command should be executed. You may optionally configure a password for each number to give an additional level of security. When a password is specified for a number, the SMS diagnostic or command message is parsed for the password and will only be executed if the number and password match.

Figure 9-32 White list for diagnostic or execution SMS

White list for diagnostic or execution SMS

All incoming diagnostic or execution text messages are checked against this white list. If the message sender and password don't match any destination numbers and passwords in this white list, the message is ignored and an error message reply is sent to the sender or to a predefined destination. You can add up to 20 destination numbers via the SMS inbox/outbox pages by clicking on 'Add white list'. Alternatively, click on 'Add' below to add a number now.

+ Add

The white list is empty

Save Refresh

A maximum of 20 numbers can be stored on the router in the white list. To add a number to the white list, click the “+Add” button.

Figure 9-33 Adding a number to the SMS white list

+ Add

#	Destination number	Password
01	0412345678	password123 x

Save Refresh

The White List numbers and passwords can be cleared by pressing the x button to the right of each entry. To add a number to the white list, enter it in the Destination number field and optionally define a password in the Password field. When you have finished adding numbers click the Save button to save the entries.

Sending an SMS Diagnostic Command

Follow the steps below to configure the router to optionally accept SMS diagnostic commands only from authenticated senders and learn how to send SMS diagnostic commands to the router.

3. Navigate to the Services > SMS messaging > Diagnostics page
4. Confirm that the Enable remote diagnostics and command execution toggle key is set to the ON position. If it is set to OFF click the toggle key to switch it to the ON position.
5. If you wish to have the router only accept commands from authenticated senders, ensure that Only accept authenticated SMS messages is set to the ON position. In the White list for diagnostic or execution SMS messages section, click the +Add button and enter the sender's number in international format into the Destination number field that appears. If you wish to also configure a password, enter the password in the Password field corresponding to the destination number.
6. If you would prefer to accept SMS diagnostic commands from any sender, set the Only accept authenticated SMS messages toggle key to the OFF position.



Note: An alternative method of adding a number to the white list is to send an SMS message to the router, navigate to Services > SMS messaging > Inbox and then click the button next to the message which corresponds to the sender's number.

7. Click the Save button.

Types of SMS diagnostic commands

There are three types of commands that can be sent; execute, get and set. The basic syntax is as follows:

- `execute COMMAND`
- `get VARIABLE`
- `set VARIABLE=VALUE`

If authentication is enabled, each command must be preceded by the password:

- `PASSWORD execute COMMAND`
- `PASSWORD get VARIABLE`
- `PASSWORD set VARIABLE=VALUE`

The following are some examples of SMS diagnostic commands:

- `password6657 execute reboot`
- `get rssi`
- `set apn1=testAPNvalue`

SMS acknowledgment replies

The router automatically replies to get commands with a value and execute commands with either a success or error response. Set commands will only be responded to if the Send Set command acknowledgement replies toggle key is set to ON. If the Send command error replies toggle key is set to ON, the router will send a reply if the command is correct but a variable or value is incorrect, for example, due to misspelling.

SMS command format

Generic Format for reading variables:

```
get VARIABLE
PASSWORD get VARIABLE
```

Generic Format for writing to variables:

```
set VARIABLE=VALUE
PASSWORD set VARIABLE=VALUE
```

Generic Format for executing a command:

```
Execute COMMAND PASSWORD execute COMMAND
```

Replies

Upon receipt of a successfully formatted, authenticated (if required) command, the gateway will reply to the SMS in the following format:

Table 9-12 SMS Diagnostic Command Syntax

TYPE	SMS CONTENTS	NOTES
get command	"VARIABLE=VALUE"	
set command	"Successfully set VARIABLE to VALUE"	Only sent if the acknowledgment message function is enabled
execute command	"Successfully executed command COMMAND"	

Where "VARIABLE" is the name of the value to be read

Where "VARIABLE (x)" is the name of another value to be read

Where "VALUE" is the content to be written to the "VARIABLE"

Where "COMMAND" is a supported command to be executed by the device (e.g. reboot)

Where "PASSWORD" is the password (if configured) for the corresponding sender number specified in the White List
Multiple commands can be sent in the same message, if separated by a semicolon.

For Example:

```
get VARIABLE1; get VARIABLE2; get VARIABLE3 PASSWORD get VARIABLE1; get VARIABLE2
set VARIABLE=VALUE1 ; set VARIABLE2=VALUE2
PASSWORD set VARIABLE1=VALUE1; set VARIABLE2=VALUE2; set VARIABLE3=VALUE3
If required, values can also be bound by an apostrophe, double apostrophe or back tick. For Example:
"set VARIABLE='VALUE'" "set VARIABLE="VALUE"" "set VARIABLE=`VALUE`" "get VARIABLE"
```

A password (if required), only needs to be specified once per SMS, but can be prefixed to each command if desired.

```
"PASSWORD get Variable1"; "get VARIABLE2"
"PASSWORD set VARIABLE1=VALUE1"; "set VARIABLE2=VALUE2"
```

If the command sent includes the "reboot" command and has already passed the white list password check, the device keeps this password and executes the remaining command line after the reboot with this same password.

For Example:

```
"PASSWORD execute reboot; getVariable1"; "get VARIABLE2" "PASSWORD execute reboot; PASSWORD get
Variable1"; "get VARIABLE2"
```



Note: Commands, variables and values are case sensitive.

List of basic commands

A list of basic commands which can be used in conjunction with the execute command are listed below:

“pdpcycle”, “pdpdown” and “pdpup” commands can have a profile number suffix ‘x’ added. Without the suffix specified, the command operates against the default profile configured on the profile list page of the Web-UI.

Table 9-13 List of basic SMS diagnostic commands

#	COMMAND NAME	DESCRIPTION
1	reboot	Immediately performs a soft reboot.
2	pdpcycle	Disconnects (if connected) and reconnects the data connection. If a profile number is selected in the command, try to disconnect/reconnect the specified profile in case the profile is active. If no profile number is selected, try to disconnect/reconnect the current active profile. Reports an error if no profile number is selected and there is no currently activated profile.
3	pdpdown	Disconnects the PDP. If a profile number is selected in the command, the router tries to disconnect the specified profile in case the profile is active. If no profile number is selected, try to disconnect the current active profile. Reports an error if no profile number is selected and there is no currently activated profile.
4	pdpup	Reconnects the PDP. If a profile number is selected in the command, the router tries to connect with the specified profile. If no profile number is selected, the router tries to connect to the last active profile. The gateway will check the currently activated profile and disconnect this profile before executing the command. The router reports an error if no profile number is selected and there is no stored last active profile number.
5	factorydefaults	Performs a factory reset on the router. Be aware that this command also clears the SMS white list on the router.
		Performs a download and install of a Firmware Upgrade (.cdi), Config File (.tar.gz) or a help document (.pdf) file. If the file is a firmware image as in the case of a .cdi file, the router will apply the recovery image first and then the main firmware image. The download location is specified immediately after the command and may be from an HTTP or FTP source URL. If the file is a .cdi file, the router will apply the file as a configuration file update for the device and reboot afterwards. If the file is a .pdf, the router will assume this is a user guide document and save it to the router and make the file available for viewing via the help menu on the Web-UI.

#	COMMAND NAME	DESCRIPTION
6	download	Note: If your download URL includes any space characters, please encode these prior to transmission according to RFC1738, for example: <code>ftp://username:password@serveraddress/directory%20with%20spaces/filename.cdi</code> Note: Authenticated FTP addresses may be used following the format as defined in RFC1738, for example: ftp://username:password@serveraddress/directory/filename.cdi
7	codconnect	Causes the router to activate the PDP context when the Connect on demand feature is enabled.
8	coddconnect	Causes the router to de-activate the PDP context when the Connect on demand feature is enabled.
9	wakeup	This forces the default Data connection profile to connect if it is in a disconnected or waiting state. There are two circumstances in which this command may be useful; where the default profile is enabled but has been manually disconnected and if Connect on demand is enabled and the router is awaiting packet of interest. In both of these situations, the wakeup command will cause the default PDP context to activate.
10	ssh.genkeys	Instructs the router to generate new public SSH keys.
11	ssh.clearkeys	Instructs the router to clear the client public SSH key files.

List of get/set commands

The following table is a partial list of get and set commands which may be performed via SMS.

Table 9-14 List of get/set commands

COMMAND NAME	EXAMPLE	DESCRIPTION
get status	<code>get status</code>	Returns the Module firmware version, LAN IP Address, Network State, Network operator and RSSI.
get sessionhistory	<code>get sessionhistory</code>	Returns the time and date of recent sessions along with the total amount of data sent and received for each session.
set syslogserver	<code>set syslogserver=123.45.67.89:514</code>	Sets a remote syslog server IP or hostname and port.
set cod	<code>set cod=1</code>	Enables or disables Connect on demand.

COMMAND NAME	EXAMPLE	DESCRIPTION
get cod	get cod	Returns the enable/disable status of the Connect on demand feature.
get codstatus	get codstatus	Returns the connection status of the Connect on demand feature.
set coddialport	set coddialport=on,53	Sets the Connect on demand feature to connect only when traffic is received on the specified port.
get coddialport	get coddialport	Returns the Connect on demand port filter status and list or filtered ports.
set codonline	set codonline=20	Sets the router to stay online for at least X minutes when data activity is detected.
get codonline	get codonline	Returns the number of minutes the router is configured to stay online when data activity is detected.
set codminonline	set codminonline=10	Sets the router to stay online for a minimum of X minutes after connecting.
get codminonline	get codminonline	Returns the minimum number of minutes the router should stay online after connecting.
set codredial	set codredial=5	Sets the number of minutes that the router should not attempt to redial after hanging up.
get codredial	get codredial	Returns the number of minutes that the router is configured to not attempt to redial after hanging up.
set coddisconnect	set coddisconnect=0	Sets the number of minutes after which the router should disconnect regardless of traffic.
get coddisconnect	get coddisconnect	Returns the number of minutes the router is configured to disconnect regardless of traffic.
set codconnectreg	set codconnectreg=30	Sets the number of minutes that the router should regularly attempt to connect.
get codconnectreg	get codconnectreg	Returns the number of minutes that the router is configured to regularly attempt to connect.
set codrandomtime	set codrandomtime=3	Sets the number of minutes that the router should randomise the dial time by.
get codrandomtime	get codrandomtime	Returns the number of minutes that the router is configured to randomise the dial time by.
set codverbose	set codverbose=1	Sets verbose logging on or off.
get codverbose	get codverbose	Returns the status of verbose logging.

COMMAND NAME	EXAMPLE	DESCRIPTION
set codignore.icmp	set codignore.icmp=1	Sets the router to ignore ICMP packets triggering data activity detection.
get codignore.icmp	get codignore.icmp	Returns the status of the Ignore ICMP option.
set codignore.tcp	set codignore.tcp=1	Sets the router to ignore TCP packets triggering data activity detection.
get codignore.tcp	get codignore.tcp	Returns the status of the Ignore TCP option.
set codignore.udp	set codignore.udp=1	Sets the router to ignore UDP packets triggering data activity detection.
get codignore.udp	get codignore.udp	Returns the status of the Ignore UDP option.
set codignore.dns	set codignore.dns=1	Sets the router to ignore DNS traffic triggering data activity detection.
get codignore.dns	get codignore.dns	Returns the status of the Ignore DNS option.
set codignore.ntp	set codignore.ntp=1	Sets the router to ignore NTP traffic triggering data activity detection.
get codignore.ntp	get codignore.ntp	Returns the status of the Ignore NTP option.
set codignore.ncsi	set codignore.ncsi=1	Sets the router to ignore NCSI traffic triggering data activity detection.
get codignore.ncsi	get codignore.ncsi	Returns the status of the Ignore NCSI option.
get plmnscan	get plmnscan	Instructs the router to perform a network scan and returns the results by SMS.
set forceplmn	set forceplmn=505,3	Sets the operator to a manual selection made by the user where "505" is the Mobile Country Code for Australia and "3" is the Mobile Network Code for Vodafone. As no network type (e.g.. LTE/3G/2G) is specified, it is selected automatically.
get forceplmn	get forceplmn	Returns the operator and network type selection mode (Automatic/Manual), in addition to the MCC and MNC values
get pppoe	get pppoe	Returns the PPPoE status, currently configured dial string and service name
set pppoe	set pppoe=1, telstra.internet, test	Sets the PPPoE status on, APN to telstra.internet, and service name to test.
get ledmode	get ledmode	Returns the status of the LED operation mode.

COMMAND NAME	EXAMPLE	DESCRIPTION
set ledmode	set ledmode=10	Sets the LED operation mode to be always on or to turn off after the specified number of minutes.
get ssh.proto	get ssh.proto	Returns the SSH protocol in use.
set ssh.proto	set ssh.proto=1,2	Sets the SSH Protocol to protocol 1, 2 or both (1,2).
get ssh.passauth	get ssh.passauth	Returns the status of the SSH Enable password authentication option.
set ssh.passauth	set ssh.passauth=1	Sets the SSH Enable password authentication option on or off.
get.ssh.keyauth	get.ssh.keyauth	Returns the status of the SSH Enable key authentication option.
set.ssh.keyauth	set.ssh.keyauth=1	Sets the SSH Enable key authentication option on or off.
get download.timeout	get download.timeout	Returns the time in minutes that the router waits before a download times out.
set download.timeout	set download.timeout=20	Sets the time in minutes that the router waits before a download times out. This is set to 10 minutes by default. Supported range is 10 – 1440 minutes.
get install.timeout	get install.timeout	Returns the time in minutes that the router waits before a file that is being installed times out.
set install.timeout	set install.timeout=5	Sets the time in minutes that the router waits before a file that is being installed times out. This is set to 3 minutes by default. Supported range is 3 – 300 minutes.

List of basic RDB variables

The following table lists valid variables where “x” is a profile number (1-6). If no profile is specified, variables are read from or written to for the current active profile. If a profile is specified, variables are read from or written to for the specified profile number ('x').

Table 9-15 List of basic SMS diagnostics RDB variables

#	RDB VARIABLE NAME	SMS VARIABLE NAME	READ/ WRITE	DESCRIPTION	EXAMPLE VALUE
0	link.profile.1.enable link.profile.1.apn link.profile.1.user link.profile.1.pass link.profile.1.auth_type link.profile.1.iplocal link.profile.1.status	profile	RW	Profile	Read: (profile no,apn,user,pass,auth,iplo cal,status) 1,apn,username,password, chap,202.44.185.111,up

#	RDB VARIABLE NAME	SMS VARIABLE NAME	READ/ WRITE	DESCRIPTION	EXAMPLE VALUE
					Write: (apn, user, pass,auth) apn,username,password
2	link.profile.1.user	username	RW	Cellular broadband username	Guest, could also return "null"
3	link.profile.1.pass	password	RW	Cellular broadband password	Guest, could also return "null"
4	link.profile.1.auth_type	authtype	RW	Cellular broadband Authentication type	"pap" or"chap"
5	link.profile.1.iplocal	wanip	R	WAN IP address	202.44.185.111
6	wwan.0.radio.information.signal_strength	rsi	R	Cellular signal strength	-65 dBm
7	wwan.0.imei	imei	R	IMEI number	357347050000177
8	statistics.usage_current	usage	R	Cellular broadband data usage of current session	"Rx 500 bytes, Tx 1024 bytes, Total 1524 bytes" or "Rx 0 byte, Tx 0 byte, Total 0 byte" when wwan down
9	statistics.usage_current	wanuptime	R	Up time of current cellular broadband session	1 days 02:30:12 or 0 days 00:00:00 when wwan down
10	/proc/uptime	deviceuptime	R	Device up time	1 days 02:30:12
11	wwan.0.system_network_status.current_band	band	R	Current band	WCDMA850

Network scan and manual network selection by SMS

Performing a network scan

The get plmnscan SMS command enables you to perform a scan of the cellular networks available at the time of the scan. It returns the following semi-colon separated information for each network in range:

- MCC
- MNC
- Network Type (LTE, 3G, 2G)
- Provider's Name
- Operator Status (available, forbidden, current)

The following is an example of a response from the get plmnscan SMS command:

```
plmnscan:505,3,7,vodafone AU,4;505,3,1,vodafone AU,1;505,2,7,YES OPTUS,1;505,2,1,YES
OPTUS,1;505,1,1,Telstra
Mobile,1;505,1,7,Telstra Mobile,1
```

Table 9-16 Network types returned by get plmnscan SMS command

NETWORK TYPE	DESCRIPTION
9	Indicates an LTE network.
7	Indicates a 3G network
1	Indicates a 2G network

Table 9-17 Operator status codes returned by get plmnscan SMS command

OPERATOR STATUS	DESCRIPTION
1	Indicates an available operator which may be selected.
2	Indicates a forbidden operator which may not be selected (applies only to generic SIM cards).
4	Indicates the currently selected operator.

Note:

- If the connection status is Up and connection mode is Always on, the get plmnscan SMS will cause the connection to disconnect, perform the scan, send the result through SMS and then bring the connection back up again. If the connection status is Down, the router will perform the PLMN scan, send the result and keep the connection status down.
- If the connection status is Waiting and connection mode is Connect on demand, the get plmnscan SMS will change the connection status to Down, perform the scan, send the result through SMS and then restore the connection status to the Waiting state.
- If the connection status is Up and connection mode is Connect on demand, the get plmnscan SMS will cause the connection to disconnect, perform the scan, send the result through SMS, and then restore the connection status to the Waiting state unless there is a traffic which triggers a connection in which case the connection status will be set to Up.

**Setting the router to connect to a network**

The router can be instructed by SMS to connect to one of the networks returned by the get plmnscan command. The set forceplmn command forces the router to connect to a specified operator network (if available) while the get forceplmn command retrieves the currently configured network on the router.

Command format:

```
set forceplmn=0|MCC,MNC| MCC,MNC,Network Type
```

For example:

```
set forceplmn=0
```

Sets the selection of operator and network type to automatic mode.

```
set forceplmn=505,3
```

Sets the operator to a manual selection made by the user where “505” is the Mobile Country Code for Australia and “3” is the Mobile Network Code for Vodafone. As no network type (e.g. LTE/3G/2G) is specified, it is selected automatically.

```
set forceplmn=505,3,7
```

Sets the operator and network type to a manual selection made by the user where “505” is the Mobile Country Code for Australia, “3” is the Mobile Network Code for Vodafone and “7” is the 3G network type.

Note:

- If the manual selection fails, the device will fall back to the previous ‘good’ network.
- When enabled, the SMS acknowledgement reply reflects the success or failure of the manual selection with respect to the set command and includes the final MNC/MCC that was configured.

Confirming the currently configured operator and network type

You can retrieve the currently configured operator and network type using the get forceplmn command.

The get forceplmn command returns the operator and network type selection mode (Automatic/Manual), in addition to the MCC and MNC values, for example:

```
Automatic,505,3
```

This response indicates that the operator/network selection mode is Automatic, and the network used is Vodafone AU.

SMS diagnostics examples

The examples below demonstrate various combinations of supported commands. This is not an exhaustive list and serves as an example of possibilities only.

Table 9-18 SMS diagnostics example commands

DESCRIPTION	AUTHENTICATION	INPUT EXAMPLE
Send SMS to change the data connection username	Not required	<code>set username='NetComm'</code>
	Required	<code>PASSWORD set username= "NetComm"</code>
Send SMS to change the data connection password	Not required	<code>set password= `NetComm`</code>
	Required	<code>PASSWORD set password= `NetComm`</code>
Send SMS to change the data connection authentication	Not required	<code>set authtype= 'pap'</code>
	Required	<code>PASSWORD set authtype = pap</code>
Send SMS to reboot	Not required	<code>execute reboot</code>
	Required	<code>PASSWORD execute reboot</code>
Send SMS to check the WAN IP address	Not required	<code>get wanip</code>
	Required	<code>PASSWORD get wanip</code>
Send SMS to check the mobile signal strength	Not required	<code>get rssi</code>
	Required	<code>PASSWORD get rssi</code>
Send SMS to check the IMEI number	Not required	<code>get imei</code>
	Required	<code>PASSWORD get imei</code>
Send SMS to check the current band	Not required	<code>get band</code>
	Required	<code>PASSWORD get band</code>
Send SMS to Disconnect (if connected) and reconnect the data connection	Not required	<code>execute pdpcycle</code>
	Required	<code>PASSWORD execute pdpcycle</code>
Send SMS to disconnect the data connection	Not required	<code>execute pdpdown</code>
	Required	<code>PASSWORD execute pdpdown</code>
Send SMS to connect the data connection	Not required	<code>execute pdpup</code>
	Required	<code>PASSWORD execute pdpup</code>
	Not required	<code>get wanip; get rssi</code>

DESCRIPTION	AUTHENTICATION	INPUT EXAMPLE
Send multiple get command	Required	PASSWORD get wanip; get rssi
Send multiple set command	Not required	set ssh.genkeys=1; set username=test; set auth=pap
	Required	PASSWORD set ssh.genkeys=1; set username=test; set auth=pap
Send SMS to reset to factory default settings	Not required	execute factorydefaults
	Required	PASSWORD execute factorydefaults
Send SMS to retrieve status of router	Not required	get status
	Required	PASSWORD get status
Send SMS to retrieve the history of the session, including start time, end time and total data usage	Not required	get sessionhistory
	Required	PASSWORD get sessionhistory
Send SMS to configure the router to send syslog to a remote syslog server	Not required	set syslogserver=123.209.56.78
	Required	PASSWORD set syslogserver=123.209.56.78
Send SMS to wake up the router, turn on the default gateway and trigger the 'connect on demand' profile if in waiting state.	Not required	execute wakeup
	Required	PASSWORD execute wakeup
Send SMS to perform firmware upgrade when firmware is located on HTTP server	Not required	execute download http://download.com:8080/firmware_image.cdi execute download http://download.com:8080/firmware_image_r.cdi
	Required	PASSWORD execute download http://download.com:8080/firmware_image.cdi PASSWORD execute download http://download.com:8080/firmware_image_r.cdi
Send SMS to perform firmware upgrade when firmware is located on FTP server	Not required	execute download ftp://username:password@download.com/firmware_image.cdi execute download ftp://username:password@download.com/firmware_image_r.cdi

DESCRIPTION	AUTHENTICATION	INPUT EXAMPLE
	Required	PASSWORD execute download ftp://username:password@ download.com/firmware_image.cdi PASSWORD execute download ftp://username:password@ download.com/firmware_image_r.cdi
Send SMS to download and install IPK package located on HTTP server	Not required	execute download http://download.com:8080/package.ipk
	Required	PASSWORD execute download http://download.com:8080/package.ipk
Send SMS to download and install IPK package located on FTP server	Not required	execute download ftp://username:password@ download.com:8080/package.ipk
	Required	PASSWORD execute download ftp://username:password@ download.com:8080/package.ipk
Send SMS to turn off PPPoE	Not required	set pppoe=0
	Required	PASSWORD set pppoe=0
Send SMS to retrieve the PPPoE status, currently configured dial string and service name	Not required	get pppoe
	Required	PASSWORD get pppoe
Send SMS to set the LED mode timeout to 10 minutes	Not required	set ledmode=10
	Required	PASSWORD set ledmode=10
Send SMS to retrieve the current LED mode	Not required	get ledmode
	Required	PASSWORD get ledmode
Retrieve current SSH protocol	Not required	get ssh.proto
	Required	PASSWORD get ssh.proto
Select SSH protocol	Not required	set ssh.proto=1
	Required	PASSWORD set ssh.proto=1
Retrieve password authentication status	Not required	get ssh.passauth
	Required	PASSWORD get.ssh.passauth
Enable/disable password authentication on host	Not required	set ssh.passauth=1 or set ssh.passauth=0
	Required	PASSWORD set ssh.passauth=1 or PASSWORD set ssh.passauth=0

DESCRIPTION	AUTHENTICATION	INPUT EXAMPLE
Generate set of public/private keys on the host	Not required	<code>execute ssh.genkeys</code>
	Required	<code>PASSWORD execute ssh.genkeys</code>
Clear client public keys stored on host	Not required	<code>execute ssh.clearkeys</code>
	Required	<code>PASSWORD execute ssh.clearkeys</code>

10. System

Log

The Log pages are used to display or download the System log and IPsec logs on the router.

System log

The System Log enables you to troubleshoot any issues you may be experiencing with your NTC-140 Series router. To access the System Log page, click on the System menu. The System Log is displayed.

Figure 10-1 System log file

Log file

Display level: Notice

Download Clear

Date & Time	Machine	Level	Process	Message
Jul 22 15:15:23	ntc_140	user.notice	ipsec_action.cgi	Restart openswan to apply log change...
Jul 22 15:15:23	ntc_140	user.notice	ipsec_action.cgi	launching - action=ipsecLogApply,param=, filename=

Log file

Use the Display level drop-down list to select a message level to be displayed. The message levels are described in the table below.

To download the System log for offline viewing, right-click the Download button and choose Save as.. to save the file. To clear the System log, click the Clear button. The downloaded log file is in Linux text format with carriage return (CR) only at the end of a line, therefore in order to be displayed correctly with new lines shown, it is recommended to use a text file viewer which displays this format correctly (e.g. Notepad++).

IPSec log

The IPSec log section provides the ability for you to download the log for the IPSec VPN function. This can assist in troubleshooting any problems you may have with the IPSec VPN. To access the IPSec log page, click on the System menu item then select the Log menu on the left and finally select IPSec log beneath it.

Figure 10-2 IPSec log

IPSec log

Log level: All

Download IPSec log

Save Exit


Use the Log level drop down list to specify the type of detail you want to capture in the log and then click the Save button. When you change the logging level, any active IPSec VPN tunnels will be disconnected as a change in logging level requires the IPSec service to be restarted.

To download the IPSec log, click the Download IPSec log button and you will be prompted to save the file.

Event notification log

The Event notification log section provides the ability for you to download the log for the Event notification function. This can assist in troubleshooting any problems you may have with the Event notification feature. To access the Event notification log page, click on the System menu item then select the Log menu on the left and finally select Event notification log beneath it.

Figure 10-3 Event notification log



Use the Download event notification history button to download the log file. The Update event notification history button forces a refresh of the log display.

System log settings

To access the System log settings page, click on the System menu item then select the Log menu on the left and finally select System log settings beneath it.

Log data is stored in RAM and therefore, when the unit loses power or is rebooted, it will lose any log information stored in RAM. To ensure that log information is accessible between reboots of the router there are two options:

- Enable the Log to non-volatile memory option
- Use a remote syslog server

Figure 10-4 System log settings

System log settings

The settings are applicable only to System logs and not to IPSec or Event notification

Log capture level

Log capture level

Non-volatile log

Log to non-volatile memory ☐ ON ☒ OFF

Remote syslog server

IP / Hostname [:PORT]

Save

Non-volatile log

When the router is configured to log to non-volatile memory, the log data is stored in flash memory, making it accessible after a reboot of the router. Up to 512kb of log data will be stored before it is overwritten by new log data. Flash memory has a finite number of program-erase operations that it may perform to the blocks of memory. While this number of program-erase operations is quite large, we recommend that you do not enable this option for anything other than debugging to avoid excessive wear on the memory.

Log capture level

The log capture level defines the amount of detail that the system log stores. This setting also affects the Display level setting on the System log page, for example, if this is set to a low level, such as “Error”, the System log will not be able to display higher log levels.

Remote syslog server

The router can be configured to output log data to a remote syslog server. This is an application running on a remote computer which accepts and displays the log data. Most syslog servers can also save the log data to a file on the computer on which it is running allowing you to ensure that no log data is lost between reboots.

To configure the NTC-140 Series router to output log data to a remote syslog server:

1. Click on the System menu from the top menu bar. The System log item is displayed.
2. Under the Remote syslog server section, enter the IP address or hostname of the syslog server in the IP / Hostname [PORT] field. You can also specify the port number after the IP or hostname by entering a semi-colon and then the port number e.g. 192.168.1.102:514. If you do not specify a port number, the router will use the default UDP port 514.
3. Click the Save button to save the configuration.

Figure 10-5 Remote syslog server configuration

Remote syslog server

IP / Hostname [:PORT]

Save

Table 10-1 System log detail levels

ITEM	DEFINITION
Debug	Show extended system log messages with full debugging level details.
Info	Show informational messages only.
Notice	Show normal system logging information.
Error	Show error condition messages only.

System Configuration

Settings backup and restore

The settings backup and restore page is used to backup or restore the router's configuration or to reset it to factory defaults. In order to view the settings page you must be logged into the web user interface as **root** using the password **admin**. The backup / restore functions can be used to easily configure a large number of NTC-140 Series router by configuring one router with your desired settings, backing them up to a file and then restoring that file to multiple NTC-140 Series routers.

To access the Settings backup and restore page, click on the System menu item then select the System configuration menu on the left and finally select Settings backup and restore beneath it.

Figure 10-6 Settings backup and restore

Save a copy of current settings

Password

Confirm password

Save

Restore saved settings

Browse

Restore

Restore factory defaults

Restore defaults

Back up your router's configuration

Log in to the web configuration interface, click on the System menu and select Settings backup and restore.

If you want to password protect your backup configuration files, enter your password in the fields under Save a copy of current settings and click on Save. If you don't want to password protect your files, just click on Save. The router will then prompt you to select a location to save the settings file.

Note:



- It is NOT possible to edit the contents of the file downloaded; if you modify the contents of the configuration file in any way you will not be able to restore it later.
- You may change the name of the file if you wish but the filename extension must remain as ".cfg"

Restore your backup configuration

1. In the web configuration interface click on the System menu and select Settings backup and restore.
2. From the Restore saved settings section, click on Browse or Choose a file and select the backup configuration file on your computer.
3. Click Restore to copy the settings to the new NTC-140 Series router. The router will apply these settings and inform you it will reboot - click on OK.

Restoring the router's factory default configuration

Click the Restore defaults button to restore the factory default configuration. The router asks you to confirm that you wish to restore factory default settings. If you wish to continue with the restoring of factory defaults, click OK.



Note: All current settings on the router will be lost when performing a restore of factory default settings. The device IP address will change to 192.168.1.1 and the default username **root** and default password **admin** will be configured.

Upload

To access the Upload page, click on the System menu, then System Configuration and then Upload.

The Upload page allows you to upload firmware files, HTTPS certificates or user created application packages to the NTC-140- 02router. When firmware files have been uploaded, they can also be installed from this page. PDF files, such as this user guide may also be uploaded for access on the router's help page.

For more information on application development, contact Lantronix about our Software Development Kit.

Figure 10-7 Upload page

The screenshot shows a web interface titled "File uploads". At the top, there are two buttons: "Choose a file" and "Upload". Below these buttons, it says "Uploaded files (Free space: 124.0 M)". Underneath is a table with the following headers: "File name", "Date", "Size", and "Action". The table is currently empty.

Updating the Firmware

The firmware update process involves first updating the recovery image firmware and then updating the main firmware image.




Note: In order to perform an update, you must be logged into the router with the root manager account (see the [Advanced configuration](#) section for more details).

To update the NTC-140 Series router's firmware:

1. Power on the router as described in the [Installing the router](#) section.
2. Log in to the router with the root user account (See the [Advanced configuration](#) section for details)
3. Select the System item from the top menu bar, select the System configuration item from the menu on the left and then select the Upload menu item.
4. Under the File uploads section, click the Choose a file button. Locate the firmware image file on your computer and click Open. The image is named ntc_140_x.x.xx.x.cdi.
5. Click the Upload button. The firmware image is uploaded to the storage on the router.

Figure 10-8 File upload




6. The uploaded firmware image is listed in the Uploaded files section. Click the [Install](#) link next to the firmware image to begin installing it then click OK on the confirmation window that appears.

Figure 10-9 Uploaded files

File name	Date	Size	Action	
ntc_140_x.x.xx.x.cdi	Jul 22 2015	42.8M	Install	Delete

7. The installation is complete when the countdown reaches zero. The router attempts to redirect you to the Status page.

Figure 10-10 Installing main firmware image



8. Hold down the reset button on the router for 15-20 seconds to reboot and restore the factory default settings of the router. See the [Restoring factory default settings](#) section for more information.

Package manager

The Package manager page is used to provide details of any user installed packages on the router and allow them to be uninstalled. For more information on application development, contact Lantronix about our Software Development Kit.

To access the Package manager page, click on the System menu, System configuration and then Package manager.

Figure 10-11 Software Applications Manager

Package manager					
Application name	Version	Architecture	Time installed		
uguide	2.0.31.58769	ntc_140	21/7/2015 11:53:03 am	Package details	Uninstall

The Application name, Version number of the application, the architecture type and time of installation are all displayed. Clicking the [Package details](#) link will display a pop-up window with further details of the package.

To uninstall any software applications, click the [Uninstall](#) link. The NTC-140 Series User Guide PDF (this document) is installed as a package and may be uninstalled to recover some storage space if required.

Administration

Administration settings

To access the Administration Settings page, click on the System menu then the Administration menu on the left and then click on Administration Settings.

The Administration settings page is used to enable or disable protocols used for remote access and configure the passwords for the user accounts used to log in to the router.

Figure 10-12 Administration page

Remote router access control

Enable HTTP ☒ ON ☐ OFF

HTTP management port (Choose a port between 1 and 65534)

Enable HTTPS ☒ ON ☐ OFF

Remote HTTPS access port (Choose a port between 1 and 65534)

Enable telnet ☒ ON ☐ OFF

Enable SSH ☒ ON ☐ OFF

Remote SSH access port (Choose a port between 1 and 65534)

Enable ping ☒ ON ☐ OFF

Local router access control

Enable local Telnet ☒ ON ☐ OFF

Enable local SSH ☒ ON ☐ OFF

Web User Interface account

Username ▼

Password

Confirm password

Telnet/SSH account

Username

Password (1-126 characters in length)

Confirm password (1-126 characters in length)

Table 10-2 Administration configuration options

OPTION	DEFINITION
Remote router access control	
Enable HTTP	Enable or disable remote HTTP access to the router. You can also set the port you would like remote HTTP access to be available on.
HTTP management port	Enter a port number between 1 and 65534 to use when accessing the router remotely.
Enable HTTPS	Enable or disable remote HTTPS access to the router using a secure connection.
Remote HTTPS access port	Enter a port number between 1 and 65534 to use when accessing the router remotely over a secure HTTPS connection.
Enable Telnet	Enable or disable remote telnet (command line) access to the router.
Enable SSH	Enable or disable Secure Shell on the router.
Remote SSH Access Port	Enter the port number for remote SSH access. Must be a port number between 1 and 65534.
Enable Ping	Enable or disable remote ping responses on the WWAN connection.
Local router access control (Telnet/SSH)	
Enable Local Telnet	Enable or disable local telnet.
Enable Local SSH	Enable or disable local SSH.
Web User Interface account	
Username	Use the drop down list to select the root or admin account to change its web user interface password.
Password	Enter the desired web user interface password.
Confirm password	Re-enter the desired web user interface password.
Telnet/SSH account	
Username	Displays the Telnet/SSH.username. This may not be changed.
Password	Enter the desired Telnet/SSH password.
Confirm password	Re-enter the desired Telnet/SSH password.

To access the router's configuration pages remotely:

1. Open a new browser window and navigate to the WAN IP address and assigned port number of the router, for example <http://123.209.130.249:8080>



Note: You can find the router's WAN IP address by clicking on the "Status" menu. The WWAN IP field in the WWAN Connection Status section shows the router's WAN IP address.


2. Enter the username and password to login to the router and click Log in.



Note: To perform functions like Firmware upgrade, device configuration backup and to restore and reset the router to factory defaults, you must be logged in with the root manager account.



Warning: Using an insecure password will result in your device being compromised. Any resulting damage may not be covered under warranty. It is strongly advised that the password not be a dictionary word, nor should the same password be used across fleets of devices.



Server certificate

What is HTTP Secure?

HTTP Secure or HTTPS is the use of the HTTP protocol over an SSL/TLS protocol. It is used primarily to protect against eavesdropping of communication between a web browser and the web site to which it is connected. This is especially important when you wish to have a secure connection over a public network such as the internet. HTTPS connections are secured through the use of certificates issued by trusted certificate authorities such as VeriSign. When a web browser makes a connection attempt to a secured web site, a digital certificate is sent to the browser so that it can verify the authenticity of the site using a built-in list of trusted certificate authorities.

There are two main differences between how HTTPS and HTTP connections work:

- HTTPS uses port 443 while HTTP uses port 80 by default.
- Over an HTTPS connection, all data sent and received is encrypted with SSL while over an HTTP connection, all data is sent unencrypted.

The encryption is achieved through the use of a pair of public and private keys on both sides of the connection. In cryptography, a key refers to a numerical value used by an algorithm to alter information (encrypt it), making the information secure and visible only to those who have the corresponding key to recover (decrypt) the information. The public key is used to encrypt information and can be distributed freely. The private key is used to decrypt information and must be secret by its owner.

Each NTC-140 Series router contains a self-signed digital certificate which is identical on all NTC-140 Series routers. For a greater level of security, the router also supports generating your own unique key. Additionally, you may use third party software to generate your own self-signed digital certificate or purchase a signed certificate from a trusted certificate authority and then upload those certificates to the router.

Generating your own self-signed certificate

To generate your own self-signed certificate:

1. Click the System item from the top menu bar, then Administration from the side menu bar and then Server certificate.
2. Select a Server key size. A larger key size takes longer to generate but provides better security.
3. Click the Generate button to begin generating Diffie-Hellman parameters.
4. Enter the certificate details using the appropriate fields. Each field must be completed in order to generate a certificate.

Figure 10-13 Generate server certificate



Note: The Country field must contain a code for the desired country from the list below.

Table 10-3 Country Codes

CODE	COUNTRY	CODE	COUNTRY	CODE	COUNTRY	CODE	COUNTRY
AX	Åland Islands	ER	Eritrea	LS	Lesotho	SA	Saudi Arabia
AD	Andorra	ES	Spain	LT	Lithuania	SB	Solomon Islands
AE	United Arab Emirates	ET	Ethiopia	LU	Luxembourg	SC	Seychelles
AF	Afghanistan	FI	Finland	LV	Latvia	SE	Sweden
AG	Antigua and Barbuda	FJ	Fiji	LY	Libya	SG	Singapore
AI	Anguilla	FK	Falkland Islands (Malvinas)	MA	Morocco	SH	St. Helena


CODE	COUNTRY	CODE	COUNTRY	CODE	COUNTRY	CODE	COUNTRY
AL	Albania	FM	Micronesia	MC	Monaco	SI	Slovenia
AM	Armenia	FO	Faroe Islands	MD	Moldova	SJ	Svalbard and Jan Mayen
AN	Netherlands Antilles	FR	France	ME	Montenegro	SK	Slovak Republic
AO	Angola	FX	France, Metropolitan	MG	Madagascar	SL	Sierra Leone
AQ	Antarctica	GA	Gabon	MH	Marshall Islands	SM	San Marino
AR	Argentina	GB	Great Britain (UK)	MK	Macedonia	SN	Senegal
AS	American Samoa	GD	Grenada	ML	Mali	SR	Suriname
AT	Austria	GE	Georgia	MM	Myanmar	ST	Sao Tome and Principe
AU	Australia	GF	French Guiana	MN	Mongolia	SU	USSR (former)
AW	Aruba	GG	Guernsey	MO	Macau	SV	El Salvador
AZ	Azerbaijan	GH	Ghana	MP	Northern Mariana	SZ	Swaziland
BA	Bosnia and Herzegovina	GI	Gibraltar	MQ	Martinique	TC	Turks and Caicos Islands
BB	Barbados	GL	Greenland	MR	Mauritania	TD	Chad
BD	Bangladesh	GM	Gambia	MS	Montserrat	TF	French Southern Territories
BE	Belgium	GN	Guinea	MT	Malta	TG	Togo
BF	Burkina Faso	GP	Guadeloupe	MU	Mauritius	TH	Thailand
BG	Bulgaria	GQ	Equatorial Guinea	MV	Maldives	TJ	Tajikistan
BH	Bahrain	GR	Greece	MW	Malawi	TK	Tokelau
BI	Burundi	GS	S. Georgia and S. Sandwich	MX	Mexico	TM	Turkmenistan
BJ	Benin	GT	Guatemala	MY	Malaysia	TN	Tunisia
BM	Bermuda	GU	Guam	MZ	Mozambique	TO	Tonga

CODE	COUNTRY	CODE	COUNTRY	CODE	COUNTRY	CODE	COUNTRY
BN	Brunei Darussalam	GW	Guinea-Bissau	NA	Namibia	TP	East Timor
BO	Bolivia	GY	Guyana	NC	New Caledonia	TR	Turkey
BR	Brazil	HK	Hong Kong	NE	Niger	TT	Trinidad and Tobago
BS	Bahamas	HM	Heard and McDonald Islands	NF	Norfolk Island	TV	Tuvalu
BT	Bhutan	HN	Honduras	NG	Nigeria	TW	Taiwan
BV	Bouvet Island	HR	Croatia (Hrvatska)	NI	Nicaragua	TZ	Tanzania
BW	Botswana	HT	Haiti	NL	Netherlands	UA	Ukraine
BZ	Belize	HU	Hungary	NO	Norway	UG	Uganda
CA	Canada	ID	Indonesia	NP	Nepal	UM	US Minor Outlying Islands
CC	Cocos (Keeling) Islands	IE	Ireland	NR	Nauru	US	United States
CF	Central African Republic	IL	Israel	NT	Neutral Zone	UY	Uruguay
CH	Switzerland	IM	Isle of Man	NU	Niue	UZ	Uzbekistan
CI	Cote D'Ivoire (Ivory)	IN	India	NZ	New Zealand	VA	Vatican City State (Holy See)
CK	Cook Islands	IO	British Indian Ocean Territory	OM	Oman	VC	Saint Vincent and the
CL	Chile	IS	Iceland	PA	Panama	VE	Venezuela
CM	Cameroon	IT	Italy	PE	Peru	VG	Virgin Islands (British)
CN	China	JE	Jersey	PF	French Polynesia	VI	Virgin Islands (U.S.)
CO	Colombia	JM	Jamaica	PG	Papua New Guinea	VN	Viet Nam

CODE	COUNTRY	CODE	COUNTRY	CODE	COUNTRY	CODE	COUNTRY
CR	Costa Rica	JO	Jordan	PH	Philippines	VU	Vanuatu
CS	Czechoslovakia (former)	JP	Japan	PK	Pakistan	WF	Wallis and Futuna Islands
CV	Cape Verde	KE	Kenya	PL	Poland	WS	Samoa
CX	Christmas Island	KG	Kyrgyzstan	PM	St. Pierre and	YE	Yemen
CY	Cyprus	KH	Cambodia	PN	Pitcairn	YT	Mayotte
CZ	Czech Republic	KI	Kiribati	PR	Puerto Rico	ZA	South Africa
DE	Germany	KM	Comoros	PS	Palestinian Territory	ZM	Zambia
DJ	Djibouti	KN	Saint Kitts and Nevis	PT	Portugal	COM	US Commercial
DK	Denmark	KR	Korea (South)	PW	Palau	EDU	US Educational
DM	Dominica	KW	Kuwait	PY	Paraguay	GOV	US Government
DO	Dominican Republic	KY	Cayman Islands	QA	Qatar	INT	International
DZ	Algeria	KZ	Kazakhstan	RE	Reunion	MIL	US Military
EC	Ecuador	LA	Laos	RO	Romania	NET	Network
EE	Estonia	LC	Saint Lucia	RS	Serbia	ORG	Non-Profit Organization
EG	Egypt	LI	Liechtenstein	RU	Russian Federation	ARPA	Old style Arpanet
EH	Western Sahara	LK	Sri Lanka	RW	Rwanda		

- When you have entered all the required details, press the Generate button. The certificate takes several minutes to generate. When the certificate has been generated, you are informed that it has been successfully generated and installed. The web server on the router restarts and you are logged out of the router. Click OK to be taken back to the login screen.

Figure 10-14 New certificate successfully generated message



SSH key management

Secure Shell (SSH) is UNIX-based command interface and network protocol used to gain secure access to a remote computer, execute commands on a remote machine or to transfer files between machines. It was designed as a replacement for Telnet and other insecure remote shell protocols which send information, including passwords, as plain text.

SSH uses RSA public key cryptography for both connection and authentication. Two common ways of using SSH are:

- Use automatically generated public-private key pairs to encrypt the network connection and then use password authentication to log on.
- Use a manually generated public-private key pair to perform the authentication and allow users or programs to log in without using a password.

To access the SSH key management page, click on the System menu then the Administration menu on the left and then click on SSH key management.

Figure 10-15 SSH Server Configuration

SSH server configuration

SSH protocol:

Enable password authentication: ☒ ON ☐ OFF

Enable key authentication: ☒ ON ☐ OFF

Host key management

Key type	Date
ssh_host_key	2014-11-05 11:44:23
ssh_host_dsa_key	2014-11-05 11:44:55
ssh_host_rsa_key	2014-11-05 11:45:12
ssh_host_ecdsa_key	2014-11-05 11:45:13

Client key management

Username	Hostname	Key type
----------	----------	----------

SSH Server Configuration

To configure the SSH server settings:

1. Use the SSH Protocol drop down list to select the protocol that you want to use. Protocol 2 is more recent and is considered more secure.

2. Select the types of authentication you want to use by clicking the Enable password authentication and Enable key authentication toggle keys on or off. Note that you may have both authentication methods on but you may not turn them both off.
3. Click the Save button to confirm your settings.

Host key management

SSH keys provide a means of identification using public key cryptography and challenge response authentication. This means that a secure connection can be established without transmitting a password, thereby greatly reducing the threat of someone eavesdropping and guessing the correct credentials.

SSH Keys always come in pairs with one being a public key and the other a private key. The public key may be shared with any server to which you want to connect. When a connection request is made, the server uses the public key to encrypt a challenge (a coded message) to which the correct response must be given. Only the private key can decrypt this challenge and produce the correct response. For this reason, the private key should not be shared with those who you do not wish to give authorization.

The Host key management section displays the current public keys on the router and their date and timestamp. These public keys are provided in different formats, including DSA, RSA and ECDSA. Each format has advantages and disadvantages in terms of signature generation speed, validation speed and encryption/decryption speed. There are also compatibility concerns to consider with older clients when using ECDSA, for example.

Figure 10-16 Host Key Management

Host key management	
Key type	Date
ssh_host_key	2014-07-04 11:48:58
ssh_host_dsa_key	2014-07-04 11:49:15
ssh_host_rsa_key	2014-07-04 11:49:23
ssh_host_ecdsa_key	2014-07-04 11:49:23

Generate keys
Get keys
Get public keys
Upload keys

Generating new keys

The complete set of keys can be re-generated by selecting the Generate keys button. This key generation process takes approximately 30 seconds to complete.

Downloading keys

The Get keys button allows you to download the complete set of public and private keys while the Get public keys button will download only the set of public keys.

Uploading your own key files

You can generate your own SSH keys and upload them to the router. To generate keys on a Linux-based machine, use the following commands:

```
mkdir keys cd keys
```

```
ssh-keygen -t rsa1 -f ssh_host_key -N "" ssh-keygen -t dsa -f ssh_host_dsa_key -N "" ssh-keygen -t rsa -f ssh_host_rsa_key -N ""
```

```
ssh-keygen -t ecdsa -f ssh_host_ecdsa_key -N "" zip -e -P "PASSWORDHERE" -j keys.zip *
```

Click the Upload keys button then locate the generated keys to upload them to the router.

Client key management

The Client Key Management section is used for uploading the public key file of clients. To upload a client public key, click the Upload button, browse to the file and click Open.

Figure 10-17 Client key management

Username	Hostname	Key type
Clear Upload		

When the file is uploaded, it is examined for validity. If the key file is not a valid public key, it will not be uploaded.

LED operation mode

The 8 front LED indicators may be turned off after a timeout period for aesthetic or power saving reasons. To access the LED Operation Mode page, click the System menu, then Administration on the left and finally select LED Operation Mode.

Figure 10-18 LED Operation Mode

LED operation mode

Mode: Turn off after timeout

LED power off timer: (1-65535 minutes)

The Mode drop down list sets the operation mode of the LEDs on the front panel of the router. To set the lights to operate at all times, set this to Always on. To set the lights to turn off after a specified period, select Turn off after timeout. When configured to turn off after timeout, use the LED power off timer field to specify the time in minutes to wait before turning off the LED indicators. The LED Power Off Timer must be an integer between 1 and 65535.

The wait period begins from the time the Save button is clicked. When the wait period expires, the LEDs will turn off. If the router is rebooted, the LED power off timer is reset. The router will boot up and wait for the configured time before turning off again.

Watchdogs

To access the Watchdogs page, click the System menu item, then select the Watchdogs menu item on the left.

Figure 10-19 Watchdogs Settings

Watchdogs settings

When configured, the watchdog feature transmits controlled ping packets to 1 or 2 user specified IP addresses. Should the watchdog not receive responses to the pings, it will reboot the device in a last resort attempt to restore connectivity.

Please be very careful when considering using this feature in situations where the device is intentionally offline for a particular reason (e.g user configured PDP session disconnect, or the connect on demand feature enabled). This is because the watchdog feature expects to be able to access the internet at all times, and will always eventually reboot the router if access isn't restored by the time the various timers and retries expire.

It is due to the nature of the watchdog being a last resort standalone backup mechanism that it will continue to do its job and reboot the device even when the connect on demand session is idle, or the PDP context is disabled by the user. Therefore, it is recommended to disable this feature if connect on demand is configured, or if the PDP context is intentionally disconnected on occasion.

This feature operates as follows:

- After every "Periodic Ping timer" configured interval, the router sends 3 consecutive pings to the "First destination address".
- If all 3 pings fail the router sends 3 consecutive pings to the "Second destination address".
- The router then sends 3 consecutive pings to the "First destination address" and 3 consecutive pings to the "Second destination address" every "Retry timer" configured interval.
- If all retry pings in step C above fail the number of times configured in "Fail count", the router reboots.
- If any ping succeeds the router returns to step A and does not reboot.

Note: The "Periodic Ping timer" should never be set to a value less than 300 seconds- this is to allow the router time to reconnect to the cellular network following a reboot.

To disable the Watchdog, simply set "Fail count" to 0

First destination address

Second destination address

Periodic Ping timer

0

(0=disable, 300-65535) secs

Retry timer

0

(0=disable, 60-65535) secs

Fail count

0

(0=disable, 1-65535) times

Periodic reboot

Force reboot every

0

(0=disable, 5-65535) mins

Randomize reboot time

1 minute

▼

Save

Watchdogs are features which monitor the router for anomalies and restart the router if an anomaly occurs preventing its normal operation. When configured, the watchdogs feature transmits controlled ping packets to 1 or 2 user specified IP addresses to confirm an active connection. If the watchdog does not receive responses to the pings after a specified number of failures, it will reboot the device in a last resort attempt to restore connectivity.

We recommend using caution when implementing this feature in situations where the device is intentionally offline for a particular reason, for example, when Connect-on-demand has been enabled. This is because the watchdog expects to be able to access the internet at all times, and will always eventually reboot the router if access isn't restored by the time the various timers expire and the fail count is reached.

It is due to the nature of the watchdog being a last resort standalone backup mechanism that it will continue to do its job and reboot the device even when the Connect-on-demand session is idle, or the PDP context is disabled by the user. Therefore, we recommended that you disable this feature if Connect-on-demand is configured or if the PDP context is intentionally disconnected on occasion.

The watchdog works as follows:

1. The router sends 3 consecutive pings to the first destination address at the interval specified in the Periodic Ping timer field.
2. If all 3 pings to the first destination address fail, the router sends 3 consecutive pings to the second destination address at the Periodic Ping timer interval.
3. If all 3 pings to the second destination address fail, the router sends 3 pings to the first destination address using the Retry timer interval.
4. If all 3 accelerated pings to the first destination address fail, the router sends 3 pings to the second destination address at the Retry timer interval.
5. If all 3 accelerated pings to the second destination address fail, the router registers this as a fail and returns to step C.
6. When the number of failures reaches the number configured in the Fail count field, the router reboots. If any ping succeeds, the router returns to step A and does not reboot.



Note: The Periodic Ping timer should not be set to a value of less than 300 seconds to allow the router time to reconnect to the cellular network following a reboot.

To disable the periodic ping reset monitor, set Fail count to 0.

Figure 10-20 Ping watchdog settings

The screenshot shows a configuration page for the Ping watchdog settings. It includes the following fields:

- First destination address:** An empty text input field.
- Second destination address:** An empty text input field.
- Periodic Ping timer:** A numeric input field with the value '0'. To its right, the text '(0=disable, 300-65535) secs' is displayed.
- Retry timer:** A numeric input field with the value '0'. To its right, the text '(0=disable, 60-65535) secs' is displayed.
- Fail count:** A numeric input field with the value '0'. To its right, the text '(0=disable, 1-65535) times' is displayed.
- Periodic reboot:** A section header in orange text.
- Force reboot every:** A numeric input field with the value '0'. To its right, the text '(0=disable, 5-65535) mins' is displayed.
- Randomize reboot time:** A dropdown menu currently showing '1 minute'.
- Save:** A blue button at the bottom of the form.

Configuring Periodic Ping settings

The Periodic Ping settings configure the router to transmit controlled ping packets to 2 specified IP addresses. If the router does not receive responses to the pings, the router will reboot.

To configure the ping watchdog:

1. In the First destination address field, enter a website address or IP address to which the router should send the first round of ping requests.

2. In the Second destination address field, enter a website address or IP address to which the router should send the second round of ping requests.
3. In the Periodic Ping timer field, enter an integer between 300 and 65535 for the number of seconds the router should wait between ping attempts. Setting this to 0 disables the ping watchdog function.
4. In the Retry timer field, enter an integer between 60 and 65535 for the number of seconds the router should wait between accelerated ping attempts, i.e. pings to the second destination address. Setting this to 0 disables the ping watchdog function.
5. In the Fail count field, enter an integer between 1 and 65535 for the number of times an accelerated ping should fail before the router reboots. Setting this to 0 disables the ping watchdog function.
- 6.

Disabling the Periodic Ping reset function

To disable the Periodic Ping reset function, set Fail count to 0.



Note: The traffic generated by the periodic ping feature is usually counted as chargeable data usage. Please keep this in mind when selecting how often to ping.

Configuring a Periodic reboot

The router can be configured to automatically reboot after a period of time specified in minutes. While this is not necessary, it does ensure that in the case of remote installations, the router will reboot if some anomaly occurs.

1. In the Force reboot every field, enter the time in minutes between forced reboots. The default value is 0 which disables the Periodic reboot function. The minimum period between reboots is 5 minutes while the maximum value is 65535 minutes.
2. If you have configured a forced reboot time, you can use the Randomise reboot time drop down list to select a random reboot timer. Randomising the reboot time is useful for preventing a large number of devices from rebooting simultaneously and flooding the network with connection attempts. When configured, the router waits for the configured Force reboot every time and then reboots after waiting for a random period that is less than or equal to the Randomise reboot time setting.
3. Click the Save button to save the settings.



Note: The randomise reboot time is not persistent across reboots; each time the router is due to reboot, it randomly selects a time less than or equal to the Randomise reboot time.

Power management

The Power management page provides you with an overview of the power profiles and the ability to configure them. Up to five power profiles may be configured and all of them may be active simultaneously. The Status column indicates whether the profile is active, while the Sleep mode and Wake mode columns summarise the method used to sleep or wake the modem.

To access the Power management page, click the System menu item, then select the Power management menu item on the left.



Note: When configuring multiple power profiles, be careful so that they do not overlap or conflict with one another, for example, configuring a schedule which wakes up the unit when another profile has it scheduled to be in low power mode.

Figure 10-21 Power management

Power management

Power profiles

	Status	Sleep mode	Wake mode	
default	☒ ON ☐ OFF	Scheduled	Ignition	
default	☐ ON ☒ OFF			
default	☐ ON ☒ OFF			
default	☐ ON ☒ OFF			
default	☐ ON ☒ OFF			

Save

To edit a power profile, click the Edit  icon of the appropriate profile.

Figure 10-22 Power Management – Power profile settings

Power profile settings

Profile ☒ ON ☐ OFF

Profile name

Sleep settings

Sleep mode

Schedule sleep at HHMM(24 hour format)

Wake settings

Wake mode

Wake when ignition pin goes ☐ Low ☒ High

Save **Cancel**

Sleep settings

Use the Sleep mode drop down list to select a condition under which the router should enter the sleep state.

Sleep after timer

When this mode is selected, the router will enter the sleep state after the number of minutes specified in the Sleep after field, regardless of the state of the ignition pin.

Figure 10-23 Sleep after timer

The screenshot shows the 'Sleep settings' section. The 'Sleep mode' dropdown is set to 'Sleep after timer'. Below it, the 'Sleep after' field is set to '5' minutes.

Sleep at scheduled time

When this mode is selected, the router goes to sleep at the time specified in the Schedule sleep at field, regardless of the state of the ignition pin. Enter the time in 24 hour format without the semi-colon.

Figure 10-24 Sleep at scheduled time

The screenshot shows the 'Sleep settings' section. The 'Sleep mode' dropdown is set to 'Sleep at scheduled time'. Below it, the 'Schedule sleep at' field is set to '0100' with the label 'HHMM(24 hour format)'.

Sleep triggered by ignition pin

This mode sets the router to enter sleep state when the signal on the ignition pin reaches the specified value.

Figure 10-25 Sleep triggered by ignition pin

The screenshot shows the 'Sleep settings' section. The 'Sleep mode' dropdown is set to 'Sleep triggered by ignition pin'. Below it, the 'Sleep when ignition pin goes' section has two radio buttons: 'Low' (selected) and 'High'. Below that, the 'Remain awake after ignition off' field is set to '2' minutes.

Use the Sleep when ignition pin goes setting to select Low or High. By default, this is set to Low. Additionally, the router will stay on for the number of minutes specified in the Remain awake after ignition off field. The minimum value for this field is 2 minutes with the maximum being 255 minutes.

Wake settings

Use the Wake mode drop down list to select a condition under which the router should return from the sleep state.

Wake triggered by ignition pin

This mode sets the router to wake up when the signal on the ignition pin reaches the specified value.

Figure 10-26 Wake-up triggered by ignition pin

The screenshot shows the 'Wake settings' section. The 'Wake mode' dropdown is set to 'Wake up triggered by ignition pin'. Below it, the 'Wake when ignition pin goes' section has two radio buttons: 'Low' and 'High' (selected).

Use the Wake up when ignition pin goes setting to select Low or High. By default, this is set to High.

Wake up at scheduled time

When this mode is selected, the router wakes up at the time specified in the Schedule wake up at field, regardless of the state of the ignition pin. Enter the time in 24 hour format without the semi-colon.

Figure 10-27 Wake up at scheduled time

Enter the time in seconds to wait before returning from sleep state in the Always wake up after field. A setting of 0 means that the router will automatically wake from sleep state immediately.

USB-OTG

The USB-OTG page displays the current status of the USB port, i.e. whether it is in Device mode or Host mode. By default, Automatic mode is set to ON, allowing the router to intelligently choose the correct mode. If you wish to manually override this selection, you can turn off Automatic mode and set Host or Device mode yourself.

To access the USB OTG page, click the System menu item, then select the USB OTG menu item on the left.

Figure 10-28 USB-OTG configuration

Storage

The Storage page provides configuration options with relation to USB and SD storage devices. To access the Storage page, click the System menu item, then select the Storage menu item on the left.

Storage device list

The Storage devices list displays any connected storage devices and summarises the type, file system, size, used and available space on each device. Additionally, an eject button is provided to unmount the storage device so you can safely remove it.

Figure 10-29 Storage device list

Storage device list

#	Name	Description	File-system	Size	Used	Available	Used (%)	
0	SDDisk0P1	microSD	VFAT	29.7G	15.7G	14.0G	53%	

Network samba storage settings

Storage access ☒ ON ☐ OFF

Verbose logging ☐ ON ☒ OFF

Authenticated access

Username

Password

Verify password

☐ Show password

Read-only ☐ ON ☒ OFF

Guest access

Guest access ☒ ON ☐ OFF

Read-only ☐ ON ☒ OFF

Network Samba storage settings

Storage devices connected to the router can be shared using the Samba protocol. The table below describes the configuration options for the Network Samba storage settings.

Table 10-4 Network samba storage settings

ITEM	DEFINITION
Storage access	Turns the Samba sharing function on or off.
Verbose logging	When turned on, this provides additional logging data in the system log. This should generally only be used when debugging to avoid generating excessively long logs.
Authenticated access	
Username	The username to be used for authenticated access to the storage device. This is configured as 'smbuser' and cannot be changed.
Password	The password to be used for authenticated access to the storage device.
Verify password	The password to be used for authenticated access to the storage device.
Show password	Displays the passwords in the authenticated access fields.

Read-only	When turned on, this provides read-only access to the files on the connected storage device(s). When read-only access for authenticated accounts is turned on, the guest access read-only option is hidden and guests are permitted read-only access also.
Guest access	
Guest access	Enables or disables guest access to the storage device.
Read-only	When turned on, this provides read-only access to the files on the connected storage device(s) for guest users. If the authenticated account has Read-only enabled then this option is not available and read-only access is automatically granted to guest users.


Reboot

The reboot option in the System section performs a soft reboot of the router. This can be useful if you have made configuration changes you want to implement.

To reboot the router:


1. Click the System menu item from the top menu bar.
2. Click the Reboot button from the menu on the left side of the screen.

Figure 10-30 Reboot menu option



3. The router displays a warning that you are about to perform a reboot. If you wish to proceed, click the Reboot button then click OK on the confirmation window which appears.

Figure 10-31 Reboot confirmation



 **Note:** It can take up to 2 minutes for the router to reboot.

Logging out

To log out of the router, click the  icon at the top right corner of the web user interface.

11. Safety and product care

Electrical safety

Accessories

Only use approved accessories.

Do not connect with incompatible products or accessories.

Connection to a car

Seek professional advice when connecting a device interface to the vehicle electrical system.

Distraction

Operating machinery

Full attention must be given to operating the machinery in order to reduce the risk of an accident.

Driving

Full attention must be given to driving at all times in order to reduce the risk of an accident. Using the device in a vehicle can cause distraction and can lead to an accident. You must comply with local laws and regulations restricting the use of mobile communication devices while driving.

Product handling

You alone are responsible for how you use your device and any consequences of its use.

You must always switch off your device wherever the use of a mobile phone is prohibited. Do not use the device without the clip-on covers attached, and do not remove or change the covers while using the device. Use of your device is subject to safety measures designed to protect users and their environment.

Always treat your device and its accessories with care and keep it in a clean and dust-free place.

Do not expose your device or its accessories to open flames or lit tobacco products.

Do not expose your device or its accessories to liquid, moisture or high humidity.

Do not drop, throw or try to bend your device or its accessories.

Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.

Do not paint your device or its accessories.

Do not attempt to disassemble your device or its accessories, only authorised personnel must do so.

Do not expose your device or its accessories to extreme temperatures. Ensure that the device is installed in an area where the temperature is within the supported operating temperature range:

- Class A: -30° C to +70° C
- Class B: -40° C to +85° C (with possible performance deviation)

Do not use your device in an enclosed environment or where heat dissipation is poor. Prolonged use in such space may cause excessive heat and raise ambient temperature, which will lead to automatic shutdown of your

device or the disconnection of the mobile network connection for your safety. To use your device normally again after such shutdown, cool it in a well-ventilated place before turning it on.

Please check local regulations for disposal of electronic products.

Do not operate the device where ventilation is restricted

Installation and configuration should be performed by trained personnel only.

Do not use or install this product near water to avoid fire or shock hazard. Avoid exposing the equipment to rain or damp areas.

Arrange power and Ethernet cables in a manner such that they are not likely to be stepped on or have items placed on them.

Ensure that the voltage and rated current of the power source match the requirements of the device. Do not connect the device to an inappropriate power source.

Small children

Do not leave your device and its accessories within the reach of small children or allow them to play with it.

They could hurt themselves or others or could accidentally damage the device.

Your device contains small parts with sharp edges that may cause an injury or which could become detached and create a choking hazard.

Demagnetisation

To avoid the risk of demagnetisation, do not allow electronic devices or magnetic media close to your device for a long time.

Avoid other magnetic sources as these may cause the internal magnetometer or other sensors to malfunction and provide incorrect data.

Electrostatic discharge (ESD)

Do not touch the SIM card's metal connectors.

Air Bags

Do not place the device in the area near or over an air bag or in the air bag deployment area

Mount the device safely before driving your vehicle.

Emergency & other situations requiring continuous connectivity

This device, like any wireless device, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you must never rely solely on any wireless device for emergency communications or otherwise use the device in situations where the interruption of data connectivity could lead to death, personal injury, property damage, data loss, or other loss.

Device heating

Your device may become warm during normal use.

Faulty and Damaged Products

Do not attempt to disassemble the device or its accessory.

Only qualified personnel should service or repair the device or its accessory.

If your device or its accessory has been submerged in water or other liquid, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorised service centre

Interference

Care must be taken when using the device in close proximity to personal medical devices, such as pacemakers and hearing aids.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15cm be maintained between a device and a pacemaker to avoid potential interference with the pacemaker.

Hearing aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby.

The level of interference will depend on the type of hearing device and the distance from the interference source, increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical devices

Please consult your doctor and the device manufacturer to determine if operation of your device may interfere with the operation of your medical device.

Hospitals

Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Aircraft

Switch off your wireless device whenever you are instructed to do so by airport or airline staff.

Consult the airline staff about the use of wireless devices on board the aircraft, if your device offers a 'flight mode' this must be enabled prior to boarding an aircraft.

Interference in cars

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of devices in their vehicles unless an external antenna is included in the installation.

Explosive environments

Petrol stations and explosive atmospheres

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your device or other radio equipment.

Areas with potentially explosive atmospheres include fuelling areas, below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

Blasting caps and areas

Turn off your device or wireless device when in a blasting area or in areas posted turn off “two-way radios” or “electronic devices” to avoid interfering with blasting operations.

12. Compliance

Manufacturer's Name & Address:

Lantronix, Inc. 48 Discovery, Suite 250, Irvine, CA 92618 USA

Product Family:

NTC-140 Series

Conforms to the following standards or other normative documents:

Country	Specification
USA	Contains FCC ID: XIA-NTC140W
Canada	Contains IC ID: 8847A-NTC140W
EU	EU Declaration of Conformity

RF Exposure

Your device contains a transmitter and a receiver. When it is on, it receives and transmits RF energy. When you communicate with your device, the system handling your connection controls the power level at which your device transmits.

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

This equipment complies with radio frequency (RF) exposure limits adopted by the Federal Communications Commission for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

Tout gain d'antenne externe doit répondre l'exposition aux radiofréquences et les limites de puissance de sortie maximum rayonnée de la section de la règle applicable. Le gain maximal de l'antenne de cet appareil est 3.74 dBi (2500-2690MHz)

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent émetteur radio FCC ID: XIA-NTC140W, IC: 8847A-NTC140W a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés ci-dessus et ayant un gain admissible maximal et l'impédance

requis pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

External antenna

Any optional external antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operated in conjunction with any other antenna or transmitter. Please consult the health and safety guide of the chosen antenna for specific body separation guidelines as a greater distance of separation may be required for high-gain antennas.

Any external antenna gain must meet RF exposure and maximum radiated output power limits of the applicable rule section. The maximum antenna gain for this device is 3.74 dBi (2500-2690MHz).

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication

This radio transmitter FCC ID: XIA-NTC140W, IC: 8847A-NTC140W has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

CE Approval

This device has been tested to and conforms to the regulatory requirements of the European Union and attained CE Marking. The CE Mark is a conformity marking consisting of the letters "CE." The CE Mark applies to the products regulated by the central European health, safety and environmental protection legislation. The CE Mark is obligatory for products it applies to: the manufacturer affixes the marking in order to be allowed to sell their product in the European market.

The wireless device is approved to be used in the member states of the EU. Lantronix declares that the wireless device is in compliance with the essential requirements and other relevant provisions of the Radio and Telecommunications Terminal Equipment Directive 1999/5/EC (R&TTE Directive). Compliance with this directive implies conformity to the following European Norms – N 60950 – Product Safety, EN 301 489 EMC, EN301511 GSM RF, EN301908 UMTS RF, EN 62311 SAR Technical

requirement for radio equipment. A notified body has determined that this device has properly demonstrated that the requirements of the directive have been met and has issued a favourable certificate of expert opinion. As such the device will bear the notified body number 0682 after the CE mark.

The CE Marking is not a quality mark. Foremost, it refers to the safety rather than to the quality of the product. Secondly, CE Marking is mandatory for the product it applies to whereas most quality markings are voluntary.

Marking: The product shall bear the CE mark, the notified body number(s) as depicted to the right. **CE 0682**

NOTE: To comply with the RF exposure requirements, this equipment must be operated with a minimum of 20 cm separation from the user.

This is a regulatory requirement and applies to all 3G capable devices meeting standard regulatory compliance such as the compliance standards listed above.

FCC Statement

FCC compliance

Federal Communications Commission Notice (United States): Before a wireless device model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure.

FCC regulations

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC regulations

CAN ICES-3(B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."

This Class B digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B). Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

IMPORTANT NOTE:**IC radiation exposure statement:**

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and user's body.

Appendix A. Default Settings

The following tables list the default settings for the NTC-140 Series router.

Table A- 1 LAN management default settings

LAN (MANAGEMENT)	
Static IP Address:	192.168.1.1
Subnet Mask:	255.255.255.0
Default Gateway:	192.168.1.1

Table A- 2 Web Interface default settings

ADMIN MANAGER ACCOUNT		ROOT MANAGER ACCOUNT	
Username:	admin	Username:	root
Password:	admin	Password:	admin



Note: The admin manager account allows you to manage all settings of the router except functions such as firmware upgrade, device configuration backup and restore and reset to factory default settings, which are privileged only to the root manager account.

Table A- 3 Telnet access

NTC-140 Series ROUTER TELNET ACCESS	
Username:	root
Password:	admin

Restoring factory default settings

Restoring factory defaults will reset the NTC-140 Series router to its factory default configuration. You may encounter a situation where you need to restore the factory defaults on your NTC-140 Series router such as:

- You have lost your username and password and are unable to login to the web configuration page;
- You are asked to perform a factory reset by support staff.

There are two methods you can use to restore factory default settings on your NTC-140 Series router:

- Using the web-based user interface
- Using the reset button on the interface panel of the router

Using the web-based user interface

To restore your router to its factory default settings, please follow these steps:

1. Open a browser window and navigate to the IP address of the router (default address is <http://192.168.1.1>). Login to the router using **root** as the User Name and **admin** as the password.
2. Click the System item from the top menu bar, then System configuration on the left menu and then click Settings backup and restore.
3. Under the Restore factory defaults section, click the Restore defaults button. The router asks you to confirm that you wish to restore factory defaults. Click OK to continue. The router sets all settings to default. Click OK again to reboot the router.
4. When the Power light returns to a steady red, the reset is complete. The default settings are now restored.

Using the reset button on the interface panel of the router

Use a pen to depress the Reset button on the device for 15-20 seconds. The router will restore the factory default settings and reboot.

When you have reset your NTC-140 Series router to its default settings you will be able to access the device's configuration web interface using <http://192.168.1.1> with username **admin** or **root** and password **admin**.

Appendix B. Recovery mode

The NTC-140 Series router features two independent operating systems, each with its own file systems. These two systems are referred to as 'Main' and 'Recovery'. It is always possible to use one in order to restore the other in the event that one system becomes damaged or corrupted (such as during a firmware upgrade failure). The recovery console provides limited functionality and is typically used to restore the main firmware image in the case of a problem.

Accessing recovery mode

Both systems have web interfaces that can be used to manipulate the other inactive system. The NTC-140 Series router starts up by default in the Main system mode, however the router may be triggered to start in recovery mode if desired.

To start the router in recovery mode:

1. Press and hold the physical reset button on the interface panel of the router for 5 to 15 seconds. When the LEDs on the front panel change to amber and countdown in a sequence, release the reset button. The router then boots into recovery mode.
2. In your browser, navigate to <http://192.168.1.1>. The router's recovery mode is hardcoded to use this address regardless of the IP address that was configured in the main system. The router's recovery console is displayed.

Figure B-1 Recovery Console

NetComm Cellular Router Recovery Console	
Status	Log
Application Installer	Settings
Reboot	
Status	
System Information	
System Up time	00:02:37
Router Version	Hardware: 1.1 Software: V2.0.23.4
Serial Number	173999152800003
Trigger	button
LAN	
IP	192.168.1.1 / 255.255.255.0
MAC Address	18:F1:45:21:0C:4D
Ethernet Port Status	
LAN 1	LAN 2
Down	Up / 1000 Mbps / FDX

Status

The status page provides basic information such as the system up time, hardware and software router versions, the router's serial number, the method used to trigger the recovery mode, the IP and MAC address of the router and the status of the Ethernet port.

Figure B-2 Recovery mode - Status

NetComm Cellular Router Recovery Console	
Status	Log
Application Installer	Settings
Reboot	
Status	
System Information	
System Up time	00:02:37
Router Version	Hardware: 1.1 Software: V2.0.23.4
Serial Number	173999152800003
Trigger	button
LAN	
IP	192.168.1.1 / 255.255.255.0
MAC Address	18:F1:45:21:0C:4D
Ethernet Port Status	
LAN 1	LAN 2
Down	Up / 1000 Mbps / FDX

Log

The log page displays the system log which is useful in troubleshooting problems which may have led to the router booting up in recovery mode. The only functionality provided here is the ability to clear the system log, filter by log level and downloading of the log file.

Figure B-3 Recovery mode - Log

Status	Log	Application Installer	Settings	Reboot
Log File Display Level: Debug Page 1 of 14 Clear Log File				
Date & Time	Machine	Level	Process	Message
Jan 1 00:01:15	ntc_140wx	daemon.info	dnsmasq-dhcp[379]	DHCPINFORM(eth0) 192.168.1.129 00:02:19:0e:3a:19
Jan 1 00:01:11	ntc_140wx	daemon.warn	dnsmasq-dhcp[379]	Ignoring domain corp.netcomm.com.au for DHCP host name NTCWKS0072
Jan 1 00:01:11	ntc_140wx	daemon.info	dnsmasq-dhcp[379]	DHCPACK(eth0) 192.168.1.129 00:02:19:0e:3a:19 NTCWKS0072
Jan 1 00:01:11	ntc_140wx	daemon.info	dnsmasq-dhcp[379]	DHCPREQUEST(eth0) 192.168.1.129 00:02:19:0e:3a:19
Jan 1 00:01:11	ntc_140wx	daemon.info	dnsmasq-dhcp[379]	DHCPOFFER(eth0) 192.168.1.129 00:02:19:0e:3a:19
Jan 1 00:01:11	ntc_140wx	daemon.warn	dnsmasq[379]	overflow: 5 log entries lost
Jan 1 00:00:05	ntc_140wx	daemon.info	dnsmasq[379]	started, version 2.57 cachesize 150
Jan 1 00:00:46	ntc_140wx	user.info	dispd[452]	[disp] boot period time-out - sec=40 sec
Jan 1 00:00:18	ntc_140wx	user.debug	kernel	[18.982219] eth0: no IPv6 routers present
Jan 1 00:00:08	ntc_140wx	user.info	kernel	[8.169219] ADDRCONF(NETDEV_CHANGE): eth0: link becomes ready
Jan 1 00:00:08	ntc_140wx	user.info	kernel	[8.164459] PHY: 0:01 - Link is Up - 10/Half
Jan 1 00:00:06	ntc_140wx	user.info	dispd[452]	force to redraw all LEDs
Jan 1 00:00:06	ntc_140wx	user.info	dispd[452]	[led-off] resetting dim timer (sec) - current timer=0
Jan 1 00:00:06	ntc_140wx	user.info	dispd[452]	[led-off] set dim timer - timer=0 sec
Jan 1 00:00:06	ntc_140wx	user.info	dispd[452]	reset all LEDs to solid off
Jan 1 00:00:06	ntc_140wx	user.err	dispd[452]	set priority (prior=-20)
Jan 1 00:00:06	ntc_140wx	user.info	dispd[452]	syslog LOG_INFO
Jan 1 00:00:06	ntc_140wx	user.err	dispd[452]	syslog LOG_ERR
Jan 1 00:00:06	ntc_140wx	user.err	dispd[452]	=====
Jan 1 00:00:06	ntc_140wx	user.err	dispd[452]	loglevel check
Jan 1 00:00:06	ntc_140wx	user.err	dispd[452]	=====
Jan 1 00:00:06	ntc_140wx	user.info	kernel	[6.167114] PHY: 0:01 - Link is Down
Jan 1 00:00:06	ntc_140wx	user.info	kernel	[6.158908] PHY: 0:01 - Link is Up - 0/Half

[Download Log File](#)

Application Installer

The Application installer is designed to upload and install main firmware images, upload recovery firmware images, custom applications and HTTPS certificates. Use the Browse button to select a file to be uploaded to the router. When it has been selected, press the Upload button. The file is sent to the router and when the transfer is complete, the file appears in the Uploaded files list.

From the Uploaded files list, you are able to either Install or Delete a file.

Figure B- 4 Recovery mode – Application installer

File Name	Date	Size	Action
ntc_140wx_vX.XX.XX.X.cdi	Jan 1 1970	32.9M	Install Delete
ntc_140wx_vX.XX.XX.X_r.cdi	Jan 1 1970	13.6M	Install Delete

Settings

The settings page provides the option of restoring the router to factory default settings. Click the Restore button to set the router back to the original factory settings.

Figure B-5 Recovery mode - Settings

Reboot

The reboot page allows you to reboot the router when you have finished using recovery mode. When rebooting the router from recovery mode, the router boots into the main firmware image unless there is some fault preventing it from doing so, in which case the recovery console will be loaded.

Click the Reboot button to reboot the router to the main firmware image.

Figure B-6 Recovery mode - Reboot

Appendix C. HTTPS – Uploading a self-signed certificate

If you have your own self-signed certificate or one purchased elsewhere and signed by a Certificate Authority, you can upload it to the NTC-140 Series router using the [Upload](#) page.




Note: Your key and certificate files must be named *server.key* and *server.crt* respectively otherwise they will not work.

To upload your certificate:


1. Click on the System item from the top menu bar. From the side menu bar, select System Configuration and then Upload. The file upload screen is displayed.

Figure C-1 Upload page




2. Click the Choose a File button and locate your server certificate file and click Open.


Figure C-2 Browse for server.crt



3. Click the Upload button to begin uploading it to the router. The file appears in the list of files stored on the router.

Figure C-3 Server certificate file uploaded

4. Repeat steps 2 and 3 for the server key file.
5. Click the Install link next to the server.crt file then click OK on the prompt that is displayed. The certificate file is installed. Repeat this for the key file. When each file is installed it is removed from the list of stored files.

Figure C- 4 Installing the server.crt file

Appendix D. RJ-45 connectors

The RJ-45 connectors provide an interface for a data connection and for device input power using the pin layout shown below.

Figure D-1 RJ-45 connector




Table D-1 RJ-45 Connector pin-out

PIN	COLOUR	SIGNAL (10/100)	SIGNAL (1000)
1	White/Orange stripe	Rx + DC +	+BI_DA
2	Orange Solid	Rx - DC +	-BI_DA
3	White/Green stripe	Tx + DC -	+BI_DB
4	Blue solid	unused	+BI_DC
5	White/Blue stripe	unused	-BI_DC
6	Green solid	Tx - DC -	-BI_DB
7	White/Brown stripe	unused	+BI_DD
8	Brown solid	unused	-BI_DD

Appendix E. Input/Output


Overview

The NTC-140 Series router is equipped with a 2 x 2 Molex connector providing a multipurpose input and output terminal as well as a dedicated ignition input. The I/O terminal may be independently configured for various functions, including:

- NAMUR (EN 60947-5-6 / IEC 60947-5-6) compatible sensor input
- Proximity sensor input for use with contact closure (open/closed) type of sensors (PIR sensors, door/window sensors for security applications) with the input tamper detection possible (four states detected: open, closed, short and break) by the use of external resistors
- Analogue 0V to 30V input
- Digital input (the I/O voltage measured by the Analogue input and the software making a decision about the input state) with the threshold levels configurable in software
- Open collector output.

Hardware Interface

The interface of the input/output terminals are based on the circuit diagram below



The Input/Output label is the physical connection to the outside world. There are protection devices and resistor dividers to condition the signal prior to it going into the processor. The three labels to the right are the interface to the processor. Output Enable activates the Transistor which provides an open collector (ground) output and can sink 200 mA at 23C. It is protected by a resettable fuse and transient protection diode. If used with the pull up resistor, which can be activated by the Pull up Voltage Enable pin, then you can have a High or Low output rather than open drain. The resistor can be pulled up to 3V3 for Cmos compatible output or 8.2 V by software. The Analogue Input pin can read values from 0V to 30 V. It is divided by a resistor network to read appropriate levels

in the processor. Depending on the sensor type used, the pull up resistor can be switched on or off. If using the NAMUR sensor configuration, the pull up will be activated to 8V2 by default.

Wiring Examples


The following examples are shown as a guide as to what can be achieved by the I/O features. It is up to the system integrator to have enough knowledge about the interface to be able to achieve the required results.



Warning: Lantronix does not offer any further advice on the external wiring requirements or wiring to particular sensors and will not be responsible for any damage to the unit or any other device used in conjunction with it. Using outputs to control high voltage equipment can be dangerous. The integrator must be a qualified electrician if dealing with mains voltages controlled by this unit.


Open Collector Output driving a relay

Any output can be configured to control a relay. This is an example where the transistor will supply the ground terminal of the solenoid. External voltage is supplied to the other side of the solenoid.




Logic level Output

An output can be used with the pull up resistor to provide a logic level output which would be suitable to control an external digital device.




LED Output

An LED can be controlled by simply providing an open collector ground to an externally powered LED. Resistor value and Voltage will need to suit the LED type used. Alternatively an LED can be powered using 8V2 via 1K resistor. The suitability of the LED will need to be investigated.





There are several ways to connect a digital input. A digital input can be anything from a simple switch to a digital waveform or pulses. The unit will read the voltage in as an analogue input and the software will decode it in a certain way depending on your configuration.

Below is a contact closure type input, which is detecting an Earth. Pull up is activated for this to work.




The following input detects an input going high. The turn on/off threshold can be set in the software.




NAMUR Sensor

A NAMUR sensor is a range of sensors which conform to the EN 60947-5-6 / IEC 60947-5-6 standards. They basically have two states which are reflected by the amount of current running through a sense resistor.




Analogue Sensor with Voltage output

There are various analogue sensors that connect directly to the unit which can provide a voltage output. These would require an external power source which may or may not be the same as the unit itself. The voltage range they provide can be between 0V and 30V. Some common sensor output ranges include 0V to 10V. The pull up resistor is not activated in this case.




Analogue Sensor with 4 to 20mA output

Another common type of sensor type is the 4-20mA current loop sensor. It provides a known current through a fixed resistor, usually 250 ohms thus producing a voltage of 0V to 5V at the input. The sensor would require an external power source which may or may not be the same as the unit itself. It will also require an external resistor. The internal pull up resistor is not activated.




Analogue Sensor with Thermistor

Some sensors work by changing resistance due to a change, such as temperature, light etc. These may be wired up to an external or internal power source and the resistance can be read into the analogue signal. This will require some software calibration like scaling or offset to map the voltage received to the sensor resistor value. An example below shows the internal pull-up voltage and 1K resistor activated. The voltage received depends on the combination of resistors and the value of the resistance of the sensor itself.



System Example –Solar powered Router with battery backup

The previous examples of wiring can be used to come up with a system. The following test case is an example of how the I/O's can be used to enhance a simple router setup.




Appendix F. Obtaining a list of RDB variables

The RDB is a database of variables that contain settings on the router. You can retrieve (get) and set the values of these variables through the command-line or via SMS Diagnostics. To access a full list of the RDB variables, follow these steps:


1. Log in to the web user interface as described in the [Advanced configuration](#) section of this guide.
2. Click the System menu at the top of the screen, then select the Administration menu on the left. Finally, select the Administration settings menu item.
3. Click the Enable Telnet toggle key so that it is in the ON position.

Enable Telnet ☒ ON ☐ OFF

4. Under the Telnet/SSH account section, enter a telnet password and then re-enter it in the Confirm password field.
5. Click the Save button at the bottom of the screen.
6. Open a terminal client such as PuTTY and telnet to the router using its IP address.



7. At the login prompt, type `root` and press Enter. At the password prompt, enter the password that you configured in step 4.
8. At the root prompt, enter the command `rdb dump | more`. This will display a list of every rdb variable on the router one page at a time.



Note: Omitting the `| more` parameter will dump a complete list without pagination. For easier access, some terminal clients such as PuTTY have the ability to log all telnet output to a text file.

Appendix G. Using USB devices and MicroSD™ cards

The NTC-140 Series router features a Micro USB 2.0 OTG port capable of supplying 0.5A to connected devices and a microSD™ card slot allowing additional storage. The Micro USB port supports both USB storage devices as well as certain USB accessories, including USB-to-Ethernet adapters and USB-to-Serial cables.

Accessing USB/SD card storage devices

When a USB storage device or microSD™ card is inserted, the router automatically mounts the storage. To access storage devices:

Windows

1. Open Windows Explorer.
2. In the address bar, type in the network address of the router (\\my.router or \\192.168.1.1 by default), and press Enter. The storage devices are labelled Disk A, Disk B or Disk C.

Mac OS

1. In Mac OS, open a Finder window.
2. Select Go -> Connect to Server.
3. Enter the server address smb://my.router or smb://192.168.1.1
4. Select the volumes you want to mount. Storage devices are labelled Disk A, Disk B or Disk C.

Linux / Smartphones

You can use any Samba client on Linux and Smartphones to access the connected storage devices by navigating to “my.router” or “192.168.1.1” in your chosen Samba client.

Host and Device mode

The USB port automatically detects whether to run in host or device mode. When in host mode, the router automatically mounts USB storage devices. When in device mode, the router supports Ethernet over USB. It is also possible to configure the USB Ethernet port as a WAN port.

Appendix H. NetComm Revision History

Table H-1 NetComm Revision History

Ver.	Document description	Date
1.0	Initial document release	22 July 2015
1.1	Updated I/O configuration description	4 September 2018
1.2	Corrected Data stream manager description	7 September 2018