


Adapt-IQ 21.5" User's Manual

Model: MCT-215LTS



Please keep this manual for future reference.

TABLE OF CONTENTS

	PAGE
DECLARATION.....	1
PRODUCT INSTRUCTIONS.....	1
POWERING ON THE PRODUCT.....	2
INSERTING THE SD CARD.....	2
INSERTING USB DEVICES.....	2
HOME SCREEN.....	3
SYSTEM BAR.....	6
APPLICATIONS.....	9
LANGUAGE.....	10
DATE & TIME.....	11
VOLUME.....	12
BRIGHTNESS.....	12
SCHEDULED POWER ON/OFF.....	13
WI-FI.....	17
ETHERNET.....	18
BLUETOOTH.....	19
VIRTUAL KEYBOARD.....	21
SWITCH INPUT METHODS.....	22
TAKE PHOTOS & SHOTS.....	23
SURF ONLINE.....	26
BROWSE FILES.....	27
PLAY MEDIA.....	28
INSTALL & UNINSTALL APPS.....	29
INSTALL APPS.....	29
UNINSTALL APPS.....	32
RESET TO FACTORY DEFAULT.....	33

Declaration

Please read the instructions carefully before equipment installation and using the device.

Do not put the product in high temperature, humid or dusty environment.

Do not drop, crash or break down this product.

Do not power off the device when it's formatting or upgrading, otherwise it will cause operation system error.

This product is not waterproof.

Use only approved add-on enhancements.

Mechanical Design

- Front Side



- Back Side



1. Camera [2M/5M][Option]
2. VESA mount holes (100x100mm)
3. Speaker
4. IO Cover [Option]
5. Add-on Module Slot
6. Volume Up/Down
7. Menu Navigation
8. Menu

Mechanical Design Continued

Bottom Side Without IO Cover



- 9. Function Key.
- 10. Add-on Module Slot
- 11. LED (power indicator), IR receiver.
- 12. USB 2.0
- 13. RS232 x 2 (in RJ45 connector form)
- 14. Mini-HDMI
- 15. Micro USB
- 16. S/PDIF Out
- 17. Headset + Microphone Jack
- 18. Ethernet RJ45 10/100/1000 Mbps connector
- 19. DC IN
- 20. Power Switch

- Bottom Side with IO Cover [Option]



- 9. Function Key
- 10. Add-on Module Slot
- 11. LED(power indicator),IR receiver.



- 12. Add-on Module Slot
- 14. USB 2.0 Port

Power on the Product

Step 1 Plug the power source into the AC/DC in jack (#8 in **Product Instruction**).

Step 2 Switch the power switch (#15) on the bottom of this product to **ON**.

Insert SD Card

This product supports external SD card. Please insert your SD card into the SD Card Slot (#2 in **Product Instruction**) on the top of this product.

Insert USB Devices

This product supports USB and Micro-USB to deal with your files.

USB

Plug your USB memory into the USB port (#10 in **Product Instruction**) on the bottom of this product, and then you can do the file operations via the File Browser. (See in **Browse Files**).


Micro-USB

Connect the Micro-USB port (#4 in **Product Instruction**) on the bottom of this product and the USB port on your computer with a Micro-USB-to-USB cable.

Click the **“Turn on USB storage”** button in the **“USB mass storage”** window that pops up automatically to make the device memory visible in your computer.


Home Screen

In the home screen, you can long-press the blank space to change the wallpaper or drag widgets to desktop.




Change Wallpaper:

1. Click “WALLPAPER”.




2. Select one picture from system presets or your own pictures.



3. Click “Set wallpaper” on the upper-left corner of the screen to apply the wallpaper.

Add Widgets:


1. Click “WIDGETS”.




2. Long-press a widget and drag it to desktop.



3. A dialog prompts you to allow adding a widget for the first time. Check the checkbox and then click "Create".



4. If you want to remove an icon, long-press the widget and drag it onto “xRemove” at the top of the screen and drop it until it turns red.




System Bar


Navigation Buttons




1. **Volume-:** Decrease the system volume.
2. **Back:** Return to the previous page.
3. **Home:** Return to the home screen.
4. **Recents:** Switch between recently used apps.



To remove an app from the list, you could long-press the icon to select “Remove from list”.



Or swipe the app item up or down to remove it.




5. Volume+: Increase the system volume.

Status Notifications




Status bar at top of the screen displays system status, such as time, Wi-Fi, SD card and USB connection etc.

Pull down the upper-left corner to open the status window.




Pull down the upper-right corner to open the shortcuts window which contains brightness adjustment, Wi-Fi, auto rotate, airplane mode and

location switch, and system settings entrance.




Applications

Click  at the bottom of home screen to enter the applications page.




The installed applications will be shown here and you can open an app by clicking its icon.

To find an app easily, you can create a shortcut by long-pressing of the icon and drag it to the home screen.




Language

In the App list, click “**Settings**”  to open the system setting app, and select the option “**Language & input**”.




Click the first option “**Language**” under “**Language & input**”, and then you can change the system language according to your preference.




Date & Time

In the App list, click “**Settings**”  to open the system setting app, and select the option “**Date & time**”.



If you enabled the option “**Automatic date & time**” under “**Date & time**”, system date and time will be synchronized automatically with network time when you connected a Wi-Fi network.

If you want to set the time manually, you need to disable “**Automatic date & time**” and “**Automatic time zone**”.




In this option, you can also set time zone, time notation and date format.

Volume

On the system bar, click the **Volume-** icon  to decrease the system volume, and click the **Volume+** icon  to increase the system volume. Or you can press the function keys (#7 in **Product Instruction**) at the lower-right corner on the back of the product to adjust the volume.

Brightness

Pull down the upper-right corner of the screen to open the shortcuts window, and then click “Brightness”.




Slide the brightness button to adjust the brightness of the screen, or turn on **Auto** switch to automatically adjust the display's brightness to the appropriate level for the current ambient light.




Scheduled Power On/Off

This function is used to power the device on and off automatically at the set time.


In the App list, click “**Settings**”  to open the system setting app, and select the option “**Scheduled Power ON/OFF**”.




Click the single option “**Set Scheduled Power On/Off Clocks**”.




The top row is for power on clocks, and the following row is for power off clocks. Click the top row to enter the settings of power on clocks.




Click the option “**Time**” to set the power on time of this device.




Click the option “**Repeat**” to select the days which will power on this device at the set time.




After setting, click “**Done**” at the upper-right corner of the screen to save them.



You will see the power on option checked after saving the settings.




For power off clocks, you can set them as same as power on clocks.



After the settings, the device will be powered off at set time, and powered on again when achieves the appointed time.

Wi-Fi


In the App list, click “**Settings**”  to open the system setting app, and select the option “**Wi-Fi**”.



Switch the Wi-Fi button to **ON**. The product will scan available wireless networks automatically. Select a network under Wi-Fi networks and input the password to connect.


Ethernet

In the App list, click “**Settings**”  to open the system setting app, select the option “**More**”, and then select “**Ethernet**” at the right side.



Check “Use Ethernet” and plug the Internet cable into the Ethernet port (#14


in **Product Instruction**). If Wi-Fi is on, please turn off Wi-Fi to allow Ethernet working.



If you are Static IP user, please set the configurations manually.

Bluetooth


In the App list, click “Settings”  to open the system setting app, and select the option “Bluetooth”.




Switch the Bluetooth button to **ON**. The product will scan ambient available Bluetooth devices automatically.

If you want to pair another Bluetooth device, select it from the “Available


Devices” list, and then click “Pair” in the pop-up window. At the same time, click “Pair” in the pop-up window of the Bluetooth device to be paired.




After pairing, the paired device will be moved to the “Paired Devices” list.



If you want to be paired by another Bluetooth device passively, click the Bluetooth name at the top. When the summary will be changed to “Visible to all nearby Bluetooth devices (Visibility timeout)”, this Bluetooth name can be scanned by other Bluetooth devices until the countdown to the end.



The Bluetooth name and visibility timeout can be changed in the menu.




Virtual Keyboard

The device provides a virtual keyboard for typing. You can use it as a real one.


When you click in a text input box, the virtual keyboard will appear at the bottom of the screen.

To collapse the virtual keyboard, you can click the icon  in the system bar.




Switch Input Methods


In any text input box, pull down the upper-left corner of the screen to see the status window, and click “**Choose input method**”.



Select an input method from the pop window.



If the keyboard icon is invisible, please check whether the installed input method is selected in the “**Language & input**” option under the system setting app.




Take Photos & Shots


Front 2M or 5M pixels camera is an optional accessory. In the App list, open  **Camera**
Click the capture button  to take a photo.



Click  above the capture button to change camera settings.




Click  to open detail settings. From left to right in the picture are: location on/off, countdown timer, picture size, white balance, and scene mode.




Click  or  under the capture button to switch take photos or videos.



Click the capture button  to shooting a video.



Click the capture button  to stop the shot.




Surf Online

In the App list, open “**Browser**” .

When connecting the device to a network, you can visit websites, play online media or download files via the browser.


In a browser window, enter in a URL in the address bar and click “**Go**” in the

virtual keyboard to go. You can also click  to add new tabs to make multiple tabs opened simultaneously.




Browse Files


In the App list, open “**Explorer**”  to view local files.



Long-press a file or folder to do file operations, such as copy, delete, move (cut), paste, rename, send (share) and create shortcut.



If you want to select several files/folders at once, click “Multi” in the menu, and then select files/folders. The selected files/folders will be highlighted in blue.



Click “Editor” in the menu to operate the selected files/folders.

Play Media

With the provided apps, you can play your media files on your storage, such

as pictures, music and videos.



Picture Player:

Support JPG, BMP, GIF, JPEG, PNG.



Music Player:

Support MP1, MP2, WMA, WAV, AAC, OGG, APE, FLAC.



Video Player:

Support MKV, TS, FLV, AVI, VOB, MPG, DAT, ASF, RM, MOV, 3GP, MP4, WMV.


Install & Uninstall Apps

Install Apps


Before installing an app, please download the app (.apk) to via the browser, or copy a downloaded app to the device from your computer.

Then you can open “**ApkInstaller**”  in the App list to install the downloaded app.


Click “Install” button.




Choose the installation file's location.




The apk files will be automatically scanned in the right side list.



Click the apk you want to install.




Click “Install” or “Next” until it turns to “Install”, and then waiting for installation finished.




You can also download an android app market, and install the apps via the market.

If “Install blocked” is prompted when installing an app, please open “**Settings**” and select the option “**Security**”, allow “**Unknown sources**” and then back to reinstall the app.




Uninstall Apps


To uninstall an app, please open “**Settings**” in the App list and select the option “**Apps**”. In this option, you will see the installed apps list.



Click the app you want to remove to enter the detail page.



Click the “**Uninstall**” button and select “OK”, and then waiting for uninstallation finished.




Reset to Factory Default


Please make sure to back up the important data before resetting the device.

In the App list, click “**Settings**”  to open the system setting app, and


select the option “**Backup & reset**”.



Click “**Factory data reset**”.



Click “**Reset tablet**” button.



Click “Erase everything” button, and then waiting system reboots and resets to factory default.